

**System Release 7.17**  
**ASTRO® 25**  
**INTEGRATED VOICE AND DATA**



# **GPW 8000 Receiver**

**NOVEMBER 2016**

**MN003283A01-A**

**© 2016 Motorola Solutions, Inc. All rights reserved**



# Copyrights

The Motorola Solutions products described in this document may include copyrighted Motorola Solutions computer programs. Laws in the United States and other countries preserve for Motorola Solutions certain exclusive rights for copyrighted computer programs. Accordingly, any copyrighted Motorola Solutions computer programs contained in the Motorola Solutions products described in this document may not be copied or reproduced in any manner without the express written permission of Motorola Solutions.

© 2016 Motorola Solutions, Inc. All Rights Reserved

No part of this document may be reproduced, transmitted, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without the prior written permission of Motorola Solutions, Inc.

Furthermore, the purchase of Motorola Solutions products shall not be deemed to grant either directly or by implication, estoppel or otherwise, any license under the copyrights, patents or patent applications of Motorola Solutions, except for the normal non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

## Disclaimer

Please note that certain features, facilities, and capabilities described in this document may not be applicable to or licensed for use on a particular system, or may be dependent upon the characteristics of a particular mobile subscriber unit or configuration of certain parameters. Please refer to your Motorola Solutions contact for further information.

## Trademarks

MOTOROLA, MOTO, MOTOROLA SOLUTIONS, and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.

## European Union (EU) Waste of Electrical and Electronic Equipment (WEEE) directive



The European Union's WEEE directive requires that products sold into EU countries must have the crossed out trash bin label on the product (or the package in some cases).

As defined by the WEEE directive, this cross-out trash bin label means that customers and end-users in EU countries should not dispose of electronic and electrical equipment or accessories in household waste.

Customers or end-users in EU countries should contact their local equipment supplier representative or service centre for information about the waste collection system in their country.

This page intentionally left blank.

# Contact Us

## Motorola Solutions Support Center

The Solutions Support Center (SSC) is the primary Motorola Solutions support contact. Call:

- Before any software reload.
- To confirm troubleshooting results and analysis before removing and replacing a Field Replaceable Unit (FRU) and Field Replaceable Entity (FRE) to repair the system.

For...	Phone
United States Calls	<b>800-221-7144</b>
International Calls	<b>302-444-9800</b>

## North America Parts Organization

For assistance in ordering replacement parts or identifying a part number, contact the Motorola Solutions Parts organization. Your first response when troubleshooting your system is to call the Motorola Solutions SSC.

For...	Phone
Phone Orders	<b>800-422-4210</b> (US and Canada Orders) For help identifying an item or part number, select choice 3 from the menu.
	<b>302-444-9842</b> (International Orders) Includes help for identifying an item or part number and for translation as needed.
Fax Orders	<b>800-622-6210</b> (US and Canada Orders)

## Comments

Send questions and comments regarding user documentation to [documentation@motorolasolutions.com](mailto:documentation@motorolasolutions.com).

Provide the following information when reporting a documentation error:

- The document title and part number
- The page number with the error
- A description of the error

We welcome your feedback on this and other Motorola Solutions manuals. To take a short, confidential survey on Motorola Solutions Customer Documentation, go to [docsurvey.motorolasolutions.com](http://docsurvey.motorolasolutions.com) or scan the following QR code with your mobile device to access the survey.



This page intentionally left blank.

# Document History

Version	Description	Date
MN003283A01-A	Original release of the <i>GPW 8000 Receiver</i> manual.	November 2016

This page intentionally left blank.

# Contents

<b>Copyrights.....</b>	<b>3</b>
<b>Contact Us.....</b>	<b>5</b>
<b>Document History.....</b>	<b>7</b>
<b>List of Figures.....</b>	<b>17</b>
<b>List of Tables.....</b>	<b>21</b>
<b>List of Processes.....</b>	<b>25</b>
<b>List of Procedures.....</b>	<b>27</b>
<b>About GPW 8000 Receiver.....</b>	<b>29</b>
What Is Covered In This Manual?.....	29
Helpful Background Information.....	29
Related Information.....	30
<b>Chapter 1: GPW 8000 Receiver Description.....</b>	<b>31</b>
1.1 GPW 8000 Receiver Introduction.....	31
1.2 GPW 8000 Receiver Components.....	32
1.3 GPW 8000 Receiver Backward Compatibility.....	33
1.3.1 Replacing a QUANTAR Station (V.24) with a Trunked GPW 8000 Receiver in a Circuit Simulcast Configuration.....	35
1.3.2 Replacing an ASTRO-TAC Receiver (V.24) with a Trunked GPW 8000 Receiver in a Circuit Simulcast Configuration.....	36
1.4 Supported System Configurations.....	36
1.4.1 Supported Frequencies for Trunked IV and D and Conventional Architectures.....	37
1.5 Overview for a GPW 8000 Receiver in a Trunked IP Voting Subsystem.....	37
1.6 Overview for a GPW 8000 Receiver in Conventional Architectures.....	37
1.6.1 ASTRO 25 Conventional Receiver.....	38
1.6.2 Analog Conventional Receiver.....	38
1.7 Overview of a GPW 8000 Receiver in Circuit Simulcast Configuration.....	39
1.8 GPW 8000 Receiver Power Efficiency Package.....	40
1.9 License Auditing.....	40
1.10 GPW 8000 Receiver Specifications.....	41
1.10.1 GPW 8000 Receiver General Specifications for Integrated Voice and Data.....	41
1.10.2 GPW 8000 Receiver 700/800/900 MHz Specifications for Integrated Voice and Data.....	43
1.10.2.1 GPW 8000 Receiver for Industry Canada (700/800/900 MHz).....	44
1.10.3 GPW 8000 Receiver UHF R1 380–435 MHz Specifications for Integrated Voice and Data.....	45
1.10.3.1 GPW 8000 Receiver for Industry Canada (UHF R1 380–435 MHz).....	46

1.10.4 GPW 8000 Receiver UHF R2 435–524 MHz Specifications for Integrated Voice and Data.....	46
1.10.4.1 GPW 8000 Receiver for Industry Canada (UHF R2 435–524 MHz).....	48
1.10.5 GPW 8000 Receiver VHF 136–174 MHz Specifications for Integrated Voice and Data.....	48
1.10.5.1 GPW 8000 Receiver for Industry Canada (VHF 136–174 MHz).....	50
1.10.6 Specifications for GPW 8000 Receiver Cabinet.....	50
<b>Chapter 2: GPW 8000 Receiver Theory of Operation.....</b>	<b>53</b>
2.1 Functions of the GPW 8000 Receiver Modules.....	53
2.1.1 Function of the Transceiver Module.....	53
2.1.1.1 Transceiver Control Board.....	54
2.1.1.2 Transceiver RF Board .....	55
2.1.1.3 Transceiver External Interfaces.....	55
2.1.2 Function of the Fan Module.....	57
2.1.3 Function of the Power Supply.....	57
2.1.3.1 GPW 8000 Receiver AC/DC Power Distribution.....	58
2.1.3.2 Power Supply Battery Charger.....	61
2.1.3.3 Battery Temperature Sensor Cable.....	62
2.1.3.4 ON/OFF Switch for Power Supply and Battery Charger.....	62
2.1.3.5 Power Supply Module Backplane Connections.....	62
2.2 GPW 8000 Receiver Backplanes and Card Cages.....	63
2.3 RFDS Modules.....	63
2.3.1 RFDS Preselector (700/800 MHz).....	63
2.3.2 RFDS Preselector (UHF).....	64
2.3.3 RFDS Preselector (VHF).....	64
2.3.4 RFDS Splitter.....	65
<b>Chapter 3: GPW 8000 Receiver Installation.....</b>	<b>67</b>
3.1 Pre-Installation Tasks.....	67
3.1.1 Installing GPW 8000 Receiver Equipment.....	67
3.2 General Safety Precautions.....	68
3.2.1 GPW 8000 Receiver Supplemental Safety Installation Requirements.....	69
3.2.2 DC Mains Grounding Connections.....	70
3.2.2.1 Disconnect Device Permanently Connected.....	70
3.2.2.2 Multiple Power Source.....	70
3.2.2.3 Connection to Primary Power.....	70
3.2.2.4 Replaceable Batteries.....	71
3.2.3 Maintenance Requiring Two People.....	71
3.2.4 Equipment Racks.....	71
3.3 General Installation Standards and Guidelines.....	71
3.3.1 General Site Preparation Overview.....	72

3.3.2 General Equipment Inspection and Inventory Recommendations.....	72
3.3.3 General Placement and Spacing Recommendations.....	73
3.3.4 General Cabinet Bracing Recommendations.....	73
3.3.5 Mounting Cabinets or Racks to a Floor.....	73
3.3.6 General Bonding and Grounding Requirements.....	74
3.3.7 General Cabling Requirements.....	74
3.3.8 General Power Guidelines and Requirements.....	75
3.3.8.1 General AC Power Guidelines and Requirements.....	75
3.3.8.2 General Breaker Recommendations.....	76
3.3.8.3 General Battery Installation Recommendations.....	76
3.3.9 General Electrostatic Discharge Recommendations.....	76
3.3.10 GPW 8000 Receiver FCC Requirements.....	77
3.3.11 Networking Tools.....	77
3.3.12 General Installation/Troubleshooting Tools.....	77
3.3.12.1 General Tools.....	77
3.3.12.2 Rack Tools.....	78
3.3.13 Technical Support for Installation.....	78
3.3.13.1 Site-Specific Information.....	79
3.4 GPW 8000 Receiver Hardware Installation.....	79
3.4.1 Placement and Spacing.....	79
3.4.2 Cabinet Version of the GPW 8000 Receiver.....	80
3.4.2.1 Floor Mounting the Cabinet Version of the GPW 8000 Receiver.....	80
3.4.2.2 Physical Dimensions and Clearances of the Cabinet Version of the GPW 8000 Receiver.....	81
3.4.2.3 Cabinet Mounting Rails.....	82
3.4.2.4 Vertical Lifting of Cabinets.....	83
3.4.2.5 Removing/Replacing a Cabinet Door.....	84
3.4.3 Rack Mounting The GPW 8000 Receiver.....	86
3.4.3.1 Mounting the GPW 8000 Receiver.....	86
3.4.4 Connecting Power.....	87
3.4.4.1 GPW 8000 Receiver Power Connections.....	87
3.4.4.2 DC Power Connection Wire Gauge Calculations for GPW 8000 Receiver.....	89
3.4.4.3 Battery Temperature Sensor Mounting.....	90
3.4.5 GPW 8000 Receiver Grounding.....	91
3.4.5.1 Grounding the GPW 8000 Receiver.....	92
3.4.6 GPW 8000 Receiver Rear Connections.....	92
3.4.7 GPW 8000 Receiver Front Connections.....	94
3.4.7.1 System Connector Ports (Conventional).....	96
3.4.7.2 Wireline Port Pin-Outs.....	99

3.4.7.3 Speaker Port Pin-Outs.....	99
3.4.7.4 V.24 Port Pin-Outs.....	100
3.4.7.5 GPW 8000 Receiver Part 68 Information.....	100
3.5 Installation/Troubleshooting Tools.....	101
3.6 Installing Device Software Prerequisites.....	101
3.7 Software Download Manager.....	103
3.8 Installing Devices in the UNC.....	105
3.8.1 Discovering a Device in the UNC.....	105
3.8.2 Loading Device OS Images to the UNC.....	106
3.8.3 Loading Software to a Device.....	107
3.8.3.1 Enabling FTP Service.....	108
3.8.3.2 Transferring and Installing the OS Image.....	108
3.8.3.3 Inspecting Device Properties for Transferred and Installed Software.....	111
3.8.3.4 Disabling FTP Service.....	111
<b>Chapter 4: GPW 8000 Receiver Configuration.....</b>	<b>113</b>
4.1 Configuration Software.....	113
4.2 Discovering a Device in the UNC.....	113
4.3 Security/Authentication Services.....	114
4.4 Device Configuration in CSS.....	115
4.4.1 Configuring a GPW 8000 Initially Using CSS.....	115
4.4.2 Connecting Through a Serial Port Link.....	116
4.4.3 Serial Connection Configurations.....	118
4.4.3.1 Setting the Device IP Address and Pairing Number in CSS.....	118
4.4.3.2 Pairing To a Comparator.....	118
4.4.3.3 Serial Security Services in CSS.....	119
4.4.3.4 Resetting SNMPv3 User Credentials to Factory Defaults in CSS.....	120
4.4.4 Connecting Through an Ethernet Port Link.....	121
4.4.5 Ethernet Connection Configurations.....	123
4.4.5.1 Setting the BR/CM Pairing Number in CSS.....	123
4.4.5.2 Setting the Date and Time in CSS.....	124
4.4.5.3 Changing SNMPv3 Configuration and User Credentials in CSS.....	124
4.4.5.4 DNS Configurations.....	127
4.4.5.5 Customizing the Login Banner in CSS.....	129
4.4.5.6 Setting the SWDL Transfer Mode in CSS.....	129
4.4.5.7 Manager IP Address Settings in CSS.....	130
4.4.5.8 NTP Server Settings in CSS.....	130
4.4.5.9 Setting the Local Password Configuration in CSS.....	131
4.4.6 Setting CSS Configuration Parameters for the GPW 8000 Receiver (Trunked Simulcast).....	132

4.4.7 Setting CSS Configuration Parameters for the GPW 8000 Receiver (Conventional).....	133
4.4.8 Configuring Battery Type.....	134
4.4.9 Setting RMC System Gain.....	134
4.5 Configuring Centralized Authentication on Devices in VoyenceControl.....	135
4.6 Configuring the Trunked GPW 8000 Receiver in Circuit Simulcast Using CSS.....	135
<b>Chapter 5: GPW 8000 Receiver Optimization.....</b>	<b>137</b>
5.1 Aligning the Internal Frequency Reference Oscillator.....	137
5.1.1 GPW 8000 Receiver Time and Frequency Inputs.....	138
5.2 Battery Equalization.....	139
5.3 Carrier Squelch Alignment.....	139
5.4 Rx Wireline Alignment.....	139
5.5 Tuning a Preselector.....	139
5.5.1 VHF Tuning Procedures.....	140
5.5.1.1 Calculating Proper VHF Alignment Frequency.....	140
5.5.1.2 Preparing the Equipment for VHF Alignment.....	141
5.5.1.3 Tuning The VHF Preselector.....	141
5.5.2 UHF Tuning Procedures.....	142
5.5.2.1 Calculating Proper UHF Alignment Frequency.....	143
5.5.2.2 Preparing the Equipment for UHF Alignment.....	144
5.5.2.3 Tuning The UHF Preselector.....	144
5.6 Testing the GPW 8000 Receiver Performance with a Service Monitor.....	145
5.6.1 Deviation Standards (Digital Operation).....	145
5.6.2 Monitoring the Power Supply Module.....	146
5.6.3 Verifying Receiver Performance (Digital Operation).....	146
5.6.4 Verifying Receiver Performance (Analog Operation).....	147
5.6.5 Checking Receiver Sensitivity (Self-Test Method) (IV and D).....	149
<b>Chapter 6: GPW 8000 Receiver Maintenance.....</b>	<b>151</b>
6.1 Fan Grill Cleaning Instructions.....	151
6.2 Aligning the Internal Frequency Reference Oscillator.....	151
<b>Chapter 7: GPW 8000 Receiver Operation.....</b>	<b>153</b>
7.1 GPW 8000 Receiver Operational States for Trunked Simulcast.....	153
7.2 GPW 8000 Receiver Conventional Operational States.....	153
7.2.1 Packet Data Interactions with Multiple NACs.....	153
7.2.2 Supplementary Signaling Interactions with Multiple NACs.....	153
7.3 Illegal Carrier Determination Feature (Trunked).....	154
7.4 RF Channel Interference Determination Feature (Conventional).....	154
<b>Chapter 8: GPW 8000 Receiver Troubleshooting.....</b>	<b>155</b>
8.1 GPW 8000 Receiver General Troubleshooting.....	155

8.2 GPW 8000 Receiver Troubleshooting Tools.....	158
8.2.1 Links and Components Monitoring in Unified Event Manager.....	159
8.2.1.1 Unified Event Manager Active Alarm Window Analyzation.....	159
8.2.1.2 Diagnostic Options in Unified Event Manager.....	159
8.2.2 MOSCAD Network Fault Management for GPW 8000 Receiver.....	160
8.2.3 Device Troubleshooting in Unified Network Configurator.....	161
8.2.4 GPW 8000 Receiver Troubleshooting in Configuration/Service Software.....	161
8.2.4.1 Internal Diagnostic Test Alarm Log.....	161
8.2.4.2 Local Password and SNMPv3 Passphrase Troubleshooting.....	161
8.3 Motorola Solutions Support Center.....	162
8.3.1 Information Necessary to Contact Motorola Solutions Support Center.....	162
8.3.2 Where to Call for Service.....	163
8.3.2.1 Motorola Solutions Support Center.....	163
8.3.3 Subcontractors.....	164
<b>Chapter 9: GPW 8000 Receiver FRU and FRE Procedures.....</b>	<b>165</b>
9.1 GPW 8000 Receiver Field Replaceable Units and Parts.....	165
9.2 Transceiver Hardware Generations.....	168
9.2.1 Transceiver Software and Feature Compatibilities.....	168
9.2.2 Identifying Transceiver Hardware Generation.....	170
9.2.3 Transceiver FRU Number Mappings.....	170
9.3 Replacing a GPW 8000 Receiver Transceiver Module.....	171
9.4 Replacing the Fan Assembly.....	177
9.5 Replacing a Power Supply.....	178
9.6 Replacing a Power Supply Fan.....	180
9.7 Replacing a GPW 8000 Receiver Backplane.....	182
9.8 Replacing a GPW 8000 Receiver Preselector Filter and Splitter.....	187
<b>Chapter 10: GPW 8000 Receiver Reference.....</b>	<b>191</b>
10.1 GPW 8000 Receiver LEDs.....	191
10.1.1 GPW 8000 Receiver Transceiver LEDs.....	191
10.1.1.1 Transceiver Status and Alarm LEDs.....	192
10.1.1.2 Transceiver Ethernet Link Status LEDs.....	192
10.1.1.3 Transceiver Application-Controlled LEDs.....	193
10.1.1.4 Transceiver Services-Controlled LEDs.....	194
10.1.2 Transceiver Option Card Intercom LED.....	194
10.1.3 Fan Module LED.....	195
10.1.4 Power Supply LEDs.....	195
10.2 GPW 8000 Receiver RFDS Equipment Specifications.....	196
10.2.1 Preselector Filter Specifications (700/800 MHz).....	197
10.2.2 Preselector Filter Specifications (UHF).....	197

10.2.3 Preselector Filter Specifications (VHF).....	197
10.2.4 Splitter Specifications.....	198
10.2.5 Performance Sensitivity with RFDS Options.....	198
<b>Chapter 11: GPW 8000 Receiver Disaster Recovery.....</b>	<b>199</b>
11.1 Recovering the GPW 8000 Receiver.....	199
11.2 Performing a Site Software Download With GCP 8000 Site Controllers.....	199
<b>Chapter 12: Standalone GPB 8000 Reference Distribution Module.....</b>	<b>203</b>
12.1 Standalone GPB 8000 Reference Distribution Module Introduction.....	203
12.1.1 GPB 8000 Reference Distribution Module Port Default Speed/Duplex Settings.	204
12.2 GPB 8000 Reference Distribution Module Function.....	205
12.3 GPB 8000 Reference Distribution Module Operational States.....	205
12.4 GPB 8000 Reference Distribution Module Installation.....	206
12.4.1 Standalone GPB 8000 Reference Distribution Module Rear Connections.....	206
12.4.2 Standalone GPB 8000 Reference Distribution Module Front Connections.....	208
12.4.3 GNSS Unit Installation.....	209
12.4.3.1 GNSS Equipment.....	210
12.4.3.2 Assembling the GNSS Antenna.....	210
12.4.3.3 Installing the GNSS Units.....	212
12.4.3.4 Alarm Indication (No Lock on GNSS Signal).....	213
12.4.3.5 GNSS Lightning Arrestor.....	213
12.5 Parameter Configuration for a GPB 8000 Reference Distribution Module.....	215
12.5.1 Configuring the Parameters for a GPB 8000 Reference Distribution Module.....	215
12.6 GPB 8000 Reference Distribution Module General Troubleshooting.....	216
12.7 GPB 8000 Reference Distribution Module FRU and FRE Procedures.....	217
12.7.1 GPB 8000 Reference Distribution Module Field Replaceable Units and Parts....	218
12.7.2 Replacing a GPB 8000 Reference Distribution Module.....	218
12.7.3 Replacing a GPB 8000 Reference Distribution Module Backplane.....	223
12.8 GPB 8000 Reference Distribution Module LEDs.....	227
12.8.1 GPB 8000 Reference Distribution Module Software and Services-Controlled LEDs.....	227
12.8.1.1 GPB 8000 Reference Distribution Module Software-Controlled LEDs...	228
12.8.1.2 GPB 8000 Reference Distribution Module Services-Controlled LEDs...	228
12.8.2 GPB 8000 Reference Distribution Module Status and Alarm LEDs .....	229
12.8.3 GPB 8000 Reference Distribution Module Active/Inactive Status LEDs.....	230
12.8.4 GPB 8000 Reference Distribution Module Link LEDs .....	230
12.9 Recovering the GPB 8000 Reference Distribution Module.....	230
<b>Chapter 13: Standalone Expansion Hubs.....</b>	<b>233</b>
13.1 XHub Port Default Speed/Duplex Settings.....	234
13.2 Expansion Hub Field Replaceable Units and Parts.....	234

13.3 Replacing the Expansion Hub.....	234
13.3.1 Standalone Expansion Hub Connections.....	235
13.4 Expansion Hub LEDs.....	238
<b>Appendix A: Conventional GPW 8000 Receiver Option Kits.....</b>	<b>241</b>
A.1 T2-2R, T3-3R, and T4-4R Receiver Mute Option Kits.....	241
A.1.1 T2-2R Receiver Mute Option Kit.....	241
A.1.1.1 T2-2R Receiver Mute Option Kit Parts List.....	242
A.1.2 T3-3R Receiver Mute Option Kit.....	243
A.1.2.1 T3-3R Receiver Mute Option Kit Parts List.....	244
A.1.3 T4-4R Receiver Mute Option Kit.....	245
A.1.3.1 T4-4R Receiver Mute Option Kit Parts List.....	247
A.1.4 Expected Site Performance for T2-2R, T3-3R, and T4-4R Receiver Mute.....	249
A.1.5 Tn-nR Receiver Mute Option Kit.....	249
A.1.5.1 Tn-nR Receiver Mute Option Kit Parts List.....	250
A.1.6 Installing the T2-2R, T3-3R, and T4-4R Receiver Mute Option Kits.....	251
A.1.7 Configuring the T2-2R, T3-3R, and T4-4R Receiver Mute Option Kits.....	252
A.2 T1-2R with Talk-Around Option Kit.....	255
A.2.1 T1-2R with Talk-Around Option Kit Parts List.....	256
A.2.2 Site Performance Expected for T1-2R with Talk-Around.....	257
A.2.3 Installing the T1-2R with Talk-Around Option Kit.....	258
A.2.4 Configuring the T1-2R with Talk-Around Option Kit.....	259
A.3 T2-2R with Duplexer and Triple Relay Option Kit.....	261
A.3.1 T2-2R with Duplexer and Triple Relay Option Kit Parts List.....	264
A.3.2 Site Performance Expected for T2-2R with Duplexer and Triple Relay.....	265
A.3.3 Installing the T2-2R with Duplexer and Triple Relay Option Kit.....	266
A.3.4 Configuring the T2-2R with Duplexer and Triple Relay Option Kit.....	267

# List of Figures

Figure 1: GPW 8000 Receiver (Front View).....	31
Figure 2: GPW 8000 Receiver (Rear View).....	31
Figure 3: Transceiver Module (Front View).....	53
Figure 4: Transceiver Control Board Information Flow.....	55
Figure 5: Transceiver RESET Switch (viewable through the drop-down door).....	56
Figure 6: Transceiver Option Card Intercom Button (behind the fan module).....	56
Figure 7: Transceiver Module (Backplane Connections) .....	56
Figure 8: Fan Module .....	57
Figure 9: Power Supply.....	58
Figure 10: AC and DC Power Distribution in the GPW 8000 Receiver.....	59
Figure 11: Basic GPW 8000 Receiver Redundant Power Wiring.....	60
Figure 12: Extended GPW 8000 Receiver Redundant Power Wiring.....	61
Figure 13: Power Supply Connections (Rear).....	63
Figure 14: Preselector Filter (700/800 MHz).....	64
Figure 15: Preselector (UHF).....	64
Figure 16: Preselector (VHF).....	65
Figure 17: Splitter.....	65
Figure 18: Warning Label on Hot Modules.....	69
Figure 19: GPW 8000 Receiver (Cabinet Version) – Floor Mounting Detail.....	81
Figure 20: Cabinet Dimensions.....	82
Figure 21: Cabinet Mounting Rails.....	83
Figure 22: Lifting a Cabinet with a Harness.....	84
Figure 23: Cabinet Door Removal.....	85
Figure 24: Cabinet Door Replacement.....	85
Figure 25: Receiver Mounted in Rack .....	86
Figure 26: GPW 8000 Receiver Power Connections.....	88
Figure 27: Battery Temperature Sensor Example 1.....	90
Figure 28: Battery Temperature Sensor Example 2.....	91
Figure 29: Rack Grounding.....	92
Figure 30: GPW 8000 Receiver Backplane.....	93
Figure 31: GPW 8000 Receiver Front.....	95
Figure 32: 50-Pin System Connector Pin-Outs (Conventional).....	98
Figure 33: Wireline Port Pin-Outs.....	99
Figure 34: Speaker Port Pin-Outs.....	100
Figure 35: VoyenceControl Welcome Page.....	108
Figure 36: VoyenceControl Login Window.....	109

Figure 37: VoyenceControl Dashboard.....	109
Figure 38: SNMPv3 Security Level Option Prompt.....	114
Figure 39: CSS Login Banner.....	115
Figure 40: CSS Login Banner.....	117
Figure 41: SNMPv3 Passphrase Prompt.....	123
Figure 42: CSS Network Services Configuration – DNS Tab.....	128
Figure 43: Remote Access Configuration Tab.....	130
Figure 44: Password Configuration Window.....	131
Figure 45: Preselector Tuning — VHF.....	142
Figure 46: Preselector Tuning — UHF.....	144
Figure 47: Metering Screen Window.....	146
Figure 48: MOSCAD Network Fault Management — Tab 1.....	160
Figure 49: MOSCAD Network Fault Management — Tab 2.....	160
Figure 50: GEN 1 Transceiver Module.....	170
Figure 51: GEN 2 Transceiver Module.....	170
Figure 52: Transceiver Module.....	172
Figure 53: GPW 8000 Receiver.....	172
Figure 54: Fan Assembly .....	177
Figure 55: Power Supply.....	179
Figure 56: Power Supply Fan.....	181
Figure 57: GPW 8000 Receiver Showing Connections to Backplane Through Backplane Cover.....	183
Figure 58: Fan Cable Connector.....	185
Figure 59: EMI Spring Panel Guide Rail Alignment.....	186
Figure 60: Preselector Filter and Splitter Mounted to GPW 8000 Receiver.....	187
Figure 61: Preselector Filter.....	187
Figure 62: Preselector Cabling.....	188
Figure 63: Splitter.....	188
Figure 64: Splitter Cabling.....	188
Figure 65: Preselector and Splitter Cabling.....	189
Figure 66: Transceiver LEDs (viewable through a drop-down door).....	192
Figure 67: Transceiver Option Card Intercom LED (viewable behind the fan module).....	195
Figure 68: Fan Module-Alarm LED (lower right corner).....	195
Figure 69: Power Supply Module.....	196
Figure 70: GPB 8000 Reference Distribution Module.....	203
Figure 71: GPB 8000 Reference Distribution Module (Inside Chassis).....	204
Figure 72: Standalone GPB 8000 RDM Backplane Connectors.....	206
Figure 73: GPB 8000 RDM Front Connectors.....	208
Figure 74: GNSS Antenna Assembly – Exploded View.....	211
Figure 75: GNSS Antenna Assembly – Cable.....	211

Figure 76: GNSS Antenna Assembly – Collar Bracket.....	211
Figure 77: GNSS Antenna Assembly – Securing the Pipe.....	212
Figure 78: GNSS Antenna Assembly – Grounding Cable.....	212
Figure 79: Lightning Arrestor – System Connections.....	213
Figure 80: Lightning Arrestor DS109–0129H-A Model Wiring.....	214
Figure 81: Lightning Arrestor DS-IX-2L1M1DC48–IG Model Wiring.....	215
Figure 82: GPB 8000 Reference Distribution Module.....	219
Figure 83: GPB 8000 Reference Distribution Module Connections to Backplane Through Backplane Cover .....	224
Figure 84: Fan Cable Connector.....	226
Figure 85: RDM Software and Services-Controlled LEDs .....	227
Figure 86: Expansion Hub.....	233
Figure 87: Expansion Hub.....	235
Figure 88: XHub Backplane Connectors.....	236
Figure 89: XHub Front Connectors.....	238
Figure 90: Expansion Hub LEDs.....	239
Figure 91: T2-2R Receiver Mute Option Kit Wiring Diagram.....	242
Figure 92: T3-3R Receiver Mute Option Kit Wiring Diagram.....	244
Figure 93: T4-4R Receiver Mute Configuration.....	246
Figure 94: T4-4R Splitter and Antenna Relay Tray.....	246
Figure 95: T4-4R Receiver Mute Option Kit Wiring Diagram.....	247
Figure 96: Tn-nR Receiver Mute Option Kit Wiring Diagram.....	250
Figure 97: CSS - WildCard Tables Example.....	253
Figure 98: T1-2R Talk-Around Option Kit Wiring Diagram.....	256
Figure 99: T2-2R with Duplexer and Triple Relay Configuration.....	261
Figure 100: Triple Antenna Relay Tray.....	262
Figure 101: T2-2R with Duplexer and Triple Relay Option Kit Wiring Diagram.....	263

This page intentionally left blank.

# List of Tables

Table 1: Receiver Modules and Function.....	32
Table 2: Power Consumption.....	40
Table 3: GPW 8000 Receiver General Specifications for IV&D.....	41
Table 4: GPW 8000 Receiver 700/800/900 MHz Specifications for IV&D.....	43
Table 5: GPW 8000 Receiver FCC Identification for IV&D (700/800/900 MHz).....	44
Table 6: GPW 8000 Receiver UHF R1 380–435 MHz Specifications for IV&D.....	45
Table 7: GPW 8000 Receiver FCC Identification for IV&D UHF R1 (380–435 MHz).....	46
Table 8: GPW 8000 Receiver R&TTE Certification for IV&D UHF R1 (380–435 MHz).....	46
Table 9: GPW 8000 Receiver UHF R2 435–524 MHz Specifications for IV&D.....	46
Table 10: GPW 8000 Receiver FCC Identification for IV&D UHF R2 (435–524 MHz).....	48
Table 11: GPW 8000 Receiver R&TTE Certification for IV&D UHF R2 (435–524 MHz).....	48
Table 12: GPW 8000 Receiver VHF 136–174 MHz Specifications for IV&D.....	48
Table 13: GPW 8000 Receiver FCC Identification for IV&D VHF (136–174 MHz).....	50
Table 14: GPW 8000 Receiver R&TTE Certification for IV&D VHF (136–174 MHz).....	50
Table 15: General Specifications for GPW 8000 Receiver Cabinet.....	50
Table 16: Transceiver Front RESET Switch Functions.....	56
Table 17: ON/OFF Switch - States for Power Supply and Battery Charger.....	62
Table 18: Power Supply Module Backplane Connections.....	62
Table 19: Activities for Site Preparation.....	72
Table 20: Heavy Gauge Wire Resistance Examples.....	76
Table 21: GPW 8000 Receiver and Power Supply Cabling Detail (Example).....	88
Table 22: DC Power Connection Wire Gauge Maximum Distances for an IV and D Site.....	89
Table 23: GPW 8000 Receiver Backplane Connections.....	93
Table 24: Transceiver Connections - Front.....	95
Table 25: 50-Pin System Connector Pin-Outs (Conventional).....	96
Table 26: Wireline Port Pin-Outs.....	99
Table 27: Speaker Port Pin-Outs.....	99
Table 28: V.24 Port Pin-Outs.....	100
Table 29: Time and Frequency Inputs.....	138
Table 30: Deviation Standards for ASTRO 25 System Test Patterns.....	145
Table 31: Illegal Carrier Determination.....	154
Table 32: GPW 8000 Receiver General Troubleshooting.....	155
Table 33: Receiver Diagnostic Options in UEM.....	159
Table 34: Local Password and SNMPv3 Passphrase Troubleshooting.....	162
Table 35: GPW 8000 Receiver Field Replaceable Units.....	165
Table 36: GPW 8000 Power Supply Compatibility with AUX PWR Not Connected.....	166

Table 37: GPW 8000 Power Supply Compatibility with AUX PWR Connected.....	167
Table 38: GPW 8000 Receiver Field Replaceable Parts.....	167
Table 39: GPW 8000 Receiver Cabinet Field Replacement Parts.....	167
Table 40: GPW 8000 Receiver Cables.....	168
Table 41: System Feature Exceptions.....	168
Table 42: Minimum Software Download Version Requirements.....	169
Table 43: Transceiver FRU Number Mappings.....	170
Table 44: Transceiver Status and Alarm LEDs.....	192
Table 45: Transceiver Ethernet Link Status LEDs.....	192
Table 46: Transceiver Application-Controlled LEDs.....	193
Table 47: Transceiver Services-Controlled LEDs.....	194
Table 48: Power Supply LEDs.....	196
Table 49: Preselector Filter Specifications (700/800 MHz).....	197
Table 50: Preselector Filter Specifications (UHF).....	197
Table 51: Preselector Filter Specifications (VHF).....	197
Table 52: Splitter Specifications.....	198
Table 53: Specifications with RFDS Options.....	198
Table 54: GPB 8000 Reference Distribution Module Port Default Speed/Duplex Settings.....	204
Table 55: GPB 8000 RDM Backplane Connections.....	206
Table 56: Standalone GPB 8000 RDM and GPW 8000 Receiver Cabling Detail (Example).....	207
Table 57: GPB 8000 RDM Front Connections.....	208
Table 58: GPB 8000 Reference Distribution Module General Troubleshooting.....	216
Table 59: GPB 8000 Reference Distribution Module Field Replaceable Units.....	218
Table 60: GPB 8000 Reference Distribution Module Field Replaceable Parts.....	218
Table 61: RDM Software-Controlled LEDs.....	228
Table 62: RDM Services-Controlled LEDs.....	228
Table 63: RDM Status and Alarm LED Assignment.....	229
Table 64: RDM Status Definitions for the Status/Alarm LEDs.....	229
Table 65: RDM Active/Inactive Status LEDs.....	230
Table 66: RDM Active/Inactive LEDs .....	230
Table 67: RDM Link LEDs.....	230
Table 68: XHub Port Default Speed/Duplex.....	234
Table 69: XHub Field Replaceable Units.....	234
Table 70: XHub Field Replaceable Parts.....	234
Table 71: XHub Backplane Connections.....	236
Table 72: Standalone XHub and GPW 8000 Receiver Cabling Detail (Example).....	237
Table 73: XHub Front Connections.....	238
Table 74: Expansion Hub LEDs with Description.....	239
Table 75: Expansion Hub Status/Alarm LED Assignment .....	239

Table 76: T2-2R Receiver Mute Option Kit Parts List.....	242
Table 77: T3-3R Receiver Mute Option Kit Parts List.....	244
Table 78: T4-4R Receiver Mute Option Kit Parts List.....	247
Table 79: Total Transmit and Receive Attenuation for T2-2R, T3-3R, and T4-4R Receiver Mute.....	249
Table 80: Tn-nR Receiver Mute Option Kit Parts List.....	250
Table 81: T1-2R with Talk-Around Option Kit Parts List.....	256
Table 82: Total Transmit and Receive Attenuation for T1-2R with Talk-Around.....	257
Table 83: T2-2R with Duplexer and Triple Relay Option Kit Parts List.....	264
Table 84: Total Transmit and Receive Attenuation for T2-2R with Duplexer and Triple Relay.....	265

This page intentionally left blank.

# List of Processes

Replacing a QUANTAR Station (V.24) with a Trunked GPW 8000 Receiver in a Circuit Simulcast Configuration .....	35
Replacing an ASTRO-TAC Receiver (V.24) with a Trunked GPW 8000 Receiver in a Circuit Simulcast Configuration .....	36
Installing GPW 8000 Receiver Equipment .....	67
Installing Device Software Prerequisites .....	101
Installing Devices in the UNC .....	105
Discovering a Device in the UNC .....	113
Configuring a GPW 8000 Initially Using CSS .....	115
Setting CSS Configuration Parameters for the GPW 8000 Receiver (Trunked Simulcast) .....	132
Setting CSS Configuration Parameters for the GPW 8000 Receiver (Conventional) .....	133
Configuring Centralized Authentication on Devices in VoyenceControl .....	135
Recovering the GPW 8000 Receiver .....	199
Installing the GNSS Units .....	212
Configuring the Parameters for a GPB 8000 Reference Distribution Module .....	215
Recovering the GPB 8000 Reference Distribution Module .....	230

This page intentionally left blank.

# List of Procedures

Mounting Cabinets or Racks to a Floor .....	73
Lifting Cabinets Vertically .....	83
Removing/Replacing a Cabinet Door .....	84
Mounting the GPW 8000 Receiver .....	86
Grounding the GPW 8000 Receiver .....	92
Discovering a Device in the UNC .....	105
Loading Device OS Images to the UNC .....	106
Enabling FTP Service .....	108
Transferring and Installing the OS Image .....	108
Inspecting Device Properties for Transferred and Installed Software .....	111
Disabling FTP Service .....	111
Connecting Through a Serial Port Link .....	116
Setting the Device IP Address and Pairing Number in CSS .....	118
Setting the Serial Security Services in CSS .....	119
Resetting SNMPv3 User Credentials to Factory Defaults in CSS .....	120
Connecting Through an Ethernet Port Link .....	121
Setting the BR/CM Pairing Number in CSS .....	123
Setting the Date and Time in CSS .....	124
Changing SNMPv3 Configuration and User Credentials in CSS .....	124
Adding or Modifying an SNMPv3 User in CSS .....	127
Performing an SNMPv3 Connection Verification in CSS .....	127
Configuring DNS in CSS .....	128
Customizing the Login Banner in CSS .....	129
Setting the SWDL Transfer Mode in CSS .....	129
Setting the Local Password Configuration in CSS .....	131
Configuring Battery Type .....	134
Setting RMC System Gain .....	134
Configuring the Trunked GPW 8000 Receiver in Circuit Simulcast Using CSS .....	135
Calculating The VHF Alignment Frequency For a Single Receive Frequency .....	140
Calculating The VHF Alignment Frequency for Multiple Receive Frequencies .....	141
Preparing the Equipment for VHF Alignment .....	141
Tuning The VHF Preselector .....	141
Calculating The UHF Alignment Frequency For a Single Receive Frequency .....	143
Calculating the UHF Alignment Frequency for Multiple Receive Frequencies .....	143
Preparing the Equipment for UHF Alignment .....	144
Tuning The UHF Preselector .....	144

Monitoring the Power Supply Module .....	146
Verifying Receiver Performance (Digital Operation) .....	146
Verifying Receiver Performance (Analog Operation) .....	147
Checking Receiver Sensitivity (Self-Test Method) (IV and D) .....	149
Replacing a GPW 8000 Receiver Transceiver Module .....	171
Replacing the Fan Assembly .....	177
Replacing a Power Supply .....	178
Replacing a Power Supply Fan .....	180
Replacing a GPW 8000 Receiver Backplane .....	182
Replacing a GPW 8000 Receiver Preselector Filter and Splitter .....	187
Performing a Site Software Download With GCP 8000 Site Controllers .....	199
Assembling the GNSS Antenna .....	210
Replacing a GPB 8000 Reference Distribution Module .....	218
Replacing a GPB 8000 Reference Distribution Module Backplane .....	223
Replacing the Expansion Hub .....	234
Installing the T2-2R, T3-3R, and T4-4R Receiver Mute Option Kits .....	251
Configuring the T2-2R, T3-3R, and T4-4R Receiver Mute Option Kits .....	252
Installing the T1-2R with Talk-Around Option Kit .....	258
Configuring the T1-2R with Talk-Around Option Kit .....	259
Installing the T2-2R with Duplexer and Triple Relay Option Kit .....	266
Configuring the T2-2R with Duplexer and Triple Relay Option Kit .....	267

# About GPW 8000 Receiver

Includes information about the GPW 8000 Receiver, standalone GPB 8000 Reference Distribution Module (RDM), and standalone Expansion Hub (XHub) which provide inbound coverage for subscriber radios. This manual provides instructions on how to install and configure the GPW 8000 Receiver and the standalone GPB 8000 Reference Distribution Module and standalone Expansion Hub components that support the GPW 8000 Receiver.

## What Is Covered In This Manual?

This manual contains the following chapters:

- [GPW 8000 Receiver Description on page 31](#) provides a high-level description of the GPW 8000 Receiver and the function it serves on your system.
- [GPW 8000 Receiver Theory of Operation on page 53](#) explains how the GPW 8000 Receiver works in the context of your system.
- [GPW 8000 Receiver Installation on page 67](#) details installation procedures relating to the GPW 8000 Receiver.
- [GPW 8000 Receiver Configuration on page 113](#) details configuration procedures relating to the GPW 8000 Receiver.
- [GPW 8000 Receiver Optimization on page 137](#) contains optimization procedures and recommended settings relating to the GPW 8000 Receiver.
- [GPW 8000 Receiver Maintenance on page 151](#) describes periodic maintenance procedures relating to the GPW 8000 Receiver.
- [GPW 8000 Receiver Operation on page 153](#) details tasks to perform once the GPW 8000 Receiver is installed and operational on your system.
- [GPW 8000 Receiver Troubleshooting on page 155](#) provides fault management and troubleshooting information relating to the GPW 8000 Receiver.
- [GPW 8000 Receiver FRU and FRE Procedures on page 165](#) lists the Field Replaceable Units (FRUs) and Field Replaceable Entities (FREs) and includes replacement procedures applicable to the GPW 8000 Receiver.
- [GPW 8000 Receiver Reference on page 191](#) contains supplemental reference information relating to the GPW 8000 Receiver indicator LEDs.
- [GPW 8000 Receiver Disaster Recovery on page 199](#) provides references and information that enables recovery of a GPW 8000 Receiver in the event of failure.
- [Standalone GPB 8000 Reference Distribution Module on page 203](#) provides information on the standalone GPB 8000 Reference Distribution Module (RDM).
- [Standalone Expansion Hubs on page 233](#) provides information on the standalone Expansion Hub (XHub).
- [Conventional GPW 8000 Receiver Option Kits on page 241](#) provides the option kits that are available for the conventional GPW 8000 Receiver.

## Helpful Background Information

Motorola Solutions offers various courses designed to assist in learning about the system. For information, go to <http://www.motorolasolutions.com/training> to view the current course offerings and technology paths.

## Related Information

In addition to the information in the table, see the Related Information Guide.

Related Information	Purpose
<i>Standards and Guidelines for Communication Sites</i>	Provides standards and guidelines that should be followed when setting up a Motorola Solutions communications site. This may be purchased on CD 9880384V83, by calling the North America Parts Organization at 800-422-4210 or the international number at 302-444-9842.
<i>System Overview and Documentation</i>	Provides an overview of the ASTRO® 25 new system features, documentation set, technical illustrations, and system-level disaster recovery that support the ASTRO® 25 radio communication system.
<i>Dynamic System Resilience</i>	Provides all the information required to understand, operate, maintain, and troubleshoot the Dynamic System Resilience feature.
<i>Conventional Operations</i>	Provides the information required to understand and operate the conventional GPW 8000 Receiver in a Centralized or Distributed Conventional Architecture.
<i>Conventional QUANTAR Replacement Guide</i>	Provides instructions for replacing conventional QUANTAR® stations with conventional analog, digital and mixed mode GPW 8000 Receivers.
<i>Trunked IP Simulcast Subsystem Remote Site</i>	Provides the information required to understand and operate the GPW 8000 Receiver in an ASTRO® 25 trunked site.
<i>G-Series Equipment System Release Setup Guide</i>	Provides information and procedures to downgrade the software of G-Series equipment to meet the operating characteristic of a particular ASTRO® 25 system release.
<i>Quick Guide for Replacing a Trunked 3600 QUANTAR with a GTR 8000 Base Radio</i>	Provides instructions for replacing Trunked 3600 QUANTAR base radios with GPW 8000 Receivers. Also provides detailed comparisons of the devices.

## Chapter 1

# GPW 8000 Receiver Description


This chapter provides a high-level description of the GPW 8000 Receiver and the function it serves in your system.

### 1.1

## GPW 8000 Receiver Introduction


This manual provides information on the standalone GPW 8000 Receiver and associated applications.

**Figure 1: GPW 8000 Receiver (Front View)**



GPW\_8000\_Receiver\_front\_w\_callouts\_A

**Figure 2: GPW 8000 Receiver (Rear View)**



GPW\_8000\_receiver\_backplane\_A

A receive-only conventional and/or trunked GPW 8000 Receiver consists of one or two transceiver modules, a fan module, and a power supply. The dual transceiver modules, installed in a dual-slot chassis, permit conventional, trunked, or both capabilities in one unit. The dual-slot chassis allows installing one single transceiver, one conventional or one trunked, or two transceivers, two conventional, two trunked, or one conventional and one trunked. This design allows deploying two receive modules in three rack units of space. One optional preselector and/or splitter can also be supplied.

The transceiver module provides the functionality for the receiver and station control with or without an optional transceiver option card. The software, configuration, network management, and inbound/outbound traffic handling, are performed through the transceiver module. The module contains on-board serial and Ethernet service ports for local servicing through Configuration/Service Software (CSS). The power supply module supports the transceiver modules. Radio Frequency Distribution System (RFDS) provides the interface between the transceivers and the site antennas.



**NOTICE:** The Transceiver Option Card (TOC) is supported only for conventional transceivers; it is not supported for trunked transceivers.

The receiver provides all the receive functions of a GTR 8000 Base Radio as a receive-only station in an ASTRO 25® conventional and trunked architecture or ASTRO® 3.1 Conventional System. The receiver operates in a voting environment with connection to a comparator providing additional receive only stations in areas where it would otherwise be difficult to receive a signal from low-power subscriber units. For conventional operation, the receiver also operates as a monitor receiver in a non-voting environment with connection to a console.

The two transceivers are independent, providing dual-system functionality, so configurations and frequencies can be mixed. In addition, the failure of one transceiver has no effect on the second transceiver. The GPW 8000 Receiver supports the following voice and data transmissions:

- Conventional IP interface voice and data
- Trunked IP interface voice and data
- Conventional V.24 voice and data
- Trunked V.24 voice and data
- Trunked Enhanced Data

The GPW 8000 Receiver receives audio or signaling from a subscriber radio, or data from a radio data user, and forwards it over an IP or V.24 interface. From the user perspective, these transmissions operate transparently without the user being aware of the type of receiver servicing the call.

Various hardware configuration options for the GPW 8000 Receiver include:

- Add or remove a second receive-only channel
- Configure one or two receive-only channels in a single chassis
- Configure a second receive-only channel
- Configure the fan module to use only one fan

## 1.2

## GPW 8000 Receiver Components

Table 1: Receiver Modules and Function

Module	Function
Power Supply	Operates from either an AC or DC input and provides the DC operating voltage for the receiver. If installed, may al-

*Table continued...*

Module	Function
	<p>so provide a separate battery charger, which can be used to maintain the charge on a 48 VDC nominal system, positive or negative ground.</p> <p>The power supply receives auxiliary power from other devices through the AUX PWR IN port, and benefits from the backup power source when needed. It also provides auxiliary power to other devices through the AUX PWR OUT port.</p>
Transceiver (XCVR)	<p>Provides the control and receiver functions.</p> <p> <b>NOTICE:</b> The GPW 8000 Receiver incorporates one or two transceivers.</p>
Transceiver Option Card (for conventional operation only)	<p>An optional board that attaches to the control board of the transceiver. Provides an internal 10 MHz frequency reference, the analog interfaces, and WildCard I/Os. The transceiver option card is available in two categories:</p> <ul style="list-style-type: none"> <li>• Oven Controlled Crystal Oscillator (OCXO)</li> <li>• Temperature Compensated Crystal Oscillator (TCXO)</li> </ul> <p> <b>NOTICE:</b> The OCXO board when initially powered on takes a few minutes to reach its operational temperature. During the warm-up period, if the receiver is configured to use the OCXO frequency reference, the receiver may report a frequency reference failure. This alarm condition automatically clears once the OCXO board has warmed up sufficiently to provide a stable reference.</p>
Fan	Provides intermittent forced air cooling for the transceiver modules.

### 1.3

## GPW 8000 Receiver Backward Compatibility

### Overview of Trunked GPW 8000 Receiver in Circuit Simulcast Configuration

The GPW 8000 Receiver provides the receive function of a GTR 8000 Base Radio as a receive-only station in a trunking architecture or in an ASTRO® system release 6.9 and later trunking system. The receiver operates in a voting environment with connection to a comparator. This arrangement provides additional receive-only stations in areas where it is otherwise difficult to receive a signal from low-power subscriber units.

Trunked GPW 8000 Receivers (V.24) operate within a digital only (V.24) infrastructure, and an ASTRO® system release 6.9 and later trunked circuit simulcast system.

Each trunked GPW 8000 Receiver in circuit simulcast configuration uses a V.24 interface for digital voice and data traffic to a Channel Bank ASTRO-TAC 3000 Comparator and an optional 4-wire link for analog voice in a mixed mode configuration.

### Conventional GPW 8000 Receiver

A conventional GPW 8000 Receiver with dual-slot chassis deployed in an A7.14 or later system release can employ two transceiver modules and support auxiliary power.

For a conventional GPW 8000 Receiver deployed with the dual-slot chassis in a system release before A7.14, only one transceiver module at the bottom slot of the chassis can be employed and no auxiliary power is supported. A GEN 1 or GEN 2 conventional transceiver can be installed in the bottom slot of the dual-slot chassis when used in a system release before A7.14.

For a conventional GPW 8000 Receiver with software supporting the A7.17 system release being deployed in a system supporting zone core software established for a system release earlier than A7.17, the conventional receiver software must be downgraded in the field to match the system release of the zone core for which it is being deployed.

For a conventional GPW 8000 Receiver with software supporting the A7.17 system release that is a replacement for a QUANTAR® that is not managed remotely, the conventional receiver does not need to be downgraded in the field to match the zone core software version.

See the *G-Series Equipment System Release Setup Guide* manual. In this case, use the software media that shipped with your receiver, or contact the Motorola Solutions Support (MSS), if necessary, to ensure your conventional GPW 8000 Receiver works with your system release.

## Trunked GPW 8000 Receiver

The Trunked GPW 8000 Receiver can be integrated into previous ASTRO® 25 system releases by replacing existing receivers without upgrading the entire system to an A7.17 system release. This capability also offers the opportunity to expand existing sites.

Integration is accomplished without changing the software or devices in the existing network. This backward compatibility applies to trunked systems installed on system releases A6.9, and later.

Users of various system releases can replace QUANTAR®/ASTRO-TAC® Receivers with GPW 8000 Receivers before deciding to migrate all multi-site subsystem equipment from circuit-based (V.24-based) to IP-based.

The trunked GPW 8000 Receiver backward compatibility is compatible with the following architectural configurations:

- ASTRO® 25 Trunked M1, M2, and M3 cores
- ASTRO® 25 Trunked L1 and L2 cores

When a trunked GPW 8000 Receiver with software supporting the A7.17 system release is deployed in an A7.14 or later system supporting zone core software established for the A7.14 or later system release, the trunked receiver must be downgraded in the field to match the system release of the zone core for which it is being deployed. The receiver interfaces with the IP network, and therefore has network-based configuration and fault management features associated with the A7.14 or later system release.

For a trunked GPW 8000 Receiver with software supporting the A7.17 system release being deployed in a system release earlier than A7.14, the trunked receiver does not need to be downgraded in the field to match the zone core software version. The receiver does not interface with the IP network and therefore does not have network-based configuration and fault management features available. The GPB 8000 Reference Distribution Module (RDMs) and Expansion Hubs (XHubs) must be deployed to provide frequency references to GPW 8000 Receivers.

## Limitations

The GPW 8000 Receivers used to replace the QUANTAR®/ASTRO-TAC® Receivers (V.24) have the following reduced functionality (limitations) when installed in a prior system release (A7.11 and later):

- The GPW 8000 Receiver is available only to existing users with A7.11 and later releases.
- The receive-only subsite with GPW 8000 receivers has no Ethernet connection for communication with the network management tools and other network devices. Centralized configuration or fault management of GPW 8000 Receivers and GPB 8000 Reference Distribution Modules is not supported.

- The GPW 8000 Receiver subsites have only V.24 circuit link connectivity to the prime site. The IP interface is available only on system release A7.14.
- The GPW 8000 Receivers and GPB 8000 Reference Distribution Modules are configurable using only release A7.17 Configuration/Service Software (CSS).
- The GPW 8000 Receiver supports a single-device software download using Software Download Manager. (SWDL). It does not support site software download using the SWDL network management application.
- The GPW 8000 Receiver does not use Network Time Protocol (NTP). Therefore, local time-of-day drifts compared to the synchronized time maintained by the other system devices.
- Integration with prior release Remote Terminal Units (RTUs) are not supported (RTU serial interface). Trunked A7.15 GPW 8000 Receivers are compatible only with system release A7.17 MOSCAD RTUs.



**NOTICE:** Because the GPW 8000 Receiver has no Ethernet interface for communication with the network management system, configure the receiver locally with any Network Access Code (NAC) changes. When a new Access Code Index (ACI) is sent through the network management system interface to non-GPW 8000 Receiver sites, manually reconfigure all GPW 8000 Receiver NACs with the new ACI at GPW 8000 Receiver sites.

## Software Download of a Trunked GPW 8000 Receiver in Circuit Simulcast Configuration

In circuit simulcast configuration, trunked GPW 8000 Receivers are not compatible with a site software download through the SWDL application. Trunked GPW 8000 Receivers support local single-device software download. See the “Downloading Software to a Single Device” section in the *Software Download Manager* manual

## Replacing a QUANTAR Receiver (V.24) with a Trunked GPW 8000 Receiver in Circuit Simulcast Configuration at a Receive Only Remote Site

A trunked GPW 8000 Receiver can be used as a replacement for an existing circuit simulcast configuration currently populated with QUANTAR® Receivers. CSS supports the service and configuration for the trunked GPW 8000 Receiver. See [Replacing a QUANTAR Station \(V.24\) with a Trunked GPW 8000 Receiver in a Circuit Simulcast Configuration](#) on page 35.

## Replacing an ASTRO-TAC Receiver (V.24) with a Trunked GPW 8000 Receiver in Circuit Simulcast Configuration at a Receive Only Remote Site

The trunked GPW 8000 Receiver can be used as a replacement for the ASTRO-TAC® Receiver (V.24). To replace the ASTRO-TAC® Receiver with the trunked GPW 8000 Receiver, see [Replacing an ASTRO-TAC Receiver \(V.24\) with a Trunked GPW 8000 Receiver in a Circuit Simulcast Configuration](#) on page 36.

### 1.3.1

## Replacing a QUANTAR Station (V.24) with a Trunked GPW 8000 Receiver in a Circuit Simulcast Configuration



**NOTICE:**

This procedure is appropriate for a receive-only remote site

**Prerequisites:** A trunked GPW 8000 Receiver can be added only to an existing circuit simulcast configuration currently populated with QUANTAR® stations. Configuration/Service Software (CSS) supports the service and configuration for the trunked GPW 8000 Receiver.

**Process:**

- 1 Archive the current codeplug for the QUANTAR® station using the WinRSS application. See “Archiving the QUANTAR Codeplug using WinRSS” in the *Quick Guide for Replacing a Trunked 3600 QUANTAR With a GTR 8000 Base Radio*.
- 2 Power down and remove the QUANTAR® station from the trunked 3600 simulcast site. See “Powering Down and Removing the Trunked 3600 QUANTAR” in the *Quick Guide for Replacing a Trunked 3600 QUANTAR With a GTR 8000 Base Radio*.
- 3 Install the trunked GPW 8000 Receiver into the station rack or cabinet. See “Installing a Digital GTR 8000 Base Radio in a Trunked 3600 Simulcast Site” in the *Quick Guide for Replacing a Trunked 3600 QUANTAR With a GTR 8000 Base Radio*.
- 4 Configure the trunked GPW 8000 Receiver using the CSS software. See [Configuring the Trunked GPW 8000 Receiver in Circuit Simulcast Using CSS on page 135](#).

## 1.3.2

## Replacing an ASTRO-TAC Receiver (V.24) with a Trunked GPW 8000 Receiver in a Circuit Simulcast Configuration

**NOTICE:**

- This procedure is appropriate for a receive-only remote site.
- The ASTRO-TAC® Receivers must be replaced in pairs. That is, two ASTRO-TAC® Receivers must be removed to install a dual-chassis GPW 8000 Receiver.

**Prerequisites:** A trunked GPW 8000 Receiver can be added only to an existing circuit simulcast configuration currently populated with ASTRO-TAC® Receivers. The WinRSS application supports the service and configuration for the trunked GPW 8000 Receiver.

**Process:**

- 1 Archive the current codeplug for the ASTRO-TAC® Receivers using the WinRSS application. See *ASTRO-TAC 3000 Comparator Radio Service Software User's Guide Software Part No.: RVN-4154*.
- 2 Power down and remove two adjacent ASTRO-TAC® Receivers from the trunked 3600 simulcast site. See the *ASTRO-TAC 9600 Trunked Simulcast Comparator For 6.0 Simulcast ASTRO 25 Trunking Systems*.
- 3 Install the trunked GPW 8000 Receiver into the station rack or cabinet.  
 **NOTICE:** Because the connector types are not all compatible, check the conversion kit.
- 4 Configure the trunked GPW 8000 Receiver using the Configuration/Service Software (CSS) software. See [Configuring the Trunked GPW 8000 Receiver in Circuit Simulcast Using CSS on page 135](#).

## 1.4

## Supported System Configurations

The GPW 8000 Receiver is available in the following system architectures:

- Centralized Conventional Architectures
- Distributed Conventional (Subsystem) Architecture
- ASTRO® 3.1 Conventional System
- Analog and/or Digital Conventional, Trunked or Mixed-Mode Systems

- Trunked IP or Circuit Simulcast Subsystem with Receive-only Sites
- Trunked IP or Circuit Single Transmit Receiver Voting (STRV) Subsystem

#### 1.4.1

### Supported Frequencies for Trunked IV and D and Conventional Architectures

The GPW 8000 Receiver is available in the following frequency bands:

- 700, 800, 900 MHz (700 MHz analog conventional is not available within the U.S.A. or Canada)
- UHF R1 (380–435 MHz)
- UHF R2 (435–524 MHz)
- VHF (136–174 MHz)



**NOTICE:** RF Distribution Functionality (RFDS) information provided in this documentation pertains to the RFDS equipment supplied by Motorola Solutions.

#### 1.5

### Overview for a GPW 8000 Receiver in a Trunked IP Voting Subsystem

The receiver captures inbound signals through external receive (Rx) antennas from the subscriber/mobile radios. It then amplifies, filters, and demodulates the signals into voice packets which are forwarded to a comparator. The comparator processes the received voice packets for a particular call.

A maximum of 30 receivers can be installed per remote site. Each has an Ethernet connection to a switch at the site for the Network Management interface.

#### 1.6

### Overview for a GPW 8000 Receiver in Conventional Architectures

Throughout this manual, the term “conventional” addresses either an analog only receiver or an ASTRO® 25 Conventional receiver that operates in either digital mode or mixed (analog/digital) mode. Conventional receivers operate within:

- An analog only infrastructure
- A Centralized or Distributed Conventional Architecture, or
- An ASTRO® 3.1 Conventional System.

Each conventional receiver uses either:

- A 2- or 4-wire TRC or 4-wire E&M interface in an analog infrastructure
- A V.24 interface for digital voice and data traffic to either a Channel Bank, Digital Interface Unit, Conventional Channel Gateway (CCGW), MLC 8000, or link converter, ASTRO-TAC 3000 Comparator, and an optional 4-wire link for analog voice in a mixed mode configuration
- An IP interface for digital voice and data traffic to a CCGW or GCM 8000 Comparator.



**NOTICE:** For information about conventional functions and topologies the receiver supports, see the *Conventional Operations* manual. The device can be IP managed while using the 4-wire/V.24 interface for channel traffic.



**NOTICE:** A receiver can be implemented as a QUANTAR® replacement within an ASTRO® 3.1 conventional system. The implementation details can be found in the *Conventional QUANTAR Replacement Guide* manual.

### 1.6.1

## ASTRO 25 Conventional Receiver

ASTRO® 25 Conventional receiver features include:

- Rx network access code
- Voice and data
- Control Messages (TSBK)
- Receive-only station
- Voting
- Console Control
  - Monitor Mode
  - Frequency Select
- WildCard Operation
- Multi-Channel – up to 16 channels
- Multiple Network Access Code (Multi-NAC) Operation
- Scan Operation
- 4-wire and V.24 connections to a DIU or an ASTRO-TAC 3000 Comparator using the same V.24 connector pin-outs as a QUANTAR® station
- Mixed Mode Analog/ASTRO operation

An ASTRO® 25 Conventional receiver can be used in the following architectures:

- ASTRO® 3.1 Conventional Systems
- Centralized Conventional Architectures
  - Zone Core with Colocated Conventional Channels
  - Trunked IP Simulcast Remote Site with Conventional Channels
  - Dispatch Console Site with Colocated Conventional Channels
  - Conventional-Only Remote Site
- Distributed Conventional (Subsystem) Architectures
  - Conventional Base Radio Sites
  - Conventional Hub Sites

### 1.6.2

## Analog Conventional Receiver

Analog conventional receiver features include:

- 12.5 kHz channel operation on all bands; 25 kHz channel operation for UHF T-Band and 800 MHz
- HearClear capability for 800 MHz
- Multi-Channel – up to 16 channel
- Alarm tones over-the-wireline

- WildCard Operation
- E&M Interface and COR receiver I/O
- 2-wire or 4-wire connection to console or Comparator
- Multi-PL receive operation
- PL/DPL
- Tone Remote Control (TRC)
- Interfaces for a local speaker
- Receive-only Analog Functionality
- Scan Operation
- Voting
- Console Control
  - Monitor Mode
  - Frequency Select

An analog conventional receiver can be used in the following architectures:

- ASTRO® 3.1 Conventional Systems
- Centralized Conventional Architectures
  - Zone Core with Colocated Conventional Channels
  - Trunked IP Simulcast Remote Site Conventional Channels
  - Dispatch Console Site with Colocated Conventional Channels
  - Conventional-Only Remote Site
- Distributed Conventional (Subsystem) Architectures
  - Conventional Base Radio Sites
  - Conventional Hub Sites

## 1.7

### Overview of a GPW 8000 Receiver in Circuit Simulcast Configuration

The Circuit Simulcast Configuration is similar to the trunked GPW 8000 Receiver described in [Overview for a GPW 8000 Receiver in a Trunked IP Voting Subsystem on page 37](#) with the following reduced functionality (limitations):

- This configuration has no Ethernet connection for communication with the network management tools and other network devices. The GPW 8000 Receiver subsites have no IP connectivity to the prime site. The IP interface is available only on A7.14 and later.
- The GPW 8000 Receiver subsites have only V.24 circuit link connectivity to the prime site.
- This configuration is configurable only through A7.14 or later Configuration/Service Software (CSS).
- It supports single device software download through the CSS application software, however, it does not support site software download via the Software Download Manager (SWDL).
- Because this configuration does not use Network Time Protocol (NTP), local time-of-day drifts compared to the synchronized time maintained by other system devices.



**NOTICE:** Because the GPW 8000 Receiver has no Ethernet interface for communication with the network management system, configure the receiver locally with any Network Access Code (NAC) changes. When a new Access Code Index (ACI) is sent through the network management system interface to non-GPW 8000 Receiver sites, manually reconfigure all GPW 8000 Receiver NACs with the new ACI at GPW 8000 Receiver sites.

## 1.8

## GPW 8000 Receiver Power Efficiency Package

The GPW 8000 Receiver is available in a Power Efficiency Package, which provides low standby power consumption functionality for ASTRO® 25 Conventional and trunked receivers (see [Table 2: Power Consumption on page 40](#)). The Power Efficiency Package optimizes the power consumption for supported receivers for the use of power generated from alternate energy sources such as solar or wind.

The Power Efficiency Package hardware includes a transceiver, power supply, fan, and optional transceiver option card (internal reference).

The following conditions must be met to obtain a power consumption of less than or equal to 35 W:

- DC source only
- Speaker turned OFF (if equipped with a transceiver option card)
- No activation of Aux Out Relays (if equipped with a transceiver option card)
- No 29 V AUX loads such as GPB 8000 Reference Distribution Modules (RDMs) and gateways
- Configuration/Service Software (CSS) configured for applications not requiring receiver diversity
- Ambient temperature of 104 °F (40 °C) or less (Single fan operation, disabling one of the fans within the fan module. See [Replacing the Fan Assembly on page 177](#) for instructions on how to disable the fan.)
- Transceiver, power supply, fan, and TCXO transceiver option card (internal reference) are all power efficiency package versions



**NOTICE:** The TCXO transceiver option card is available only for non-simulcast conventional systems. The OCXO transceiver option card is available for conventional simulcast systems, but adds 20 W.

**Table 2: Power Consumption**

	AC Maximum	DC Maximum
Dual Transceiver Modules	105 W	75 W
With Power Efficiency Option (Single Module)	40 W	30 W
With Power Efficiency Option (Dual Modules)	65 W	50 W

## 1.9

## License Auditing

License auditing for ASTRO® 25 G-series devices at M and L core systems can be enabled through the License Manager to ensure that site licenses have been purchased and also to prevent the transfer of site licenses across systems.

The License Manager performs the following functions:

- Monitors the number of site devices in use within the system.

- Audits the number of active licenses.
- Displays a noncompliance notification on the Unified Event Manager (UEM) when the number of devices exceeds the licenses.

If a site license is not present, the following functions do not occur:

- Send or receive audio
- Vote audio
- Implement site control functions; such as assigning channels or calls.

Any issues with an existing site license are sent to the UEM without system functionality being restricted.

### 1.10

## GPW 8000 Receiver Specifications

The following GPW 8000 Receiver Specifications reference the appropriate TIA specifications including the following methods and performance recommendations:

Phase 1 (includes Linear Simulcast):

- Methods: TIA-102.CAAA-C, "Digital C4FM/CQPSK Transceiver Measurements Methods" September 2008
- Performance: TIA-102.CAB-C, "Land Mobile Radio Transceiver Performance Recommendations, Project 25 – Digital Radio Technology, C4FM/CQPSK Modulation" January 2010

Phase 2:

- Methods: TIA-102.CCAA, "Two-Slot Time Division Multiple Access Transceiver Measurement Methods" August 2011
- Performance: TIA 102.CCAB, "Two-Slot Time Division Multiple Access Transceiver Performance Recommendations" October 2011



**IMPORTANT:** Specifications are subject to change without notice.

### 1.10.1

## GPW 8000 Receiver General Specifications for Integrated Voice and Data

Table 3: GPW 8000 Receiver General Specifications for IV&D

Item	Specification
Model Number	T7540A
Number of Channels (trunked)	1
Number of Channels (conventional)	16
Size (H x W x D)	133 mm x 483 mm x 457 mm (5.25 inches x 19 inches x 18 inches) 3 rack units
Weight	16.3 kg (36 lb)
Humidity (non-moisture condensing)	50 °C (122 °F)

*Table continued...*

Item	Specification
	90% Humidity
Temperature Range	
Operating:	-30 to 60 °C (-22 to 140 °F)
Storage:	-40 to 85 °C (-40 to 185 °F)
Operating Altitude	Up to 1800 meters (5900 ft) above mean sea level Above 1800 meters (5900 ft), the derating is 1.5 °C/km (0.8 °F/1000 feet) Above 3000 meters (9800 ft), the peak power derating for the cavity combiner and phasing harness is 1 dB/1km (0.3 dB/1000 feet)
Power Requirements	AC: 90-264 VAC, 47-63 Hz DC: 43.2-60 VDC
Number of Transceivers	One or two
Power Consumption — one transceiver	
AC:	80 W max
DC:	50 W max
Power Consumption — two transceivers	
AC:	105 W max
DC:	75 W max
Power Consumption with Power Efficiency Option — one transceiver	
AC:	40 W max
DC:	30 W max
Power Consumption with Power Efficiency Option — two transceivers	
AC:	65 W max
DC:	50 W max
Power Supply Type	Switching
Battery Revert	Included
Input/Output Impedance	50 Ohms
Frequency Stability — OCXO	
Temperature, Voltage, and One Year Aging	0.10 ppm
Temperature	0.04 ppm
Aging per Year	0.03 ppm
Aging per 5 Years	0.1 ppm

*Table continued...*

Item	Specification
Frequency Stability — TCXO (available only with the Power Efficiency Package for non-simulcast, conventional systems)	
Temperature, Voltage, and One Year Aging	1.5 ppm
Temperature	0.5 ppm
Aging per Year	1.0 ppm
Frequency Generation	Synthesized at multiples of 2.5 kHz or 3.125 kHz
RF Input Connector	BNC female
RF Input Connector with Optional Preselector	N female

## 1.10.2

**GPW 8000 Receiver 700/800/900 MHz Specifications for Integrated Voice and Data**

Table 4: GPW 8000 Receiver 700/800/900 MHz Specifications for IV&amp;D

Item	Specification
Model Number	T7540A
Frequency Range	792–825 MHz or 896–902 MHz
Electronic Bandwidth	Full Bandwidth
Modulation	C4FM, Analog FM, H-CPM
Channel Spacing	12.5/25 kHz
Sensitivity (12 dB SINAD)	
	12.5 kHz -118 dBm
	25 kHz -117 dBm
Sensitivity 5% Bit Error Rate Static (BER)	
	C4FM: -118 dBm
	H-CPM: -116 dBm
Faded Sensitivity 5% Bit Error Rate (BER)	
	C4FM: -110 dBm
Sensitivity degradation with Preselector	1.0 dB
Sensitivity degradation with Splitter	4.5 dB
Sensitivity degradation with Preselector and Splitter	5.0 dB
Intermodulation Rejection	85 dB
Digital Adjacent Channel Rejection (TIA-102)	60 dB
Analog Adjacent Channel Rejection (EIA-603)	75 dB
Analog	

*Table continued...*

Item	Specification	
Analog Adjacent Channel Rejection (TIA-603D)	12.5 kHz	50 or 60 dB (adjustable)
	25 kHz	80 dB
Offset Channel Selectivity		20 dB
Spurious and Image Response Rejection		85 dB 100 dB with narrow preselector
Blocking Immunity		100 dB
Signal Displacement Bandwidth		1 kHz
Conducted Spurious		-57 dBm
Bit Error Rate Floor		0.01%
RX Wireline Level (at 60% deviation)		-20 to 0 dBm (adjustable)
Analog FM Hum and Noise	12.5 kHz	45 dB
	25 kHz	50 dB
Analog Audio Distortion	12.5 kHz	3% or 5% (selectable in CSS)
	25 kHz	3%
Analog Audio Frequency Response		+1, -3 dB from 6 dB per octave de-emphasis referenced to 1 kHz
Co-Channel Rejection C4FM		9 dB
Intermediate Frequencies	First:	73.35 MHz
	Second:	2.16 MHz

Table 5: GPW 8000 Receiver FCC Identification for IV&amp;D (700/800/900 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
896-902 MHz	Receiver	N/A	ABZ89FR5824B
806-825 MHz	Receiver	N/A	ABZ89FR5811B
799-805 MHz	Receiver	N/A	ABZ89FR5811B

## 1.10.2.1

**GPW 8000 Receiver for Industry Canada (700/800/900 MHz)**

The GPW 8000 Receiver is verified to meet Industry Canada requirements for unintentional radiators for the following IC frequency bands:

- 700 MHz: 798–806 MHz
- 800 MHz: 806–824 MHz
- 900 MHz: 896–901 MHz

## 1.10.3

**GPW 8000 Receiver UHF R1 380–435 MHz Specifications for Integrated Voice and Data**

Table 6: GPW 8000 Receiver UHF R1 380–435 MHz Specifications for IV&amp;D

Item	Specification	
Model Number	T7540A	
Electronic Bandwidth	Full band	
Frequency Range	380–435 MHz	
Modulation	C4FM, H-CPM, Analog FM	
Channel Spacing	12.5/25 kHz	
Analogue Sensitivity (12 dB SINAD)		
	12.5 kHz	-118 dBm
	25 kHz	-117 dBm
Digital Sensitivity 5% Bit Error Rate Static (BER)		
	C4FM:	-118 dBm
	H-CPM:	-116 dBm
Faded Sensitivity 5% Bit Error Rate (BER)		
	C4FM:	-110 dBm
Sensitivity degradation with Preselector	2.0 dB	
Sensitivity degradation with Splitter	4.0 dB	
Sensitivity degradation with Preselector and Splitter	5.0 dB	
Intermodulation Rejection	85 dB	
Digital Adjacent Channel Rejection (TIA-102)	60 dB	
Analog Adjacent Channel Rejection (EIA-603) Analog	75 dB	
Analog Adjacent Channel Rejection (TIA-603D)		
	12.5 kHz	50 or 60 dB (adjustable)
	25 kHz	80 dB
Spurious and Image Response Rejection	85 dB	
	100 dB with preselector	
Blocking Immunity	100 dB	
Signal Displacement Bandwidth	1 kHz	
Conducted Spurious	-57 dBm	
Bit Error Rate Floor	0.01%	
RX Wireline Level (at 60% deviation)	-20 to 0 dBm (adjustable)	
Analog FM Hum and Noise		

*Table continued...*

Item	Specification	
	12.5 kHz	45 dB
	25 kHz	50 dB
Analog Audio Distortion		
	12.5 kHz	3% or 5% (Selectable in CSS)
	25 kHz	3%
Analog Audio Frequency Response		+1, -3 dB from 6 dB per octave de-emphasis referenced to 1 kHz
Co-Channel Rejection C4FM		9 dB
Intermediate Frequencies		
	First:	73.35 MHz
	Second:	2.16 MHz

Table 7: GPW 8000 Receiver FCC Identification for IV&amp;D UHF R1 (380–435 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
350–435 MHz	Receiver	N/A	ABZ89FR4822B

Table 8: GPW 8000 Receiver R&amp;TTE Certification for IV&amp;D UHF R1 (380–435 MHz)

R&TTE Certification			
Frequency Range	Type	Power Output	R&TTE Option Number
350–435 MHz	Receiver	N/A	CA02310AA

#### 1.10.3.1

#### GPW 8000 Receiver for Industry Canada (UHF R1 380–435 MHz)

The GPW 8000 Receiver is verified to meet Industry Canada requirements for unintentional radiators for the following IC frequency bands:

- UHF R1: 406.1-430 MHz

#### 1.10.4

#### GPW 8000 Receiver UHF R2 435–524 MHz Specifications for Integrated Voice and Data

Table 9: GPW 8000 Receiver UHF R2 435–524 MHz Specifications for IV&amp;D

Item	Specification
Model Number	T7540A
Electronic Bandwidth	Full band

*Table continued...*

Item	Specification	
Frequency Range	435–524 MHz	
Modulation	C4FM, H-CPM, Analog FM	
Channel Spacing	12.5/25 kHz	
Analogue Sensitivity (12 dB SINAD)		
	12.5 kHz	-118 dBm
	25 kHz	-117 dBm
Digital Sensitivity 5% Bit Error Rate Static (BER)		
	C4FM:	-118 dBm
	H-CPM:	-116 dBm
Faded Sensitivity 5% Bit Error Rate (BER)		
	C4FM:	-110 dBm
Sensitivity degradation with Preselector	2.0 dB	
Sensitivity degradation with Splitter	4.0 dB	
Sensitivity degradation with Preselector and Splitter	5.0 dB	
Intermodulation Rejection	85 dB	
Digital Adjacent Channel Rejection (TIA-102)	60 dB	
Analog Adjacent Channel Rejection (EIA-603)	75 dB	
Analog		
Analog Adjacent Channel Rejection (TIA-603D)		
	12.5 kHz	50 or 60 dB (adjustable)
	25 kHz	80 dB
Spurious and Image Response Rejection	85 dB 100 dB with preselector	
Blocking Immunity	100 dB	
Signal Displacement Bandwidth	1 kHz	
Conducted Spurious	-57 dBm	
Bit Error Rate Floor	0.01%	
RX Wireline Level (at 60% deviation)	-20 to 0 dBm (adjustable)	
Analog FM Hum and Noise		
	12.5 kHz	45 dB
	25 kHz	50 dB
Analog Audio Distortion		
	12.5 kHz	3% or 5% (Selectable from CSS)
	25 kHz	3%

Table continued...

Item	Specification
Analog Audio Frequency Response	+1, -3 dB from 6 dB per octave de-emphasis referenced to 1 kHz
Co-Channel Rejection C4FM	9 dB
Intermediate Frequencies	
First:	73.35 MHz
Second:	2.16 MHz

Table 10: GPW 8000 Receiver FCC Identification for IV&amp;D UHF R2 (435–524 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
435–524 MHz	Receiver	N/A	ABZ89FR4820B

Table 11: GPW 8000 Receiver R&amp;TTE Certification for IV&amp;D UHF R2 (435–524 MHz)

R&TTE Certification			
Frequency Range	Type	Power Output	Option Number
435–524 MHz	Receiver	N/A	CA02310AA

#### 1.10.4.1

### GPW 8000 Receiver for Industry Canada (UHF R2 435–524 MHz)

The GPW 8000 receiver-only unit has been verified to meet Industry Canada requirements for unintentional radiators for the following IC frequency bands:

- UHF R2: 450–470 MHz

#### 1.10.5

### GPW 8000 Receiver VHF 136–174 MHz Specifications for Integrated Voice and Data

Table 12: GPW 8000 Receiver VHF 136–174 MHz Specifications for IV&amp;D

Item	Specification
Model Number	T7540A
Electronic Bandwidth	Full band
Frequency Range	136–174 MHz
Modulation	C4FM, H-CPM, Analog FM
Channel Spacing	12.5/15/25/30 kHz
Analogue Sensitivity (12 dB SINAD)	
12.5 kHz	-119 dBm
25 kHz	-118 dBm

*Table continued...*

Item	Specification	
Digital Sensitivity 5% Bit Error Rate Static (BER)	C4FM:	-119 dBm
	H-CPM:	-117 dBm
Faded Sensitivity 5% Bit Error Rate (BER)	C4FM:	-111 dBm
Sensitivity degradation with Preselector		2.0 dB
Sensitivity degradation with Splitter		4.0 dB
Sensitivity degradation with Preselector and Splitter		5.0 dB
Intermodulation Rejection		85 dB
Digital Adjacent Channel Rejection (TIA-102)		60 dB
Analog Adjacent Channel Rejection (EIA-603)		75 dB
Analog		
Analog Adjacent Channel Rejection (TIA-603D)		
	12.5 kHz	50 or 60 dB (adjustable)
	25 kHz	80 dB
Spurious and Image Response Rejection		90 dB
		95 dB with preselector
Blocking Immunity		100 dB
Signal Displacement Bandwidth		1 kHz
Conducted Spurious		-57 dBm
Bit Error Rate Floor		0.01%
RX Wireline Level (at 60% deviation)		-20 to 0 dBm (adjustable)
Analog FM Hum and Noise		
	12.5 kHz	45 dB
	25 kHz	50 dB
Analog Audio Distortion		
	12.5 kHz	3% or 5% (Selectable in CSS)
	25 kHz	3%
Analog Audio Frequency Response		+1, -3 dB from 6 dB per octave de-emphasis referenced to 1 kHz
Co-Channel Rejection C4FM		9 dB
Intermediate Frequencies		
	First:	44.85 MHz
	Second:	2.16 MHz

Table 13: GPW 8000 Receiver FCC Identification for IV&amp;D VHF (136–174 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
136–174 MHz	Receiver	N/A	ABZ89FR3791B

Table 14: GPW 8000 Receiver R&amp;TTE Certification for IV&amp;D VHF (136–174 MHz)

R&TTE Certification			
Frequency Range	Type	Power Output	Option Number
136–174 MHz	Receiver	N/A	CA02310AA

#### 1.10.5.1

### GPW 8000 Receiver for Industry Canada (VHF 136–174 MHz)

The GPW 8000 receiver-only unit has been verified to meet Industry Canada requirements for unintentional radiators for the following IC frequency bands:

- VHF: 138–174 MHz

#### 1.10.6

### Specifications for GPW 8000 Receiver Cabinet

Table 15: General Specifications for GPW 8000 Receiver Cabinet

General Specifications	
Height	
Cabinet Version (Option CA02446AA):	31 in. (78.74 cm) 15 Rack Units
Cabinet Version (Option CA02447AA):	47 in. (119.4 cm) 24 Rack Units
Footprint (W x D)	24 in. x 24 in. (609.6 mm x 609.6 mm)
Weight (empty cabinet)	
Cabinet Version (Option CA02446AA):	77.6 lb (35.2 kg)
Cabinet Version (Option CA02447AA):	123 lb (55.8 kg)
Weight (with one receiver)	
Cabinet Version (Option CA02446AA):	98.6 lb (44.72 kg)
Cabinet Version (Option CA02447AA):	144 lb (65.32 kg)
Maximum Stack Quantity*	2
Maximum Stack Height	

Table continued...

**General Specifications**

Cabinet Version (Option CA02446AA):	62 in. (157.48 cm)	
Cabinet Version (Option CA02447AA):	94 in. (238.76 cm)	
Temperature Range, Operating		
Cabinet without Doors:	-22 to 140 °F (-30 to 60 °C)	
Cabinet with Doors:	-22 to 131 °F (-30 to 55 °C)	
Temperature Range, Storage	-40 to 185 °F (-40 to 85 °C)	
Maximum Recommended Ambient with # of Receivers**		
	<b>31 in. 15 RU Cabinet</b>	<b>47 in. 24 RU Cabinet</b>
1	55	55
2	55	55
3	50	55
4	NR	55
5	NR	50
6	na	50
7	na	NR
8	na	NR
Operating Altitude		
	Up to 1800 meters (5900 ft) above mean sea level Above 1800 meters (5900 ft), the derating is 1.5 °C/km (0.8 °F/1000 feet)	
	Maximum operational altitude is 5000 meters (16900 ft)	

\* = If different size cabinets are being stacked, place the larger cabinet on the bottom. Use a 9/16 in. hexagon head screw with washer and lock nut. The minimum bolt size must not be smaller than 1/2 in.

\*\* = NR - Not recommended. Though the cabinet does have enough available space to accommodate this number of chassis, typically some peripherals, RFDS, networking, and other equipment may be colocated and occupy the remaining space. In addition, a few RUs of space for cable egress is recommended at the top of the cabinet so cables do not interfere with the airflow from the equipment. If adding more equipment than shown, validate that the internal cabinet temperature does not exceed the rating of any installed devices.

This page intentionally left blank.

## Chapter 2

# GPW 8000 Receiver Theory of Operation

For an understanding of the GPW 8000 Receiver components theory of operation, review the modules that provide the receiver functionality, the modules that provide RF Distribution Functionality (RFDS), and the backplane that connects to other modules within the site.

### 2.1

## Functions of the GPW 8000 Receiver Modules

The following are GPW 8000 Receiver modules:

- One or two transceiver (XCVR) modules (with or without a transceiver option card)
- Fan module
- Power supply module

### 2.1.1

## Function of the Transceiver Module

The transceiver module provides the control, receiver, and optional transceiver option card for the receiver.

**Figure 3: Transceiver Module (Front View)**



GTR8000\_XCVR\_wSAC

The transceiver generates the station reference, which typically must be locked on to one of many possible external sources. For a trunked GPW 8000 Receiver, the external source is a combined 1PPS /10 MHz (time and frequency) from the GPB 8000 Reference Distribution Modules (RDMs), through additional Expansion Hubs (XHubs), which connect to Global Navigation Satellite System (GNSS) or TRAK devices.

For Time Division Multiple Access (TDMA) or Frequency Division Multiple Access (FDMA) with Enhanced Data, both time and frequency references are required. This configuration includes a standalone model of RDMs (two modules), and GNSS or TRAK devices. RDMs receive 1PPS input from GNSS or TRAK devices and provide 1PPS /10 MHz to trunked GPW 8000 Receivers.

If only FDMA voice and FDMA IV&D data are provided, only frequency references are required, including a standalone model of RDMs (two modules) without GNSS or TRAK devices. RDMs are configured without external 1PPS input. The trunked GPW 8000 Receiver still must be configured to use an integrated reference input through the CP2 link from the RDM external source, but only needs 10 MHz from RDMs for frequency reference.

For conventional-only GPW 8000 receivers, an external source of 5 MHz frequency is applicable, and the Transceiver Option Card provides an internal frequency reference.

The transceiver SPI bus allows communication with its receiver circuitry, as well as the power supply module.

Two or three circuit boards in the transceiver are:

#### **Transceiver Control Board**

Performs the control management, digital signal processing, and receive data formatting for the receiver.

#### **Transceiver RF Board**

Contains DC power conversion/regulation and performs receiver functions.

#### **Transceiver Option Card**

An optional board that attaches to the control board. Provides an internal 10 MHz frequency reference. For conventional operation, it also provides the analog interfaces and WildCard I/Os. The transceiver option card requires an internal frequency reference oscillator alignment at different intervals mandated by its category and frequency band. See Base Radio Service Help > Service Screens > Alignment Screens in the *CSS Online Help* for the alignment procedures and mandated intervals.



**NOTICE:** The Transceiver Option Card is supported only for conventional transceivers; it is not supported for trunked transceivers.

The transceiver option card is available in two categories:

- **OCXO (Oven Controlled Crystal Oscillator)** – operates at 0.1 ppm and is inclusive to temperature and aging. The OCXO Transceiver Option Card is available in 700/800 MHz, UHF R1/R2, and VHF frequency bands.
- **TCXO (Temperature Compensated Crystal Oscillator)** – operates at 1.5 ppm, of which 0.5 ppm is allocated to temperature, and 1.0 ppm is allocated to aging. Reference precision with the TCXO is traded for lower power consumption. The TCXO mandates shorter maintenance intervals. The TCXO transceiver option card is available in UHF R1/R2 frequency bands. The TCXO is only available for non-simulcast conventional systems.

##### 2.1.1.1


#### **Transceiver Control Board**

The main operating software for the receiver is loaded in the XCVRs control section. As the main manager for the receiver, the XCVR control board provides operational control over the other station modules. It handles three types of information flow, in the following ways:

- Serves as a gateway between the network and RF functionality, by distributing the RF payload to and from the network.
- Supports operational and diagnostic functions with digital control data (for example: site information, channel assignments, and identification numbers for call processing).
- Ensures the flow of other network management configuration information.

[Figure 4: Transceiver Control Board Information Flow on page 55](#) shows the information flow through the transceiver control and RF sections for trunked and conventional operation.

**Figure 4: Transceiver Control Board Information Flow**



### 2.1.1.2

## Transceiver RF Board

In addition to DC power conversion/regulation, the XCVR RF board provides circuitry for the following receiver functions.

### 2.1.1.2.1

### Exciter

The Exciter is present in a GPW 8000 Receiver, but is powered down to save energy.

### 2.1.1.2.2

### Receiver

The receiver provides either a single receive path or dual-branch diversity. Dual-branch diversity can be enable or disabled, and is applicable only to Time Division Multiple Access (TDMA) access. The receiver also provides enhanced diagnostic capabilities using an on-board noise source generator. It includes a wide tuning range (electronic varactor-tuned) preselector. The preselector is electronically tuned to the desired receive frequency anywhere between 792–900 MHz, UHF R1 380–435 MHz, UHF R2 435–524 MHz, or VHF 136–174 MHz.

### 2.1.1.3


## Transceiver External Interfaces

The transceiver external interfaces include seven external ports, a switch, and LEDs. If a transceiver option card is part of the transceiver, there are four additional external ports. See [GPW 8000 Receiver Front Connections on page 94](#) for the port connections. See [GPW 8000 Receiver LEDs on page 191](#) for information on the LEDs.

### 2.1.1.3.1

### Transceiver Switch

The RESET switch on the front of the transceiver module is accessible through the drop-down door to the left of the fans.


**Figure 5: Transceiver RESET Switch (viewable through the drop-down door)****Table 16: Transceiver Front RESET Switch Functions**

User Action	Result
Press switch for more than 3 seconds, then release	Transceiver Control Module Reset

### 2.1.1.3.2

#### **Transceiver Option Card Intercom Button**


The intercom button on the front of the transceiver option card is accessible behind the fan module. Pressing the intercom button toggles the intercom function between the ON and OFF states.

**Figure 6: Transceiver Option Card Intercom Button (behind the fan module)**

### 2.1.1.3.3

#### **Transceiver Ports (Rear)**

The transceiver interconnects to the backplane using a 120-pin HVDML digital connector and 8-pack RF connector, as shown in the figure. These connections handle multiple signals including power supply communications, fan interface, and peripheral interface. The digital connection receive alarm data and the site controller Time Division Multiplexer (TDM) signals are used to pass reference and control data to the receiver.

**Figure 7: Transceiver Module (Backplane Connections)**

### Single Receiver Input

An RJ-45 Ethernet port on the backplane is cabled to a site LAN switch for this channel. The backplane also provides an RF connection to the transceiver for receive (Rx) path A.

### Dual Receiver Input

The backplane also provides RF connections to the transceiver for receive (Rx) paths A and B (TDMA).

#### 2.1.2

### Function of the Fan Module

The fan module provides intermittent forced-air cooling for the transceiver module. The fan module houses two 119 mm axial fans which deliver a total of approximately 160 cubic feet per minute of airflow. Nominal fan speed is 4100 revolutions per minute. A thermostat behind the fan module controls each fan. If the fan speed for either fan falls below 30% of the rated speed, a built-in speed sensor on each fan turns on the red Fan Alarm LED.

If the fan module is used for the Power Efficiency Package, the following must be configured in the Configuration/Service Software (CSS) to take full advantage of the Power Efficiency Package:


- Disabling one of the fans within the fan module. See [Replacing the Fan Assembly on page 177](#) for instructions on how to disable one of the fans.

The fan module connects to the backplane through a 4-pin port on the front of the chassis.



**NOTICE:** The power supply module has its own fan which provides independent airflow.

**Figure 8: Fan Module**



#### 2.1.3

### Function of the Power Supply

The power supply, with front-to-rear airflow, operates from either an AC or DC input and provides the DC operating voltage for the receiver. However the power supply prioritizes an AC source (if present) over a DC source.

**Figure 9: Power Supply**

G\_series\_power\_supply\_A



**NOTICE:** If the power supply module is used for the Power Efficiency Package, the power supply must be used in DC mode to obtain the 35 W standby power consumption performance.

When operating from an AC source (90 to 264 VAC, 47-63 Hz), the supply generates two DC output voltages of 29 V with respect to output ground. The power supply automatically adjusts to AC input ranges and supplies a steady output.

In AC mode, the power supply may provide a separate battery charger which can be used to maintain the charge on a 48 VDC nominal system, positive or negative ground, if installed. The supply generates two DC output voltages of 29 V with respect to output ground, when operating from a DC source (43.2 VDC to 60 VDC maximum), positive or negative ground. This voltage limit includes consideration of the battery charging "float voltage" associated with the intended supply system, regardless of the marked power rating of the equipment. Whether in AC, Battery Revert, or DC Only mode, at a voltage of 42 V or lower, the power supply shuts down to not damage any connected battery bank. Once this condition occurs, the power supply starts only after the applied voltage exceeds 45 V.

The battery charger is not usable when operating from a DC input power source. This DC source must be located in the same building as the receiver, and it must meet the requirements of a SELV circuit.

The power supply contains several switching-type power supply circuits as follows:

- Power factor correction circuitry
- Battery charging circuitry
- Diagnostics and monitoring circuitry

The power supply controls its own continuously running fan, changing its speed to fast, or slow as needed.



**NOTICE:** If the power supply module is used for the Power Efficiency Package, the power supply fan does not run below a 40 °C air inlet temperature.


#### 2.1.3.1

### GPW 8000 Receiver AC/DC Power Distribution

When both AC and 48 VDC are present, the GPW 8000 Receiver operates from AC power. When AC power is not available, the receiver switches to operate from the DC source. Operation returns to the

AC source when the AC source is restored. Switchover from AC to DC and back again is fully automatic. No operator action is required. The battery charger outputs of more than one GPW 8000 Receiver should not be connected together. If neither AC nor DC power is available, the receiver operates using power from the AUX PWR IN connector.

**Figure 10: AC and DC Power Distribution in the GPW 8000 Receiver**




AC\_DC\_Power\_Distribution\_in\_GPW\_8000\_Receiver\_A

DC power can be connected if the optional DC power cable is ordered and installed. The cable plugs into the backplane.

DC input voltage range is 43.2 VDC to 60 VDC, positive or negative ground. This voltage limit includes the battery charging “float voltage” associated with the intended supply system, regardless of the marked power rating of the equipment.


The main DC output of the power supply is used to provide power to the transceiver modules. The auxiliary DC output of the power supply is used as a redundant power source for another GPW 8000 Receiver chassis at the site.

The GPW 8000 Receiver power supplies may be wired such that each chassis power supply provides and receives alternate power from another GPW 8000 Receiver chassis. By implementing this wiring method, a failure of a power supply does not result in loss of receiver function. This wiring is achieved using the AUX PWR IN and AUX PWR OUT connections on the backplane cover. A cable is included with each chassis to make these connections.

**Figure 11: Basic GPW 8000 Receiver Redundant Power Wiring**

Basic\_GPW\_8000\_Receiver\_Redundant\_Power\_Wiring\_A

Figure 12: Extended GPW 8000 Receiver Redundant Power Wiring



Extended\_GPW\_8000\_Receiver\_Power\_Redundancy\_Wiring\_A

#### 2.1.3.2

### Power Supply Battery Charger

The power supply may include an integrated battery charger. The battery charger is controlled through software residing on the associated device module. Software contains the information on supported battery types and obtains user-specific information pertaining to the particular site. The device software receives battery bus voltage and battery temperature information from the power supply, and uses these variables with supported battery charging profiles to return a signal which sets the charger output voltage appropriately. The battery charge and temperature conditions are viewed through Configuration/Service Software (CSS) and Unified Network Configurator (UNC), or through alarms to Unified Event Manager (UEM).

The maximum charging current available from the integrated charger is 3 A (48 VDC nominal system). A battery with capacity no larger than 60 Ah should be connected to a single charger to ensure that the charger maintains an adequate state-of-charge on the backup battery, and the backup battery is restored to full capacity within a reasonable amount of time following operation on battery backup power.

In addition to standard sealed lead-acid batteries (valve-regulated lead acid or gel cells), the power supply supports charging of vented lead-acid and NiCd batteries.

## 2.1.3.3

**Battery Temperature Sensor Cable**

The integrated charger in the power supply performs temperature compensated battery charging when a temperature sensor is connected. If the sensor is disconnected, the charger continues to operate as an uncompensated charger with the charging profile following the minimum charger voltage specified by the battery manufacturer.

Included is a 40 ft battery temperature sensor cable, which attaches to a battery pack, supplied by your organization, and to the backplane of the device. This three-wire cable carries a voltage signal to the power supply from the sensor element, which must be mounted close to the storage battery. Voltage is proportional to the battery temperature, and the diagnostic circuitry in the power supply module. This cable is extended to a total length of 190 ft using 50 ft extensions. See [Battery Temperature Sensor Mounting on page 90](#).



**IMPORTANT:** Continuous operation with a disconnected sensor is not recommended.

## 2.1.3.4

**ON/OFF Switch for Power Supply and Battery Charger**

This table identifies the switch states for the power supply and battery charger.

Table 17: ON/OFF Switch - States for Power Supply and Battery Charger

Switch Position	Power Supply State	Battery Charger State
ON (1)	<ul style="list-style-type: none"> <li>Power Factor Correction (PFC) section is active (AC input only)</li> <li>Main DC converter runs to create the MAIN and AUX DC outputs</li> </ul>	DLN6781A can be started if desired (AC input only) DLN6805A Disabled
OFF (0)	<ul style="list-style-type: none"> <li>Main DC converter is turned OFF and the MAIN and AUX DC outputs become 0.0 VDC</li> </ul>	Disabled (AC input only)



**NOTICE:** If the power switch is switched "off" while AUX IN power is connected, the power remains "on".

## 2.1.3.5

**Power Supply Module Backplane Connections**


This table provides descriptions and functions of the power supply backplane connections.

Table 18: Power Supply Module Backplane Connections

Port/Type	Description
AC	Input only
Battery / DC Power and	<b>48 VDC:</b> <ul style="list-style-type: none"> <li>Provides the DC input to the power supply when operating from a DC source.</li> </ul>

Port/Type	Description
Control Signal	<ul style="list-style-type: none"> <li>Connects the charger output to the standby battery when operating from an AC input with a standby DC battery.</li> </ul> <p><b>29 VDC:</b></p> <ul style="list-style-type: none"> <li>Provides the Main and Auxiliary DC outputs of the power supply for use by the transceiver.</li> </ul> <p>Other signals this connector handles include control interface and battery temperature interface.</p>

**Figure 13: Power Supply Connections (Rear)**



G\_Series\_PS\_Rear1

## 2.2

## GPW 8000 Receiver Backplanes and Card Cages

Card cages are created with a welded and riveted design. Each card cage has a backplane. See [GPW 8000 Receiver Rear Connections on page 92](#).

## 2.3

## RFDS Modules

The Radio Frequency Distribution System (RFDS) equipment included in your system depends on which options were purchased from Motorola Solutions. The following are some examples of the RFDS equipment available for your system.




**NOTICE:** If the RTTE option was selected, a duplexer is required for applicable applications.


### 2.3.1

### RFDS Preselector (700/800 MHz)

The preselector provides a first level of band pass filtering for inbound RF signals. RF input and output connectors are cabled to the RF Output RX-A. This filter must be included to fulfill TIA102-CAAB Class A spurious response rejection (90 dB). The filter is not required when using a receiver multicoupler system. This filter CANNOT be retuned in the field.


**Figure 14: Preselector Filter (700/800 MHz)****2.3.2****RFDS Preselector (UHF)**

The preselector rejects unwanted signals including the transmitter signals from overloading the receiver. This filter must be included to fulfill TIA102-CAAB Class A spurious response rejection (90 dB). The filter is not required when using a receiver multicoupler system. This filter can be retuned in the field.

**Figure 15: Preselector (UHF)****2.3.3****RFDS Preselector (VHF)**

The preselector rejects unwanted signals including the transmitter signals from overloading the receiver. This filter must be included to fulfill TIA102-CAAB Class A spurious response rejection (90 dB). The filter is not required when using a receiver multicoupler system. This filter can be retuned in the field.

**Figure 16: Preselector (VHF)**



#### 2.3.4

### RFDS Splitter

A receiver RF splitter is an option for GPW 8000 Receivers. Splitters are also included with T2-2R, T3-3R, and T4-4R options. The splitter is a passive device so its loss degrades the sensitivity of the receivers. The splitter is mounted on the rear of the chassis.

**Figure 17: Splitter**



GPW\_8000\_Receiver\_Splitter\_A

This page intentionally left blank.

## Chapter 3

# GPW 8000 Receiver Installation

This chapter details installation procedures relating to the GPW 8000 Receiver.

3.1

## Pre-Installation Tasks

Follow this process to perform the installation tasks. Ensure that you have the following:

- Appropriate cables
- Access to Software Download Manager (SWDL), Configuration/Service Software (CSS), and the Unified Network Configurator (UNC)
- IP/DNS information
- Login and password information

3.1.1

### Installing GPW 8000 Receiver Equipment



#### NOTICE:

- A trunked GPW 8000 Receiver in Circuit Simulcast Configuration supports single device software download through Configuration/Service Software (CSS) application software. A trunked GPW 8000 Receiver in Circuit Simulcast Configuration does not support site software download via the Software Download Manager (SWDL).
- A trunked GPW 8000 Receiver in Circuit Simulcast Configuration has no Ethernet connection for communication with the network management tools and other network devices. Centralized configuration or fault management of GPW 8000 Receivers and GPB 8000 Reference Distribution Modules (RDMs) are not supported.

#### Process:

- 1 Prepare the site to comply with the Motorola Solutions requirements and specifications for the equipment, as listed in the *Standards and Guidelines for Communication Sites* manual. The receiver may be installed in a suitable, restricted access, indoor enclosure in any location suitable for electronic communications equipment. Other codes and guidelines that may apply to the location must also be met. See [General Safety Precautions on page 68](#).
- 2 Inspect and inventory all racks, cabinets, cables, and other equipment with a Motorola Solutions representative to ensure that the order is complete. See [General Installation Standards and Guidelines on page 71](#).
- 3 Various tools are used to install and service the equipment. If information is needed regarding where to obtain any of the equipment and tools listed, contact the Motorola Solutions Support Center (SSC). See [General Installation/Troubleshooting Tools on page 77](#) for a list of general recommended tools for installing and servicing the hardware.
- 4 Install all equipment using the site drawings and other documents the Field Engineer provides. Use the installation standards and guidelines for placing and installing equipment.
- 5 Properly ground all the racks and cabinets to protect against ground faults, electrical surges, and lightning. See [GPW 8000 Receiver Hardware Installation on page 79](#).

- 6 Connect all necessary cables within a rack and between the racks for system interconnection. See [GPW 8000 Receiver Rear Connections on page 92](#) and [GPW 8000 Receiver Front Connections on page 94](#).
- 7 Run a preliminary check of a site before applying power.
- 8 See [Installing Device Software Prerequisites on page 101](#) for a list of items you need access to before installing the software.
- 9 See [Installing Devices in the UNC on page 105](#) to discover the receiver and to load OS software images from the Unified Network Configurator (UNC).  
This step does not apply to Trunked GPW 8000 Receivers in Circuit Simulcast Configuration.
- 10 See [Device Configuration in CSS on page 115](#) to program the configurations into the receiver using Configuration/Service Software (CSS).
- 11 See [Configuring Centralized Authentication on Devices in VoyanceControl on page 135](#) to program the receiver using UNC.  
This step does not apply to Trunked GPW 8000 Receivers in Circuit Simulcast Configuration.

### 3.2

## General Safety Precautions



**WARNING:** Compliance with FCC guidelines for human exposure to Electromagnetic Energy (EME) at Transmitter Antenna sites generally requires that personnel working at a site must be aware of the potential for exposure to EME, and can exercise control of exposure by appropriate means, such as adhering to warning sign instructions, using standard operating procedures (work practices), wearing personal protective equipment, or limiting the duration of exposure. For more details and specific guidelines, see "Appendix A" of the Motorola Solutions *Standards and Guidelines for Communications Sites* manual.

Observe the following general safety precautions during all phases of operation, service, and repair of the equipment described in this manual. Follow the safety precautions listed and all other warnings and cautions necessary for the safe operation of all equipment. See the appropriate section of the product service manual for additional pertinent safety information. Due to the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modifications of equipment.



**NOTICE:** The installation process requires preparation and knowledge of the site before installation begins. Review installation procedures and precautions in the Motorola Solutions *Standards and Guidelines for Communications Sites* manual before performing any site or component installation.

Always follow all applicable safety procedures, such as Occupational Safety and Health Administration (OSHA) requirements, National Electrical Code (NEC) requirements, local code requirements, and safe working practices. Also, all personnel must practice good judgment. General safety precautions include the following:


- Read and follow all warning notices and instructions marked on the product or included in this manual before installing, servicing, or operating the equipment. Retain these safety instructions for future reference.
- If troubleshooting the equipment while power is on, be aware of the live circuits.
- Ground all equipment properly in accordance with the Motorola Solutions *Standards and Guidelines for Communications Sites* manual and specified installation instructions for safe operation.
- Slots and openings in the cabinet are provided for ventilation. Do not block or cover openings that protect the devices from overheating.
- Only a qualified technician familiar with similar electronic equipment should service equipment.

- Some equipment components can become hot during operation. Turn off all power to the equipment and wait until sufficiently cool before touching.
- Maintain emergency first aid kits at the site.
- Direct personnel to call in with their travel routes to help ensure their safety while traveling between remote sites.
- Institute a communications routine during certain higher risk procedures where the on-site technician continually updates management or safety personnel of the progress so that help can be dispatched if needed.
- Never store combustible materials in or near equipment racks. The combination of combustible material, heat, and electrical energy increases the risk of a fire safety hazard.
- Equipment installed at the site meeting the requirements of a "restricted access location," per UL60950-1, is defined as follows: "Access can only be gained by service persons or by a user who has been warned about the possible burn hazard on equipment metal housing. Access to the equipment is by using a tool or lock and key, or other means of security, and is controlled by the authority responsible for the location."



**WARNING:** Burn hazard. The metal housing of the product may become extremely hot. Use caution when working around the equipment.

**Figure 18: Warning Label on Hot Modules**



warning\_hot



**WARNING:** DC input voltage must be no higher than 60 VDC. This maximum voltage includes consideration of the battery charging "float voltage" associated with the intended supply system, regardless of the marked power rating of the equipment. Failure to follow this guideline may result in electric shock.

RF energy burn hazard: disconnect power in the cabinet to prevent injury while disconnecting and connecting antennas.



**CAUTION:** All Tx and Rx RF cables outer shields must be grounded per Motorola Solutions *Standards and Guidelines for Communications Sites* manual requirements.

All Tx and Rx RF cables must be connected to a surge protection device according to the Motorola Solutions *Standards and Guidelines for Communications Sites* manual. Do not connect Tx and Rx RF cables directly to an outside antenna.



**IMPORTANT:** All equipment must be serviced by Motorola Solutions-trained personnel.

### 3.2.1

## GPW 8000 Receiver Supplemental Safety Installation Requirements

The Supplemental Safety and Installation Requirements include the following:

- The GPW 8000 Receiver must be installed in a suitable, in-building enclosure. A restricted access location is required when installing this equipment into the end system.

- The receiver contains a Class 1 built-in power supply component. This component is equipped with an appliance inlet for connecting to an AC input, and DC input terminals which meet SELV DC circuit requirements.
- When installing the equipment, all requirements of relevant standards and local electrical codes must be fulfilled.
- The maximum operating ambient temperature of this equipment is 60 °C. The maximum operating altitude is 3000 meters above sea level.
- When the GPW 8000 Receiver is used in a DC reverting system, the DC power supply must be located in the same building as the GPW 8000 Receiver, and it must meet the requirements of a SELV circuit.

### 3.2.2

## DC Mains Grounding Connections



**CAUTION:** This equipment is designed to permit the connection of the earthed conductor of the DC supply circuit to the earthing conductor at the equipment. If this connection is made, you must meet all following conditions:

- Connect this equipment directly to the DC supply system earthing electrode conductor or to a bonding jumper from an earthing terminal bar or bus in which the DC supply system earthing electrode conductor is connected.
- Locate this equipment in the same immediate area (such as adjacent cabinets) as any other equipment that has a connection between the earthed conductor of the same DC supply circuit and the earthing conductor (and also the point of earthing of the DC system). Do not earth the DC system elsewhere.
- Locate the DC supply source within the same premises as the equipment.
- Do not install switching or disconnecting devices in the earthed circuit conductor between the DC source and the point of connection of the earthing electrode conductor.

### 3.2.2.1

## Disconnect Device Permanently Connected

Incorporate a readily accessible disconnect device (circuit breaker or switch) in the building installation wiring.

### 3.2.2.2

## Multiple Power Source

This product has multiple power sources. If service requires the removal of a power source, disconnect all inputs (AC and DC powers), including the AUX PWR IN connector, to remove power completely to the equipment before servicing.

### 3.2.2.3

## Connection to Primary Power

For supply connections, use wires suitable for at least 75 °C.

### 3.2.2.4

#### Replaceable Batteries



**WARNING:** Risk of Explosion if you replace the battery with an incorrect type. Dispose of used batteries according to the instructions.

### 3.2.3

#### Maintenance Requiring Two People

Identify maintenance actions that require two people to perform the repair. Two people are required when:

- A repair has the risk of injury that would require one person to perform first aid or call for emergency support. An example is work around high-voltage sources. If an accident occurs to one person, another person may be required to remove power and call for emergency aid.
- Heavy lifting is involved. Use the National Institute of Occupational Safety and Health (NIOSH) lifting equation to determine whether one or two persons are required to lift a system component when it must be removed and replaced in its rack.

### 3.2.4

#### Equipment Racks

Lift equipment racks without the use of lifting equipment only when sufficient personnel are available to ensure that regulations covering health and safety are not breached. Use an appropriately powered mechanical lifting apparatus for moving and lifting the equipment racks. In addition, comply with any local regulations that govern the use of lifting equipment.

For installation of the cabinet version of the GPW 8000 Receiver, see [Cabinet Version of the GPW 8000 Receiver on page 80](#).



**WARNING:** Crush Hazard could result in death, personal injury, or equipment damage. Equipment racks can weigh up to 360 kg (800 lb). See the following instructions for proper lifting procedures.

### 3.3

#### General Installation Standards and Guidelines

This section provides guidelines to ensure a quality installation. Review these guidelines before unpacking and installing the system. Additionally, review the installation information in the *Standards and Guidelines for Communication Sites* manual for more details, including:

- Equipment installation
- Antenna installation

Review installation information specifically for GPW 8000 Receivers and subsystems in [GPW 8000 Receiver Hardware Installation on page 79](#)

## 3.3.1

## General Site Preparation Overview

Perform the activities listed in this table to ensure proper site preparation. The table references specific chapters in the Motorola Solutions *Standards and Guidelines for Communication Sites* manual for more information.

**Table 19: Activities for Site Preparation**

Activity	Description of Activity	Chapter Reference
Review the site plan.	<ul style="list-style-type: none"> <li>Prevents potential on-site and off-site interference by local trunked systems.</li> <li>Minimizes cable lengths.</li> <li>Determines the location of telecom equipment.</li> </ul>	<ul style="list-style-type: none"> <li>Chapter 2 "Site Design and Development"</li> </ul>
Determine site access and security.	Outlines of site access and security measures.	<ul style="list-style-type: none"> <li>Chapter 2 "Site Design and Development"</li> </ul>
Review safety considerations.	Outlines general, installation, and environmental safety guidelines and requirements and OSHA-related considerations.	<ul style="list-style-type: none"> <li>Chapter 3 "Communications Site Building Design and Installation"</li> </ul>
Schedule installation of telephone service.	Ensures options and functions of on-site, two-way communications for personnel safety and maintenance.	<ul style="list-style-type: none"> <li>Chapter 3 "Communications Site Building Design and Installation"</li> </ul>
Review grounding specifications.	Ensures that the site meets or exceeds the Quality Audit Checklist in Appendix F as well as the Power and Grounding Checklist in Appendix D.	<ul style="list-style-type: none"> <li>Appendix D. "Grounding (Earthing) Electrode System Testing/Verification"</li> <li>Appendix F. "R56 Compliance Checklist"</li> </ul>
Schedule installation of site power.	Covers grounding, power sources, and surge protection.	<ul style="list-style-type: none"> <li>Chapter 4 "External Grounding (Earthing)"</li> <li>Chapter 5 "Internal Grounding (Earthing)"</li> <li>Chapter 6 "Power Sources"</li> <li>Chapter 7 "Surge Protective Devices"</li> </ul>

## 3.3.2

## General Equipment Inspection and Inventory Recommendations

Take an inventory of all equipment with a Motorola Solutions representative to ensure that the order is complete. Carefully inspect all equipment and accessories to verify that they are in good condition. Promptly report any damaged or missing items to a Motorola Solutions representative.



**CAUTION:** Do not tamper with factory configuration settings for these devices. These settings include software configuration, firmware release, password, and physical connections. Motorola Solutions has configured and connected these devices to meet specific performance requirements. Tampering with these devices may result in unpredictable system performance or catastrophic failure.

### 3.3.3

## General Placement and Spacing Recommendations

When placing equipment at a site, perform the following:

- Place each rack on a firm, level, and stable surface, and bolt the racks together.
- Use correct mounting hardware and shims to prevent rack movement.
- Use strain relief when installing and positioning cables and cords to help ensure that no interruption of service occurs.
- Provide an appropriate amount of space around all components to allow for proper air flow, cooling, and safe access to equipment.
- Locate the site racks and other equipment with enough spacing to allow access for service.



**NOTICE:** Proper spacing of equipment is essential for ease of maintenance and safety of personnel. Spacing requirements have been established to meet the National Fire Protection Associations (NFPA) code, and the American Society of Heating, Refrigerating, and Air Conditioning Engineers (ASHRAE) standards. Adhere to any local regulations that apply to the installation.

- Locate the system in an area free of dust, smoke, and electrostatic discharge (ESD).
- See the Motorola Solutions *Standards and Guidelines for Communication Sites* manual for details on these space requirements.

### 3.3.4

## General Cabinet Bracing Recommendations

Use all supplied bracing hardware when installing a rack or cabinet, and secure all equipment within a rack or cabinet.

If additional equipment is installed, see the system design document the field engineer provided, or consult the Motorola Solutions Field Representative.

Subsystem cabinets are self-supporting structures. In areas subject to seismic activity, additional bracing of the cabinet may be required to prevent it from tipping. However, the bracing hardware must be locally procured. No specific procedures are provided within this manual for bracing cabinets in active seismic areas. See the Motorola Solutions *Standards and Guidelines for Communication Sites* manual for details on seismic conditions.

### 3.3.5

## Mounting Cabinets or Racks to a Floor

**When and where to use:** Perform the following steps to properly install a cabinet or open rack within a site building. Secure the cabinets and racks to the floor for optimum stability. This procedure is written so that the cabinet or rack is moved only once.

### Procedure:

- 1 Carefully mark the mounting holes with a pencil, as indicated on the appropriate cabinet or rack footprint.

- 2 Drill the marked mounting holes to the appropriate depth of the mounting hardware with a hammer drill and bit.
- 3 Insert an anchor into the drilled hole. If necessary, tap the anchor into place using a hammer.
- 4 Carefully move the cabinet or rack into the position indicated by the holes in the floor.

 **WARNING:** Equipment cabinets and racks are heavy and may tip. Use extreme caution when moving. Lift from top eyenuts with the appropriate apparatus, or secure the cabinet or rack from tipping if lifting from the bottom. Failure to do so could result in death or serious injury or equipment damage.

- 5 Adjust and level the cabinet or rack as necessary to position the cabinet mounting holes with the pre-drilled holes.
- 6 Secure the cabinet or rack to the site floor with the locally procured mounting hardware.

 **IMPORTANT:** If securing the cabinet or rack to a concrete floor, use 1/2-inch grade 8 bolts with anchors.

### 3.3.6

## General Bonding and Grounding Requirements

Cabinets and racks include a Rack Grounding Bar (RGB) with the capacity to terminate numerous ground wires. Attach equipment added to the cabinet or rack to the ground bar using solid or stranded 6 AWG copper wire.

The RGB uses dual-hole lugs to terminate ground wires. The minimum number of dual-hole attachments is system-dependent and specified by the customer. This bar provides electrical continuity between all bonds and ground wire with a current-carrying capacity equal to or exceeding that of a 6 AWG copper wire.

See the Motorola Solutions *Standards and Guidelines for Communication Sites* manual for more information on proper bonding and ground at a site.

### 3.3.7

## General Cabling Requirements

Diagrams for cabling are typically included in the system-specific configuration documentation Motorola Solutions provides. Also see the Motorola Solutions *Standards and Guidelines for Communication Sites* manual for cabling standards.

 **IMPORTANT:** System certification was completed using shielded cables. To prevent emission problems, use only shielded cables. Do not substitute other cable types.

- Position the equipment to avoid excessive tension on cables and connectors. Cables must be loose with absolutely no stress on the connectors. Careful cable routing and securing the cables with tie wraps (or other devices) is one way to provide this protection. Set up preventive maintenance loops .
- Dress the cables neatly using cable ties. Do not tighten the cable ties until you are sure that the required service length and bend radius requirements are met. Leave cable ties loose enough to allow adjustment.
- Verify that all cables are properly labeled to match System-specific configuration documentation Motorola Solutions provided.
- Ensure that cables do not exceed the minimum bend radius as outlined in the Motorola Solutions *Standards and Guidelines for Communication Sites* manual.



**CAUTION:** Use only Category 5 Shielded Twisted Pair (or higher) for cabling Ethernet connections. Motorola Solutions has engineered this system to meet specific performance requirements. Using other cabling and connectors may result in unpredictable system performance or catastrophic failure.



**NOTICE:** For more information on cabling guidelines, see the documentation supplied with components from each equipment manufacturer.

### 3.3.8

## General Power Guidelines and Requirements

See the Motorola Solutions *Standards and Guidelines for Communication Sites* manual for information on providing electrical service, power budgeting, selecting batteries, and other topics for supplying power at the site.

Perform electrical installation work in accordance with the current edition of the NFPA 70 and local building codes. Where required, use a qualified and licensed electrician for all electrical installations.

### 3.3.8.1

## General AC Power Guidelines and Requirements

The Motorola Solutions *Standards and Guidelines for Communication Sites* manual defines the guidelines and requirements for cabinets and racks which house equipment that requires AC power input. Some of the guidelines and requirements are as follows:

- The cabinet or rack is designed to accept 120/240 V, single-phase power with an amperage service size as required by the electronic equipment.
- Cabinets and racks powered by commercial power must be equipped with a Nationally Recognized Test Laboratory (NRTL) certified power distribution module that contains a main circuit breaker or individual circuit breakers of the correct size as required for the electronic equipment or as the customer specified.
- A decal showing an electrical schematic of the power wiring is affixed to the inside surface of the cabinet.
- All AC power equipment and electrical components must conform to National Electrical Manufacturers Association (NEMA) and National Electrical Code (NEC). The AC power equipment must also be listed by an NRTL.
- A surge arrestor, designed to protect equipment systems from a 120/240 V service and load center, is placed on the power feed ahead of all individual load center circuit breakers. This gapless arrestor must be listed by an NRTL for the purpose intended.
- Selection of a surge arrestor is based on the susceptibility of the equipment powered by the electrical service, with margin provided for locally generated disturbances. See ANSI/IEEE C62.41 (21) for more details.
- At least one 120 VAC, 15 A duplex convenience outlet equipped with Ground Fault Interrupter (GFI) protection must be provided in the electronic equipment compartment.



**CAUTION:** Do not use surge/transient suppressors without careful and expert power system analysis.



**NOTICE:** Redundant devices could be terminated on different AC main phases so that a single phase failure does not result in a power loss for both devices.

## 3.3.8.2

**General Breaker Recommendations**

Each power supply should have its own supply breaker. The breaker recommendations for AC and DC supply breakers are as follows:

- For a 120 VAC, 60 Hz application, the AC supply breaker must be rated for a continuous current of 15 A. For a 220 VAC, 50 Hz application, the AC supply breaker must be rated for a continuous current of 10 A minimum, not to exceed 20 A.
- Individual DC breakers are not used. For information involving the sizing of cables and DC power distribution, see the *Standards and Guidelines for Communication Sites* manual.
- Site installation must include a single current interrupting device on the DC input distribution (fuse or circuit breaker) rated for the application loading, not to exceed 200 A. For each standalone device, the DC supply breaker should be rated for a continuous current of 25 A.

## 3.3.8.3

**General Battery Installation Recommendations**

Position the batteries and charger as closely as possible to the rectifier system using the cables. Use a heavy gauge stranded cable to minimize voltage drop. Examples of the resistance of some heavy gauge wire are:

Table 20: Heavy Gauge Wire Resistance Examples

Gauge	Resistance
#6 gauge	0.3951 /1000 ft
#4 gauge	0.2485 /1000 ft
#2 gauge	0.1563 /1000 ft

The maximum voltage drop can be calculated by knowing the peak current the radio system draws. Use the following formula:

Total Voltage drop =  $[\Omega/1000 \text{ ft}] \times [\text{total loop length (ft)}] \times [\text{Ipeak (A)}] + [\text{connector(s) voltage drop(s)}]$

See [DC Power Connection Wire Gauge Calculations for GPW 8000 Receiver](#) on page 89 for additional guidelines on the cable sizing.

## 3.3.9

**General Electrostatic Discharge Recommendations**

Electronic components, such as circuit boards and memory modules, can be sensitive to Electrostatic Discharge (ESD). Use an antistatic wrist strap and a conductive foam pad when installing or upgrading the system.

If an ESD station is not available, wear an antistatic wrist strap. Wrap the strap around the wrist and attach the ground end (usually a piece of copper foil or an alligator clip) to an electrical ground. An electrical ground can be a piece of metal that literally runs into the ground (such as an unpainted metal pipe), or the metal part of a grounded electrical appliance. An appliance is grounded if it has a three-prong plug and is plugged into a three-prong grounded outlet.



**NOTICE:** Do not use a computer as a ground, because it is not plugged in during installation.

### 3.3.10

## GPW 8000 Receiver FCC Requirements

The GPW 8000 Receiver has been tested and found to comply with the limits in part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to radio communications when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy. If not installed properly and used in accordance with the instruction manuals, the GPW 8000 Receiver may cause harmful interference to radio communications. Operation of some compliant equipment in a residential area may cause harmful interference to radio communications, in which case the interference must be corrected.

### 3.3.11

## Networking Tools

Use the following networking tools for installing and servicing the network:

- Fluke® OneTouch Assistant LAN tester
- NiMH rechargeable battery for Fluke
- T1/E1 or E1 test set (such as the Hewlett-Packard® HP37702A)
- Serialtest® software with the ComProbe® and SerialBERT option

### 3.3.12

## General Installation/Troubleshooting Tools

If information is needed regarding where to obtain any of the equipment and tools listed, contact the Motorola Solutions Support Center (SSC). See [Motorola Solutions Support Center on page 162](#).

### 3.3.12.1

## General Tools

Use the following general tools to install, optimize, and service equipment in the system:

- 150 MHz 4 Channel Digital Storage Oscilloscope
- Transmission Test Set (TIMS Set)
- Aeroflex 3900 Series Service Monitor or equivalent
- 50 Ohm Terminated Load
- Digital Multimeter (DMM)
- Terminal Emulation Software
- DB-9 Straight through serial cable
- RS-232 Cables with Connectors
- Punch Block Impact Tool
- MODAPT – RJ-45 Breakout Box
- Remote RJ-11/ RJ-45 Cable Tester (1200 ft length maximum)
- PC Cable Tester (RG-58, 59, 62, BNC, RJ-45, RJ-11, DB-9, DB-15, DB-25, Centronics 36-pin connectors)
- ESD field service kit
- Amprobe Instruments GP-1 Earth Tester

- AEMC 3730 Clamp-on Ground Resistance Tester

### 3.3.12.2

## Rack Tools

Use the following tools to install, optimize, and service the equipment:

- Service Monitor: Aeroflex 3900 Series Service Monitor with P25 Options installed (plus Time Division Multiple Access (TDMA) options as required)
- Personal Computer meeting the following specifications:
  - Operating Systems:
    - + Windows 10 (Server 2012 R2)
- Hardware Requirements:
  - Processor:
    - + 1 GHz or higher Pentium grade
  - Processor Memory:
    - + 2 GB RAM recommended for Windows 10
  - Hard Disk Space:
    - + 300 MB minimum free space (for a Typical Installation, including Help Text and Software Download Manager) or 100 MB minimum free space (for a Compact Installation)
  - Peripherals:
    - + Microsoft Windows supported mouse or trackball
    - + Microsoft Windows supported serial port for product communication
    - + Microsoft Windows supported Ethernet port for product communication
    - + Microsoft Windows supported printer port for report printing
    - + CD-ROM for software installation
- Configuration/Service Software (CSS) DLN6455
- CSS serial programming cable
- Ethernet cable
- Antenna tester
- 50 Ohm terminated load
- Rohde & Schwarz NRT-Z14 Directional Power Sensor, 25-1000 GHz, 0.1-120 W. Recommended for all uses when a service monitor is not available.

### 3.3.13

## Technical Support for Installation

Technical support is available from the site-specific documents the Field Engineer or Motorola Solutions Field Representative provided for the system, one of the Motorola Solutions Support Centers (SSC), or qualified subcontractors.

- SSC can help technicians and engineers resolve system problems and ensure that warranty requirements are met. Check your contract for specific warranty information. See [Motorola Solutions Support Center on page 162](#).

- The Motorola Solutions System Service Subcontractor Assessment program ensures that service people contracted by Motorola Solutions meet strict minimum requirements before they can work on any system. For more information on this program, contact the Motorola Solutions representative.

#### 3.3.13.1

### Site-Specific Information

When the Motorola Solutions Center for Customer Solution Integration (CCSi) stages a system, the Field Engineer assigned to the system creates all site-specific system documentation to document how the system was staged. Site-specific information includes the following:

- Site design drawings showing the location of racks, cabinets, cable trays, and other components
- Rack drawings showing the location of the equipment in each rack
- Cable matrix in a table format that shows each cable and its connections
- Interconnect wiring diagrams to show the cable connections between devices
- Pre-programmed parameters of each site component
- Templates used to program each device
- All firmware and software revisions of each site component
- Test data from each device that requires operational verification
- Optimization requirements and settings of each electrical path
- Acceptance Test Plan for the site components



**NOTICE:** Maintain this site-specific information to reflect the current site configuration and layout for the system.

#### 3.4

### GPW 8000 Receiver Hardware Installation

The following is installation information specific to GPW 8000 Receivers.

#### 3.4.1

### Placement and Spacing

Cabinets and racks allow equipment to be added to a site. Always consider room for expansion when setting up a site. Cabinets or racks may be installed next to each other or to other equipment. However, provide all cabinets and racks with sufficient floor space to permit access for installation and service.

Clearance required for service and installation is at least 2 ft in the front and rear.

#### Front access:

- At least 2 ft floor access in front of the cabinet or rack.

#### Rear access:

- At least 2 ft floor access at the rear of the cabinet or rack



**NOTICE:** For the cabinet version, when an eyenut has to be replaced, provide at least 2 ft access to both sides of the cabinet so that both side panels can be removed.

### 3.4.2

## Cabinet Version of the GPW 8000 Receiver

The GPW 8000 Receivers are offered with factory cabinet options for mounting flexibility. Two cabinet height options are available:

- 31 in. 15 Rack Units (Option CA02446AA)
- 47 in. 24 Rack Units (Option CA02447AA)

Each cabinet is ordered with a single receiver and Radio Frequency Distribution System (RFDS) equipment pre-installed. Additional receivers and other devices are installed in the cabinet during field installation. For spacing equipment or placing peripherals between receivers, additional slides rails can be ordered.


The cabinets have knockouts on the top and bottom that provide space and separation of cable types when routing the cables. Follow the Motorola Solutions *Standards and Guidelines for Communication Sites* manual for the multiple knockouts for the different cable types as shown in [Figure 20: Cabinet Dimensions on page 82](#). The doors on both cabinets are provided with standard locks (key# 2135), which come with two keys per lock. Each door can also be detached and mounted on a reverse direction.

### 3.4.2.1

## Floor Mounting the Cabinet Version of the GPW 8000 Receiver

Securely fasten the cabinet to the floor or other rigid surface capable of supporting the load of the cabinet.

Figure 19: GPW 8000 Receiver (Cabinet Version) – Floor Mounting Detail





**IMPORTANT:** The four 5/8 in. holes in the top of the cabinet are for stacking cabinets and are not intended for strength when lifting a cabinet.

#### 3.4.2.2

### Physical Dimensions and Clearances of the Cabinet Version of the GPW 8000 Receiver

The figures show the dimensions for both the 31 in. and 47 in. cabinets. Minimum recommended clearances are 36 in. (front and rear) for installation access.

**Figure 20: Cabinet Dimensions**




## G\_Series\_Cabinet\_Dimensions

### 3.4.2.3 Cabinet Mounting Rails

The figures show the dimensions and spacings of the mounting rails inside both the 31 in. and 47 in. cabinets. The mounting rails are square hole and require cage nuts for additional equipment installation.

**Figure 21: Cabinet Mounting Rails**



3424

## Vertical Lifting of Cabinets

Motorola Solutions made no provision to enable the removal of a harness after the equipment has been lifted and placed flat onto a surface. Your organization must provide those provisions.


### 3.4.2.4.1

## Lifting Cabinets Vertically

**When and where to use:** Use this procedure to lift the cabinet with a harness and place onto a flat surface.

## Procedure:

1 Place two temporary supports onto the floor or flat surface. Position the supports to facilitate the removal of harness. See [Figure 22: Lifting a Cabinet with a Harness on page 84](#).

**Figure 22: Lifting a Cabinet with a Harness**

- 2 Using the harness, lift the cabinet onto the two supports.
- 3 Remove the harness.
- 4 Lift one side of the cabinet slightly and remove one of the supports. Carefully lower the cabinet onto the flat surface.
- 5 Lift the other side of the cabinet slightly and remove the other support. Carefully lower the cabinet onto the flat surface.

#### 3.4.2.5


### Removing/Replacing a Cabinet Door

**When and where to use:** The default orientation of the door hinge is on the right side of the cabinet. Use this procedure to change the hinge to the left side of the cabinet, or to replace a cabinet door.

#### Procedure:

- 1 Loosen the M6 fastener and detach the ground cable from the bus bar.  
If removing the front cabinet door, the ground cable is detached from the M6 nut in the cabinet body.


**Figure 23: Cabinet Door Removal**



Cabinet\_Door\_Removal

- 2 To remove the door, release the spring loaded latch.
- 3 Lift the door from the pin hinge.

**Figure 24: Cabinet Door Replacement**



Cabinet\_Door\_Replacement


- 4 Flip the door 180° and reattach it to the cabinet with the pin hinge.
- 5 Reattach the ground cable to the M6 nut in the cabinet body.

### 3.4.3

## Rack Mounting The GPW 8000 Receiver

Mount the receiver housing in a rack that has been secured to the floor. For open racks, two brackets are required to distribute the weight. Without brackets, the center of gravity of the system shifts to the back, potentially causing structural issues with the rack. The brackets come with the required number of screws.

**Figure 25: Receiver Mounted in Rack**



HPD\_SASC\_SABR\_bracket\_install



**NOTICE:** Perform this installation with two people so that one person can hold the device in place while the other person attaches the brackets to the rack.

### 3.4.3.1

## Mounting the GPW 8000 Receiver

### Procedure:

- 1 Determine where to mount the device on the rack and mark the location. The brackets are useful in making this determination, and the pin on the back of the bracket helps in finding the exact location on the rack.
- 2 Attach the brackets to the sides of the chassis:
  - a Use M6x1x13 machine screws with a captive washer (zinc plated).
  - b Screw one bracket into the clinch nuts on the side of the chassis.
  - c Screw the second bracket into the clinch nuts on the other side of the chassis.

- 3 Lift the device into place on the rack using the pins on the brackets to properly line up the device.
- 4 Attach the two brackets to the rack:
  - a For a Motorola Solutions modular rack, use M6x1x10 thread-forming screws with a black finish.
  - b For a Motorola Solutions open rack, use 1224x5/8 thread-forming screws (zinc plated).
  - c For your own rack, use hardware appropriate for the rack.
  - d Attach the brackets to both sides of the rack through the upper back openings on the brackets.
  - e Attach the brackets to the rack on both sides through the lower back openings.
- 5 In the front, attach the chassis to the brackets:
  - a Screw two M6x1x10 thread-forming screws (black finish) through the front holes on one side of the chassis and into the bracket.
  - b Screw two M6x1x10 thread-forming screws (black finish) through the front holes on the other side of the chassis and into the bracket.

#### 3.4.4

### Connecting Power


This section covers topics on connecting power cables to the receiver, calculating the length of wire for various gauges, and mounting the battery temperature sensor.

#### 3.4.4.1

### GPW 8000 Receiver Power Connections

Both AC and DC inputs are provided by your organization and are connected to the power supply through the backplane of the receiver.

The following is an example of power connections supporting trunked GPW 8000 Receivers, standalone GPB 8000 Reference Distribution Modules (RDMs), and standalone Expansion Hubs (XHubs).

**Figure 26: GPW 8000 Receiver Power Connections****Table 21: GPW 8000 Receiver and Power Supply Cabling Detail (Example)**

Device	Port	Connects to Device /Port
XCVR 2 & 1 Chassis A Pwr Sply A	AC or DC IN	AC or DC Power Source
	AUX PWR OUT	XCVR 6 & 5 Chassis C / AUX PWR IN
XCVR 4 & 3 Chassis B Pwr Sply B	AC or DC IN	AC or DC Power Source
	AUX PWR OUT	XCVR 2 & 1 Chassis A / AUX PWR IN

*Table continued...*

Device	Port	Connects to Device /Port
XCVR 6 & 5 Chassis C Pwr Sply C	AC or DC IN	AC or DC Power Source
	AUX PWR OUT	RDM 2 & 1 Chassis D / AUX PWR IN
RDM 2 & 1 Chassis D Pwr Sply D	AC or DC IN	AC or DC Power Source
	AUX PWR OUT	XCVR 4 & 3 Chassis B / AUX PWR IN



**NOTICE:** See [GPW 8000 Receiver Rear Connections on page 92](#) and [GPW 8000 Receiver Front Connections on page 94](#).

#### 3.4.4.2

### DC Power Connection Wire Gauge Calculations for GPW 8000 Receiver

Because the power supply disconnects itself from the DC input when it senses that DC voltage has dropped to 42 VDC, minimize the voltage drop in the DC power supply loop (the total length of the 48 VDC hot wire and the DC return wire) to no more than 1 V total. Minimizing the voltage drop ensures that the maximum energy is removed from the battery before disconnecting the power supply from the DC input line.

If a single pair of 2 AWG wire is used to connect the battery to the back panel, the maximum length of a single conductor would be 75 m (245 ft). Use of smaller gauge wire would reduce this length depending on the resistance of the wire.

The actual current value can be calculated from the power consumption value in the specifications tables. See [GPW 8000 Receiver General Specifications for Integrated Voice and Data on page 41](#).

To determine the maximum length of wire for wire other than 2 AWG, the following relationship can be used:

- Length (m/ft) =  $V/I/R$

where:

- $V$  = voltage drop in one leg of the loop (max = 0.5 V)
- $I$  = current the receiver draws during DC operation
- $R$  = resistance of the wire being considered (in Ohms per ft)

For common wire sizes, the maximum distances shown in [Table 22: DC Power Connection Wire Gauge Maximum Distances for an IV and D Site on page 89](#) apply.

Table 22: DC Power Connection Wire Gauge Maximum Distances for an IV and D Site

AWG	Resistance (ohm/304.8 meter/1000 ft)	Maximum Distance (for 13 A)
2	0.1563	75 m (245 ft)
3	0.1970	60 m (195 ft)
4	0.2485	47 m (155 ft)
5	0.3133	37 m (120 ft)
6	0.3951	30 m (95 ft)

## 3.4.4.3

### Battery Temperature Sensor Mounting


A 40 ft battery temperature sensor cable is shipped with your device. This three-wire cable carries a voltage signal to the power supply from a sensor element which must be mounted close to the storage battery. Voltage is proportional to the battery temperature and the diagnostic circuitry in the power supply module. The 40 ft cable can be extended to a total length of 190 ft using 50 ft extensions (Motorola Solutions part number 3084827Y04. See [Motorola Solutions Support Center on page 162](#).

Mount the sensing element of the temperature sensor so that it detects the actual battery temperature (or the ambient temperature as close as possible to the batteries being charged). The two examples of mounting are as follows:

#### Example 1

Use cable ties to attach the sensing cable to the positive (or negative) power cable. A minimum of two cable ties should be used (spaced 6 inches apart), with one of the cable ties not more than 2 inches from the sensing element. Mount the sensing element not more than 2 inches from the battery post where the power cable connects. See [Figure 27: Battery Temperature Sensor Example 1 on page 90](#).

**Figure 27: Battery Temperature Sensor Example 1**




GTR8000\_Battery\_Temperature\_Sensor\_1

#### Example 2

Attach the sensing cable to an existing battery tray support bracket using cable ties or nylon loop straps of the proper size. Mount the sensing element not more than 2 inches from the surface of the batteries being monitored. Use a minimum of two cable ties and/or loop straps to secure the sensing cable to the bracket. Place the cable ties/ loop straps no more than 6 inches apart with one placed no more than 2 inches from the sensing element. See [Figure 28: Battery Temperature Sensor Example 2 on page 91](#).

Figure 28: Battery Temperature Sensor Example 2



GTR8000\_Battery\_Temperature\_Sensor\_2

### 3.4.5

## GPW 8000 Receiver Grounding

Detailed grounding information is beyond the scope of this manual. See the *Standards and Guidelines for Communication Sites* manual for detailed information about grounding and lightning protection.



**IMPORTANT:** Ground the battery system, either positive or negative, at the battery. The DC input (battery charger output) of the power supply floats with respect to earth ground. The power supply can therefore be used in either positive ground or negative ground DC systems. Connect the appropriate terminal (+ or -) of the DC system to protective earth at the battery. These instructions assume that all telephone lines, antenna cables, and AC or DC power cables have been properly grounded and lightning-protected.


When rack installations have a primary rack and one or more expansion racks, all these racks must be connected to the same Sub System Ground Bus Bar (SSGB) (with no other rack connected to the SSGB). Grounding ensures that surge events do not produce ground potential differences that affect signals between the racks.

The backplane has a double lug with two lock nuts on the rear panel where the ground wire connects to the backplane on one end, and to the rack grounding bar on the other. The rack grounding bar is connected to the master ground bus bar.

To use the grounding lugs, a length of #6 AWG wire with UL-listed ring lugs is required on both ends. This wire is shipped with the device.

For the cabinet version of the receiver, the rack grounding bar is connected to the SSGB with a provided AWG2 dual hole lug.

**Figure 29: Rack Grounding**



GTR8000\_rack\_grounding

#### 3.4.5.1

### Grounding the GPW 8000 Receiver

#### Procedure:


- 1 Connect the ground wire attached to the two grounding lugs at the rear of the receiver to the rack grounding bar.
- 2 Tighten the ground lock nut to 60 in-lb (6.94 N.m).
- 3 Connect all other equipment and peripherals to the rack grounding bar.

#### 3.4.6

### GPW 8000 Receiver Rear Connections

The GPW 8000 Receiver connects to a site LAN switch port for this channel and to the receive path.

Figure 30: GPW 8000 Receiver Backplane



GPW\_8000\_receiver\_backplane\_w\_callouts\_C

Table 23: GPW 8000 Receiver Backplane Connections

Port / Type	Device it connects to:	Port / Type	Description
LAN A	LAN Site Switch, external switch, GPB 8000 Reference Distribution Module (RDM) or Expansion Hub (XHub)	LAN	LAN connection to LAN A. (One for each transceiver module.) An SDM3000 RTU device connects to the site LAN switch that is connected to this port.
LAN B	LAN Site Switch, external switch, GPB 8000 RDM or XHub	LAN	LAN connection to LAN B. (One for each transceiver module.)
RX-A	Receive line A	BNC	Receiver branch A RF input port. (One for each transceiver module.)
RX-B	Receive line B	BNC	Receiver branch B RF input port. (One for each transceiver module.) (For Time Division Multiple Access (TDMA) only.)
AUX PWR IN	GPW 8000 Receiver		Auxiliary power input from another GPW 8000 Receiver, a standalone GPB 8000 RDM, or GCM 8000 Comparator. Used as an alternative power source if the power supply module fails.
AUX PWR OUT	Various		Auxiliary power output from the power supply. Reserved for connection to other system components that require a redundant AUX PWR input, such as another GPW 8000 Receiver chassis or XHub chassis.

Table continued...

Port / Type	Device it connects to:	Port / Type	Description
BAT TEMP	Battery temperature sensor	6-pin	For battery temperature sensor cable and probe (included with DC cable option CA01400AA). Used for temperature compensated battery charging.
GND	Ground		Two studs for a two-hole ground lug.
+BATT/D C	DC power supply or battery		Input from a +/- 48 VDC nominal power supply or backup battery. From this port, the DC power feeds through the backplane to the DC connector on the power supply. Neither connection on this port is internally grounded.
AC IN	120/240 VAC power source.		Input from 90/264 VAC nominal power source. From this port, AC power feeds through the backplane to the AC input connector on the power supply.
EXT FREQ REF	TRAK (Simulcast Site Reference)	BNC	5 MHz/1pps composite, 5 MHz, or 10 MHz input. Used in a conventional receiver when the option card frequency reference is not used. (Feeds both transceiver modules.)
1PPS			Not in use




**NOTICE:** The EXT FREQ REF input on the rear of the device is high impedance. Use an external termination to properly terminate the cable connected to the input. It is recommended that a BNC "T" and a 50 Ohm BNC termination is connected to the input to terminate the cable. If the cable is daisy chained (multiple receivers connected together and driven by one TRAK/PSC output), only the last receiver in the chain has the termination.

### 3.4.7

## GPW 8000 Receiver Front Connections

Two service ports are accessible through a drop-down door to the left of the fans. The remaining ports are behind the fan module.

Figure 31: GPW 8000 Receiver Front



GPW\_8000\_receiver\_front\_no\_fan\_w\_callouts\_A

 **NOTICE:** The optional Transceiver Option Card attaches to the control board. For conventional operation, the board provides an internal 10 MHz frequency reference, the analog interfaces, and WildCard I/Os.

Table 24: Transceiver Connections - Front

XCVR Port / Type	Connects to This Device/Port	Description
Ethernet service port, RJ-45	Service PC, LAN port	Ethernet service port for local access using Configuration/Service Software (CSS). Also may be used for localized software downloads.   <b>NOTICE:</b> Supports only 10 Mb half duplex operation.
Serial service port, DB-9	Service PC, RS-232 port	Serial service port for initial configuration of the IP address.
Microphone port, RJ-45		Not in use
Speaker port, RJ-9	External Speaker, RJ-9 port	Used to connect to an amplified (DC powered) external speaker. Audio volume level is set from the CSS.   <b>CAUTION:</b> To prevent damage to the receiver, use speaker kits HSN1006A and cable part no. 0185180U01.
Wireline port, RJ-45	Landline equipment, RJ-45	Connection between telephone lines or analog site equipment

Table continued...

XCVR Port / Type	Connects to This Device/ Port	Description
		and the analog receiver. The wireline processes and routes all wireline audio signals between the receiver and landline equipment (such as consoles or modems).
System Connector, mini SCSI	50-pin Telco Connector or Punchblock	Provides the WildCard I/Os and supplementary Analog I/Os for analog simulcast and special applications. Editing of Wildcard configurations is permitted only through CSS.
Asynchronous port, RS232, RJ-45		Not in Use
V.24 port	Digital Circuit, RJ-45	Connection port when the receiver is part of a conventional or trunked circuit-based site, mixed mode, or digital only.
Reference frequency input, BNC*	Service monitor	Connection port to service monitor for frequency calibration.

\* See [GPW 8000 Receiver Time and Frequency Inputs on page 138](#).



**NOTICE:** For information about conventional functions and topologies the receiver supports, see the *Conventional Operations* manual. The receiver can be IP managed while using the 2- or 4-wire/V.24 interface for channel traffic.

#### 3.4.7.1

### System Connector Ports (Conventional)

The system connector, a 50-pin Mini SCSI connector, is used for the WildCard inputs, outputs, and the analog audio paths not routed to their own connector.

Table 25: 50-Pin System Connector Pin-Outs (Conventional)

Pin No.	Signal	Type	Function	Note
1	Aux In 2	Input	Main Standby - External handshaking	Pull To Ground To Activate
2	Aux In 4	Input	Main Standby- Status of other side	Pull To Ground To Activate
3	Aux In 6	Input		Pull To Ground To Activate
4	Aux In 8	Input	Main Standby - Connectivity other Station	Pull To Ground To Activate
5	Aux In 9 –	Input	Opto-Isolated In - Current flow to Activate	
6	Aux In 10 –	Input	Opto-Isolated In - Current flow to Activate	


Table continued...

Pin No.	Signal	Type	Function	Note
7	Aux In 11 –	Input		Opto-Isolated In - Current flow to Activate
8	Aux In 12 –	Input		Opto-Isolated In - Current flow to Activate
9	Aux In 13	Input	For future use	Pull To Ground To Activate
10	Aux Out 12	Output		Low Impedance to Ground When Active
11	Aux Out 2	Output		Low Impedance to Ground When Active
12	Aux Out 4	Output	Main Standby - Station Status	Low Impedance to Ground When Active
13	Aux Out 6	Output		Low Impedance to Ground When Active
14	Aux Out Relay 7 Com	Output	RD STAT - Receiver Active	Form Relay A Closed When Active
15	Aux Out Relay 8 Com	Output	Main Standby - Antenna Relay	Form Relay A Closed When Active
16	Aux Out Relay 9 Com	Output		Form Relay A Closed When Active
17	Aux Out Relay 10 Com	Output		Form Relay A Closed When Active
18	Aux Out 11	Output		Low Impedance to Ground When Active
19	External_Reset	Input	Reset	Buffered Input Pull To Ground To Activate
20	TSTAT	Output	For future use	0 Volts When Inactive / +5 Volts when Active
21	AUX RX	Output	Aux Rx	Analog Signal – Unbalanced
22	GND		GND	
23	AUX TX	Input/Output		Not functional
24	PL -	Input		Not functional
25	Gen TX –	Input		Not functional
26	Aux In 1	Input		
27	Aux In 3	Input		Pull To Ground To Activate
28	Aux In 5	Input		Pull To Ground To Activate
29	Aux In 7	Input	Rx Inhibit	Pull To Ground To Activate
30	Aux In 9 +	Input		Opto-Isolated In - Current flow to Activate
31	Aux In 10 +	Input		Opto-Isolated In - Current flow to Activate

Table continued...

Pin No.	Signal	Type	Function	Note
32	Aux In 11 +	Input		Opto-Isolated In - Current flow to Activate
33	Aux In 12 +	Input		Opto-Isolated In - Current flow to Activate
34	GND		GND	
35	Aux In 14	Input	For future use	Pull To Ground To Activate
36	Aux Out 1	Output		Low Impedance to Ground When Active
37	Aux Out 3	Output		Low Impedance to Ground When Active
38	Aux Out 5	Output		Low Impedance to Ground When Active
39	Aux Out Relay 7 N.O.	Output	RD STAT - Receiver Active	Form Relay A Closed When Active
40	Aux Out Relay 8 N.O.	Output	Main Standby - Antenna Relay	Form Relay A Closed When Active
41	Aux Out Relay 9 N.O.	Output		Form Relay A Closed When Active
42	Aux Out Relay 10 N.O.	Output		Form Relay A Closed When Active
43	GND		GND	
44	GND		GND	
45	RSTAT	Output	For future use	0 Volts When Inactive / +5 Volts when Active
46	GND		GND	
47	TX DATA +			Not functional
48	GND		GND	
49	PL +	Input		Not functional
50	Gen TX +	Input		Not functional

Figure 32: 50-Pin System Connector Pin-Outs (Conventional)



System\_connector\_pinouts\_A

## 3.4.7.2


**Wireline Port Pin-Outs**

The Wireline port, an RJ-45 connector, can accommodate up to eight pins.

Table 26: Wireline Port Pin-Outs

Signal Name	Pin No.	2-Wire Connection	4-Wire Connection	Auxiliary 4-Wire Connection
Line2_+	1	Input/Output	Output	
Line2_-	2	Input/Output	Output	
Line3_+	3			Input
Line1_-	4			Input
Line1_+	5			Input
Line3_-	6			Input
Line4_+	7			Output
Line4_-	8			Output

Figure 33: Wireline Port Pin-Outs



Wireline\_pinouts\_A

## 3.4.7.3

**Speaker Port Pin-Outs**


The Speaker port is an RJ-9 connector that provides the interface to an external speaker.



**CAUTION:** To prevent damage to the receiver, use the HSN1006A speaker with the 0185180U01 cable.

Table 27: Speaker Port Pin-Outs

Signal Name	Pin No.
GND	1
+12 V	2
GND	3
Speaker Out	4

**Figure 34: Speaker Port Pin-Outs****3.4.7.4****V.24 Port Pin-Outs**

The V.24 port is an RJ-45 connector that provides the interface to a Digital Interface Unit, Conventional Channel Interface, Conventional Channel Gateway (CCGW), ASTRO-TAC® 3000 Comparator, Link Converter, or Channel Bank.

**Table 28: V.24 Port Pin-Outs**

Signal Name	Pin No.	Type
RCLK	1	Input
Rx Line Det	2	Input
TCLK	3	Input/Output
GND	4	GND
Data Rx	5	Input
Data Tx	6	Output
CTS	7	Input
RTS	8	Output

**3.4.7.5****GPW 8000 Receiver Part 68 Information**

This section applies when the receiver is equipped with the optional wireline interface circuitry contained on the Oven Controlled Crystal Oscillator (OCXO) Transceiver Option Card (Option CA01506AA) or Temperature Compensated Crystal Oscillator (TCXO) Transceiver Option Card (Option CA01953).



**NOTICE:** The TCXO Transceiver Option Card is used for the Power Efficiency Package option.

This equipment complies with Part 68 of the FCC rules and the requirements of the Administrative Counsel for Terminal Attachments (ACTA). On the rear of this equipment is a label that contains, among other information, the registration number:

- US: ABZNINANT7039

If requested, this number must be provided to the telephone company.

The connector used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements of the ACTA. A compliant connector is provided with this product. See installation instructions for details.

REN: N/A

Connector: RJ-48

Authorized Network Port: 04NO2

Service Order Code: 7.0Y

If the equipment causes harm to the telephone network, the telephone company notifies your organization in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company notifies your organization as soon as possible. Also, your organization is advised of the right to file a complaint with the FCC if it is necessary.

The telephone company may change its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If changes happen, the telephone company provides advance notice so your organization can make necessary modifications to maintain uninterrupted service.

If your organization experiences trouble with this equipment, see [Motorola Solutions Support Center on page 162](#) for repair and warranty information. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

None of the circuit boards in this equipment are field repairable. For assistance in sending the boards back for repair, see [Motorola Solutions Support Center on page 162](#).

This equipment cannot be used on telephone company public coin phone service. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission, or corporation commission for information.

### 3.5

## Installation/Troubleshooting Tools

In addition to the general tools needed for site installation activities, a service monitor is used specifically for testing the equipment.

To place an order, contact Motorola Solutions at:

Phone: 1-800-422-4210 ext. 6883

TTY Phone: 1-866-522-5210

Motorola Online users: Web: <https://businessonline.motorolasolutions.com>

Fax: 1-800-622-6210

### 3.6

## Installing Device Software Prerequisites

**When and where to use:** The following tasks are required before you can complete the device software installation and begin the configuration procedures in the “Configuration” chapter.

### Process:

- 1 Transfer and install new software to a device using the Software Download Manager. See [Software Download Manager on page 103](#).



**NOTICE:** This step is not applicable for Trunked GPW 8000 Receivers in Circuit Simulcast Configuration. GPW 8000 Receivers in Circuit Simulcast Configuration support only single device software download through the Software Download Manager (SWDL), and do not support site software download through the SWDL.

- 2 Obtain the ASTRO® 25 media. Specifically, you need the Motorola Solutions Device OS Image media. See [Loading Device OS Images to the UNC on page 106](#).
- 3 Obtain user names, passwords, and procedures required to access the devices on the network. For specific user names and passwords to access devices on the network, contact your system administrator.
- 4 Set up the users in the IT Admin group in Active Directory Users and Computers. See the *Authentication Services* manual.
- 5 Obtain the following values from the system administrator:
  - Line interface number
  - Zone Controller (ZC) site link path 1 IP address
  - ZC site link path 2 IP address
  - Host name to access the Unified Network Configurator (UNC) server application using Secure SHell (SSH) (<username> @IP address format)
  - Site ID number
  - IP address 1 and 2
  - Primary and secondary NTP IP addresses



**NOTICE:** The following are applicable to systems with Authentication, Authorization, and Accounting (AAA) Servers, Domain Controllers, or Syslog Servers.

- Primary, secondary, and tertiary Domain Name Services (DNS) IP addresses
- Requested DNS Domain Name
- Requested DNS Host Name
- System Name
- Primary SYSLOG Service Name Fully Qualified Domain Name (FQDN)
- Backup SYSLOG Service Name Fully Qualified Domain Name (FQDN)
- Remote Authentication Dial-In User Service (RADIUS) FQDN parameter value
- RADIUS Row Status parameter value
- RADIUS Service Time Out (seconds) parameter value
- RADIUS Service Retransmits Attempts parameter value
- RADIUS Service Dead Timer (min) parameter value
- RADIUS Specific Key parameter value
- RADIUS Service Global Key parameter value

- 6 Obtain the default credentials (local accounts, central authentication, and SNMPv3) for the device being installed, as well as the updated passwords for those types of accounts (so that you can change the password after you install the device). Contact your system administrator, if you do not have this information. See the [SNMPv3 manual](#) or see [Local Password and SNMPv3 Passphrase Troubleshooting on page 161](#) for more information.
- 7 Configure the device as a RADIUS client on the RADIUS server. When these devices are configured with a RADIUS key that matches a shared secret for that device in Microsoft Windows Internet Authentication Service (IAS), they become RADIUS clients. They do not join the Active Directory domain. See the *Authentication Services* manual for more information.



**NOTICE:** This step is not applicable for Trunked GPW 8000 Receivers in Circuit Simulcast Configuration. GPW 8000 Receivers in Circuit Simulcast Configuration support only single device software download through the Software Download Manager (SWDL), and do not support site software download through the SWDL.

8



**NOTICE:** This step is applicable to systems with AAA Servers, Domain Controllers, or Syslog Servers.

To use the VoyenceControl component of the Motorola Solutions centralized configuration application for any of the site device procedures, set up the UNC. Depending on your organizational policies, you may also need to implement a secure protocol between the UNC and the site device. Before performing any procedures using VoyenceControl, the device must be discovered in VoyenceControl, and the device configurations must be recently pulled to the UNC database. See the following ASTRO® 25 system documentation: *Unified Network Configurator* manual and *Securing Protocols with SSH* manual.



**NOTICE:** This step is not applicable for Trunked GPW 8000 Receivers in Circuit Simulcast Configuration. GPW 8000 Receivers in Circuit Simulcast Configuration support only single device software download through the Software Download Manager (SWDL), and do not support site software download through the SWDL.

3.7

## Software Download Manager

The Software Download Manager (SWDL) is an application that can transfer only, install only, or transfer and install new software to devices. The new software can be installed either locally at a site or on the Network Management subsystem. Individual devices not connected to the system can be downloaded using single device mode.



**NOTICE:** Throughout this manual, the name SWDL is used to refer to the Software Download Manager application.

### Software Download Security Transfer Modes

A software download can be performed using the following security transfer modes:

#### Clear SWDL

Transfers the software without security, based on the File-Transfer Protocol (FTP)

#### Secure SWDL

Transfers the software as encrypted, based on the Secure File-Transfer Protocol (SFTP)



**NOTICE:** All secure sequential and simultaneous transfers use the Diffie-Hellman group exchange. The Diffie-Hellman group exchange is used for devices supporting Diffie-Hellman group exchange. The Diffie-Hellman group exchange enhances the security of Secure Shell (SSH) protocol initial key exchange. See the *Software Download Manager* manual for details.

Before initiating transfer, SWDL connects to the site in the zone to discover all devices. The transfer mode of all devices is displayed in the SWDL window. It is important that all devices have the same SWDL transfer mode. Otherwise, SWDL flags a mismatch of the SWDL transfer modes across site devices.

SWDL provisions the credentials for Secure SWDL as part of initiating the SWDL operation. No user intervention is required. For a single device, Secure or Clear SWDL is configured based on the SWDL Transfer Mode configuration within the Configuration/Service Software (CSS). The Unified Network Configurator (UNC) can be used to schedule and configure all devices in the system at once.

For information on how to configure the secure or clear SWDL transfer mode, see the *Unified Network Configurator* manual and “Configuring Devices for Security” in the *CSS Online Help*.

## Software Download Transfer Methods

A software download can be accomplished in two ways:

### Site Software Download

Allows you to transfer and install application software from any location within a network. The Software Download Manager resides on the Network Management Client computer and a service computer/laptop loaded with the CSS application. From either of the computers, you can select device types to download software. Site Software Download allows you to select the zone, site, device types, and software download operation to perform. When performing a site software download, the site controller coordinates the software transfer for all trunked base radios, receivers, comparators, and reference distribution modules installed at the site. A site software download can only be performed on a trunked ASTRO® 25 system.



**NOTICE:** Trunked GPW 8000 Receivers in a circuit simulcast configuration are not supported using a site software download.

### Single Device Software Download

Allows you to transfer and install software to a single instance of a device (such as one base radio). This feature gives the technician the ability to install different versions of software. Single device software download is done from a service computer/laptop loaded with the CSS application either connected directly to the device or connected to the network.



**NOTICE:** Conventional devices and 3600 base radios are supported only in single device software download.

## Site Software Download Functionality

When SWDL is connected from a central remote location, SWDL performs a site software download to the site controllers, then to the comparators and base radios or receivers installed at the site. Both active and standby site controller modules have two flash memory banks for storing software. The device application is run from RAM, and is loaded from the active flash memory bank after a reset. One bank is active while the other bank is inactive. The transfer of the software using SWDL is a background process, without interruption of services at the site, that loads the software into the inactive bank. The site controller executes the software from one bank, while software is simultaneously downloaded to the inactive bank. The transfer and install are done in the background. An install causes the site controller to reset and load the RAM from the bank that was installed with the new software.



**NOTICE:** For geographically redundant prime sites, a site software download should not be attempted while the third Site Controller (SC3) is in the active state.

SWDL communicates with the site controllers to determine the number of existing remote sites and the number of channels. SWDL considers a channel or remote site to be accessible if its status is "Not Unconfigured." This term means that the site must be set up with a service computer/laptop with CSS or a network management client before software download is performed on the site.

The system downloads software to the site controllers, comparators, base radios, or receivers as a unit. Use SWDL to transfer software to each device type, then perform an install operation. During the transfer, the operation designates a proxy for each device type at each LAN. Site controllers proxy for comparators, and base radios or receivers proxy for each other. The proxy cross-transfers the software to other devices on the LAN. Using proxies minimizes system downtime. Transfers to the LAN are done simultaneously except for the site controller and comparators.

Software installation is done on a channel-by-channel basis, starting with the highest number channel. When a channel software download occurs, the base radio or receiver which incorporates that channel is processed along with the comparator for that channel. For example, if channel 3 was being downloaded, comparator 3 and the base radios or receivers for channel 3 at each of the remote sites would be installed simultaneously.

SWDL operation can be fault managed through Unified Event Manager (UEM), syslog, local SWDL log files, user messages, and device reports.

For further information on SWDL, see the *Software Download Manager* manual.

The operating software can also be loaded using the UNC. See the *Unified Network Configurator* manual to perform single device software downloads (ruthless download) to the devices.

See the *G-Series Equipment System Release User Guide* for SWDL instructions specific to the operating characteristics of your existing system release.

### 3.8

## Installing Devices in the UNC

**When and where to use:** The Unified Network Configurator (UNC) is the Network Manager used to discover a device and load Operating System images. This process lists the basic steps involved using the UNC on a device.



**NOTICE:** The UNC is not applicable for K core or non-networked sites.



**NOTICE:** The UNC is not applicable for GPW 8000 Receivers in Circuit Simulcast Configuration.

### Process:

- 1 Discover the device in the UNC. See [Discovering a Device in the UNC on page 105](#).
- 2 Log in to the UNC server application using PuTTY. See the *Securing Protocols with SSH* manual.
- 3 Load the operating system images to the UNC. See [Loading Device OS Images to the UNC on page 106](#).
- 4 Enable FTP services on the UNC. See [Enabling FTP Service on page 108](#).
- 5 Transfer and install the OS image to the device. See [Transferring and Installing the OS Image on page 108](#).
- 6 Inspect the device properties for the transferred and installed software. See [Inspecting Device Properties for Transferred and Installed Software on page 111](#).
- 7 Disable FTP services for the UNC. See [Disabling FTP Service on page 111](#).

### 3.8.1

## Discovering a Device in the UNC

**When and where to use:**

The discovery process allows the Unified Network Configurator (UNC) to manage the site devices. Once the device is installed, configured through the Configuration/Service Software (CSS), and security parameters are enabled, follow this procedure to discover the device. The configuration information can then be updated using this configuration management application.

The UNC network management solution consists of two applications. Both the UNC Wizard and the VoyenceControl applications are used in this procedure.



**NOTICE:** The names EMC Smarts™ Network Configuration Manager and VoyenceControl are used interchangeably for this product.

Once the device is discovered in the UNC, the OS images and CSS configuration files can be loaded to add a device to a site, which then connects the site to the current ASTRO® 25 zone core.

### Procedure:

- 1 Ensure that Domain Name Services (DNS) is functional on your system. DNS is supplied by a specific server application, which must be operational before you can discover the device.

- 2 Log on to the UNC Wizard from the Network Management (NM) client, by double-clicking the **Internet Explorer** icon on the desktop.

The Internet Explorer browser opens.
- 3 In the **Address** field, enter: `http://ucs-unc0<Y>.ucs:9443/UNCW`  
where <Y> is the number of the UNC server (01 for primary core UNC server, and 02 for backup core UNC server).

The UNC Wizard launches and a login dialog box appears.
- 4 Type the administrative user name and password. Click **OK**.

The UNC Wizard appears.
- 5 From the list of available wizards on the left side, select **Subnet Discovery**.

The right side of the window is updated with the **Subnet Discovery** form.
- 6 Select **RF Site** by clicking the **Discovery Type** drop-down list.
- 7 Enter the **Zone ID** and the **Site ID**. Click **Submit**.

An auto-discovery job is created in the UNC Schedule Manager.
- 8 Log on to the UNC from the NM client by entering:  
`http://ucs-unc0<Y>.ucs`  
where <Y> is the number of the UNC server (01 for primary core UNC server, and 02 for backup core UNC server).

The UNC client launches and a login dialog box appears.
- 9 Type the administrative user name and password. Click **OK**.

VoyenceControl launches.

 **NOTICE:** The names EMC Smarts™ Network Configuration Manager and VoyenceControl are used interchangeably for this product.
- 10 Press F7 (Schedule Manager).

The **Schedule Manager** window appears in the UNC with the discovery jobs.
- 11 Verify that the **Zone** and **Site** containers include any devices discovered.

 **IMPORTANT:** No site devices should be in the **Lost and Found** folder. If any devices are in the folder, see the *Unified Network Configurator* manual for troubleshooting guidance.
- 12 In the UNC Wizard, verify the devices by selecting **Channel** under **RF Site Level Configuration**. If multiple zones exist, choose **Zone**.

The device sites are listed, which means they are available for channel configuration.

### 3.8.2

## Loading Device OS Images to the UNC

**Prerequisites:** This procedure requires the Motorola Solutions device Operating System (OS) Image media. Locate the Transport OS Image media packaged with the Network Management media.

**When and where to use:** This procedure loads the OS images for the devices for distribution through the Unified Network Configurator (UNC). Once OS images are distributed to the UNC, you can update the device Configuration/Service Software (CSS) configuration files to the UNC.

**Procedure:**

- 1 Launch a Secure SHell (SSH) terminal server session in PuTTY to access the UNC **Server Administration** menu. See the *Securing Protocols with SSH* manual.
- 2 From the UNC **Server Administration** menu, select **OS Images Administration**. Press **ENTER**.
- 3 From the **OS Images Administration** menu, select **Load new OS images**. Press **ENTER**.  
A message appears indicating there are two methods for loading OS Images.
- 4 Insert the **Motorola Solutions Device OS Images** media into the CD/DVD-ROM drive of the server.  
The drive light starts blinking on the server.
- 5 When the drive light stops blinking, press **ENTER**.  
The OS images load on the UNC.
- 6 From the menu, select **View OS Images**. Press **ENTER**.  
The device software image appears.
- 7 From the menu, select **Eject CD**. Press **ENTER**.  
The media ejects from the drive on the server.
- 8 Remove the **Motorola Solutions Device OS Images** media from the CD/DVD-ROM drive of the server.
- 9 To log out of the server, press **ENTER**.  
The **User Configuration Server Administration** menu appears.
- 10 Press **ENTER** again.  
The prompt appears.

### 3.8.3

## Loading Software to a Device



**NOTICE:** These procedures are for a single device download. For a site download, see [Software Download Manager on page 103](#).

The following procedures describe how to load software images onto Unified Network Configurator (UNC) and download and install this software to the device. Secure protocols for software download is the preferred approach to transfer operations. However, as a backup option, FTP service can be enabled before installing the software.

## 3.8.3.1

### Enabling FTP Service

**When and where to use:** Follow this procedure to enable FTP service before installing the OS software.

**Procedure:**

- 1 Launch a Secure SHell (SSH) terminal server session in PuTTY to access the Unified Network Configurator (UNC) **Server Administration** menu. See the *Securing Protocols with SSH* manual.
- 2 From the Server Administration menu, select **Unix Administration**. Press **ENTER**.
- 3 From the Unix Administration menu, select **FTP Services**. Press **ENTER**.
- 4 From the FTP Services menu, select **Enable FTP service**. Press **ENTER**.

The FTP Services are enabled and available for software transfer and install operations.

## 3.8.3.2

### Transferring and Installing the OS Image

**When and where to use:** Use this procedure to download the OS from the Unified Network Configurator (UNC) to the device.

**Procedure:**

- 1 On the Private Network Management (PNM) client where you set up VoyenceControl, double-click the UNC shortcut on the desktop.

You can also paste the following address into an IE web browser: `http://ucs-unc0<Y>.ucs`, where <Y> is the number of the UNC server (01 for primary core UNC server, and 02 for backup core UNC server).

Internet Explorer opens to the URL of the application server, and a VoyenceControl client session launches with the welcome page.

**Figure 35: VoyenceControl Welcome Page**





**NOTICE:** The names EMC Smarts™ Network Configuration Manager and VoyenceControl are used interchangeably for this product.

2 Click the **launch VoyenceControl™** link.

A VoyenceControl client session launches with the login window.


**Figure 36: VoyenceControl Login Window**



3 Enter the User ID and Password. Click **OK**.

The **VoyenceControl Dashboard** appears.

**Figure 37: VoyenceControl Dashboard**



4 In the left navigation pane, expand **Networks**, then select **ASTRO 25 Radio Network**, then **Views**.

The list of options expands.

5 From the navigation pane, double-click **Motorola <device>**.

The view opens and all currently discovered devices appear.

6 From the menu, select **Tools** → **OS Inventory**.

A list of the OS images appears.

7 Verify OS images loaded on the UNC server appear in the OS inventory.

 **NOTICE:** These images were automatically created during the [Loading Device OS Images to the UNC on page 106](#) procedure.

8 Under **Networks** in the navigation pane, select one or more devices from the same device class by right-clicking the selections.

9 From the menu, select **Update OS Image**.

10 From the **Select OS Image** window, select **Software Image**. Click **Next**.

11 From the **Update OS Image** window, select each device that appears in the **Selected Devices** section.

This action associates a version to a device instance.

 **NOTICE:** In most cases, the “summary of device partitions” are already set up and the values in step 11 through step 14 must be verified.

12 Select **nvm partition** from the **Manage Partition for Device** section.

 **NOTICE:** Selecting **nvm partition** defines where the OS image is transferred and is the only choice for the device.

13 From the **Selected Image** section, select the image for this device.

 **NOTICE:** Ignore the **Install** and **Copy** check boxes.

The **Image Info** tab is populated and informs the application which image to use.

14 Click **Add**.

The **Summary of Device Partitions for Device** populates and confirms the proper setup.

15 Select the **Device Options** section, **Software Operations**, then choose **transfer**, **install**, or **both**.

These selections indicate which operations occur when the job is executed.

 **NOTICE:** If **transfer** is chosen, select the install option later to complete the installation. If **both** is chosen, the software is transferred and installed. There are up to two resets of the device during installation.

16 Click **Schedule**.

17 From the **Schedule Push Job** window, configure the schedule information. Click **Approve and Submit**.

The job is approved and can be viewed in the **Schedule Manager** window.

 **NOTICE:** If only **Submit** is chosen, the job must be approved later.

18 Verify the job status by pressing F7 (Schedule Manager).

The **Schedule Manager** window appears in the UNC with the discovery jobs.

### 3.8.3.3

## Inspecting Device Properties for Transferred and Installed Software

**When and where to use:** When the software has been transferred and installed, follow this procedure to inspect the device properties before assuming the installation was a success and disabling FTP service

### Procedure:

- 1 From the **Device** view, right-click the device, select **Pull**, and then **Pull Hardware Spec**.

The current software version information is updated in the Unified Network Configurator (UNC).



**NOTICE:** Skip this step if a Pull All or Pull Hardware Spec has already occurred.

- 2 From the **Device** view, right-click on the device, and then choose **Properties**.

The **Device Properties** window appears.



**NOTICE:** Select the **Properties** icon to view the device properties appear directly within the **Device** view.

- 3 Choose the **Configuration** tab, and then the **Hardware** tab.

- 4 Double-click the **Chassis** object from the **Physical Hardware** properties.

- 5 From the **Chassis** property tree, view the following properties and their values:

- **Bnk1:<device>**: Transferred software in bank 1.
- **Bnk2:<device>**: Transferred software in bank 2.
- **<device>**: Installed and Running Software.



**NOTICE:** The Table format can be used (instead of the Diagram format) to view the Installed and Running Software in the **Device** view.

### 3.8.3.4

## Disabling FTP Service

**When and where to use:** Follow this procedure to disable the FTP service after the transfer and installation of the software is completed.

### Procedure:

- 1 Launch a Secure SHell (SSH) terminal server session in PuTTY to access the Unified Network Configurator (UNC) **UNC Server Administration** menu. See the *Securing Protocols with SSH* manual.

- 2 From the **UNC Server Administration** menu, select **Unix Administration**. Press **ENTER**.

- 3 From the Unix Administration menu, select **FTP Services**. Press **ENTER**.

- 4 From the **FTP Services** menu, select **Disable FTP service**. Press **ENTER**.

The FTP services are disabled and unavailable for software transfer and install operations.

- 5 To back out of the menus, press **q** three times.

- 6 At the prompt, enter: **exit** to return to the previous menu.

- 7 To log out of the application, enter: **exit**.

- 8 Close the PuTTY connection.

This page intentionally left blank.

## Chapter 4

# GPW 8000 Receiver Configuration

Proper software/hardware configuration for the GPW 8000 Receivers and subsystems require the following activities:

- Updating factory installed receiver application software
- Setting parameters in a configuration file stored on the GPW 8000 Receiver that affects both the receiver and the RF Distribution System (RFDS) functionality.

This chapter details configuration procedures relating to the receiver.

### 4.1

## Configuration Software

Configuration of a device can be done on two software applications: Configuration/Service Software (CSS) and Unified Network Configurator (UNC).

### CSS

is used to configure the parameters on the device. CSS can access devices remotely over the network, or locally through an Ethernet/serial connection to the service port on the device or through a LAN switch. CSS also can be used to view status information, equalize batteries, and check internal logs of the equipment at the site. See the *CSS Online Help* for configuration details.

### UNC Wizard

is a component of UNC used to configure the parameters of a site, subsite, and channel. See the *UNC Wizard Online Help* for configuration details.

### VoyenceControl

is a component of UNC used to pull and push configurations and configure the parameters of the device. See the *Unified Network Configurator* manual for general information about using VoyenceControl functions.



**NOTICE:** While it is possible to configure a conventional device using the UNC, it is preferable to use CSS because configuration dependencies are enforced.

The UNC is not applicable for K core or non-networked sites.

All parameters are programmed locally when the site is installed but not linked to a network. Test all parameters before making the site available. The ability to locally program provides the means to test the site before making it available for system operation.

### 4.2

## Discovering a Device in the UNC



**NOTICE:** GPW 8000 Receivers in circuit simulcast Configuration have no Ethernet connection for communication with the network management tools and other network devices. Centralized configuration or fault management of these GPW 8000 Receivers and GPB 8000 Reference Distribution Modules (RDMs) is not supported.

**When and where to use:** Use these high-level steps to discover the devices in the Unified Network Configurator (UNC). See the *Unified Network Configurator* manual for details on discovering devices.

### Process:

- 1 Use the UNC Discovery Wizard to:
  - Discover the devices.

- Upload configurations for the devices.
- Generate changes for non-compliant devices.

2 Approve jobs (if any).

#### 4.3

## Security/Authentication Services


If the device supports SNMPv3 protocol, a pop-up dialog box appears displaying the SNMPv3 Password Prompt when logging in to a device through Configuration/Service Software (CSS) using an Ethernet connection. For configuration details, see the *Information Assurance Features Overview*, *Software Download Manager*, and *SNMPv3* manuals. See [Figure 38: SNMPv3 Security Level Option Prompt on page 114](#).

**Figure 38: SNMPv3 Security Level Option Prompt**



A pop-up window appears displaying the File Transfer Access Services for CSS. Use this logon when communicating to a device through CSS using either an Ethernet or DB-9 Serial Port connection. See [Figure 39: CSS Login Banner on page 115](#).

Figure 39: CSS Login Banner



#### 4.4

## Device Configuration in CSS

This section covers configuration of a device using the Configuration/Service Software (CSS).

 **NOTICE:** The IP address for the device is available through a serial port connection in the **Tools** → **Set IP Address** from the CSS menu.

#### 4.4.1

### Configuring a GPW 8000 Initially Using CSS

#### Process:

- 1 Perform the following configuration steps that require a serial connection. See [Connecting Through a Serial Port Link on page 116](#).
  - a Set the IP address and paring number of the device. See [Setting the Device IP Address and Pairing Number in CSS on page 118](#).  
 **NOTICE:** The pairing number can also be set via Ethernet. See step 2a.
  - b Set the serial security services. See [Setting the Serial Security Services in CSS on page 119](#).
- 2 Perform the following configuration steps that require an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 121](#).
  - a Set the pairing number of the device. See [Setting the BR/CM Pairing Number in CSS on page 123](#).
  - b Set the current date and time in Configuration/Service Software (CSS). See [Setting the Date and Time in CSS on page 124](#).
  - c Change the SNMPv3 configuration and user credentials from CSS on a selected device in the site. See [Changing SNMPv3 Configuration and User Credentials in CSS on page 124](#).
  - d Create, update, or delete an SNMPv3 user. See [Adding or Modifying an SNMPv3 User in CSS on page 127](#).
  - e Verify the SNMPv3 credentials. See [Performing an SNMPv3 Connection Verification in CSS on page 127](#).

- f Configure Domain Name Services (DNS) for a conventional receiver using CSS. See [Configuring DNS in CSS on page 128](#).
- g Set the Software Download Manager (SWDL) transfer mode. See [Setting the SWDL Transfer Mode in CSS on page 129](#).
- h Configure for Secure SHell (SSH). See “Configuring SSH for RF Site Devices and VPMs Using CSS” in the *Securing Protocols with SSH* manual.
- i Enable RADIUS Authentication using CSS. See “Configuring RADIUS Sources and Parameters Using CSS” in the *Authentication Services* manual. Ensure that the receivers have been added to the RADIUS servers on the domain controllers as RADIUS clients.
- j Enable Centralized Authentication using CSS. See “Enabling/Disabling Centralized Authentication Using CSS” in the *Authentication Services* manual.
- k Set the Local Cache Size for Centralized Authentication using CSS. See “Setting the Local Cache Size for Central Authentication Using CSS” in the *Authentication Services* manual.
- l Customize the login banner text using CSS (optional). See [Customizing the Login Banner in CSS on page 129](#).
- m Enable Centralized Event Logging using CSS (optional). See “Enabling/Disabling Centralized Event Logging on Devices Using CSS” in the *Centralized Event Logging* manual.
- n Set the Network Time Protocol (NTP) Server Settings. See [NTP Server Settings in CSS on page 130](#).

3 Set up the local Password Configuration using CSS (optional). See [Setting the Local Password Configuration in CSS on page 131](#).

4 Continue to one of the following depending on the type of device you are configuring:

- [Setting CSS Configuration Parameters for the GPW 8000 Receiver \(Trunked Simulcast\) on page 132](#)
- [Setting CSS Configuration Parameters for the GPW 8000 Receiver \(Conventional\) on page 133](#).

#### 4.4.2

## Connecting Through a Serial Port Link

**Prerequisites:** This procedure assumes that the Configuration/Service Software (CSS) application is loaded on your service computer/laptop. See the *Private Network Management Client* manual.

**When and where to use:** This procedure describes the steps required to connect through a serial port link to set the IP address of the device and to set the serial security services. Perform all other device function and feature configurations through an Ethernet port connection in the CSS.


### Procedure:

- 1 Connect a serial cable to a service computer/laptop running CSS, and the serial connector on the device module. The serial cable is an RS232, female DB-9 to male DB-9 straight through cable. If the service computer/laptop does not have a serial port, use a USB-to-serial converter external device.
- 2 Open the CSS application.
- 3 From the menu, select **Tools** → **Connection Configuration**.  
The **Connection Screen** dialog box appears.
- 4 In the **Connection Type** area, select **Serial**.  
The **Serial Settings** area on the dialog box becomes enabled.

- 5 In the **Serial Port** field, select the communication port that matches the one selected on the service computer/laptop.
- 6 In the **Baud Rate** field, select the baud rate with which you want to communicate with the device.
  - Baud Rate 19200
- 7 Click **Connect**.

A login/password prompt screen appears.

**Figure 40: CSS Login Banner**



- 8 Provide the required credentials. Perform one of the following actions:
  - If a domain controller is available on the network, enter the **Username** and **Password** for the RADIUS service user account assigned to the netwadm group in the Active Directory. (The default service user is `serviceuser`.)
  - If a domain controller is not available on the network, enter the **Username** and **Password** for the local `bts_service` account.
  - If the **Elevated Privileges Password** field is active, enter the **Elevated Privileges Password** that was set up for this device.

When accessing the device, if the default passwords do not work, the passwords may have been set to default values by a different system release of software. See "Resetting Device Passwords" in the *CSS Online Help* to reset the passwords to the current software release defaults. If Authentication Services are not enabled on a device, type any alphanumeric characters to populate the [**Username**, **Password**, and **Elevated Privileges Password**] fields, as they cannot be left blank.

- 9 To access the device and close the dialog box, click **OK**.

The blank CSS main window appears.



**NOTICE:** The **Service** menu is not available until you read the configuration file from the device using an Ethernet connection.

## 4.4.3

## Serial Connection Configurations

The following procedures set configuration parameters in the Configuration/Service Software (CSS) using a serial connection.

## 4.4.3.1

### Setting the Device IP Address and Pairing Number in CSS

**Prerequisites:** Obtain the required credentials information (local service account password and elevated privileges password) to configure the site devices before proceeding. The user credentials information includes both the current and new credentials. Without the current credentials, access to the device or to the user credentials is denied. See [Local Password and SNMPv3 Passphrase Troubleshooting on page 161](#).



**NOTICE:** Setting or changing the device IP Address causes the SNMPv3 configuration and user credentials to automatically reset.

**Procedure:**

- 1 Connect to the device using Configuration/Service Software (CSS) through a serial port link. See [Connecting Through a Serial Port Link on page 116](#).
- 2 From the menu, select **Tools** → **Set IP Address/BR\_CM Pairing Number**.



**NOTICE:** If the device is not in a voting or simulcast IP only topology, the menu item is shown as **Set IP Address/Box Number**.

The **Set IP Address and Base Radio/Comparator Pairing Number** dialog box appears or the **Set IP Address and Box Number** dialog box appears.

- 3 In the **Device IP Address** field, enter the device IP address. Click **Set Device IP Address**.
- 4 In a voting or simulcast IP only topology, enter the device pairing number. Click **Set BR/CM Pairing Number**.
- 5 Click **OK** to close the dialog box.
- 6 Click **Reset** to initiate a hardware restart.

SNMPv3 user credentials reset to their factory default values.

- 7 Click **Close** to close the dialog box.
- 8 To reconfigure the SNMPv3 user credentials, see [Changing SNMPv3 Configuration and User Credentials in CSS on page 124](#).

## 4.4.3.2

### Pairing To a Comparator

When operating in a voting, multicast, Single Transmit Receiver Voting (STRV), or IP simulcast configuration, receivers must be paired to comparators using the **BR/CM Pairing Number**. The **BR/CM Pairing Number** for the receiver and comparator is used to create an IP multicast group that allows the receiver and comparator to talk to each other. The receiver listens for messages that the comparator sends to establish an IP connection with all the paired receivers. When the receiver receives the message from the comparator, it extracts the comparator IP address from the message and uses it to send received voice and data back to the comparator.

Communication from the comparator to the paired receiver always uses a multicast IP address. Communication between the paired receiver to the comparator always uses a unicast IP address.

The multicast IP address is calculated based on the receiver and comparator pairing number and the formula as follows:

**For Conventional Systems:**

224.10.100.nnn, where nnn is:  $(2 * \text{channel number}) - 1$  for channel number between [1, 127]

224.10.101.nnn, where nnn is:  $(2 * (\text{channel number} - 127) - 1)$  for a channel number between [128, 200]

**For Trunked Multi-Site Systems:**

224.100.102.nnn, where nnn is:  $100 + (2 * \text{channel number}) - 1$

 **NOTICE:** The **BR/CM Pairing Number** is not used for circuit (V.24 or 4-wire/V.24 hybrid link) configurations.

See [Setting the Device IP Address and Pairing Number in CSS on page 118](#) to set the pairing number. The pairing number can also be set using an Ethernet connection. See [Setting the BR/CM Pairing Number in CSS on page 123](#).

#### 4.4.3.3

### Serial Security Services in CSS

The Serial Security Services in Configuration/Service Software (CSS) enables the secure services and changes the device password.

 **NOTICE:** The Serial Security Services must be set before changing the SNMPv3 configuration and user credentials on a selected device in the site.

Before enabling this parameter, any login and password may be used on the File Transfer Access Services login window to access a device. After Authentication Services are enabled, the login and password provided is checked against the following authentication sources:

**Stored password**

RF site devices support a configurable password for the Local Service and Elevated Privileges accounts. The password is verified against the stored password for these accounts.

**Built-in logins and passwords**

RF site devices support built-in login/password combinations for a login by services such as the software downloads. Only certain software download login names are authenticated in this way.

**Centralized Authentication**

For authentication through centralized accounts instead of Local Service, Elevated Privileges, and built-in user accounts, use the **Configure the Centralized Authentication** parameter in CSS for the Challenge Handshake Authentication Protocol (CHAP). See Chapter 7, “Enabling/Disabling Centralized Authentication in CSS” in the *Authentication Services* manual. This procedure requires an Ethernet connection to the device being configured.

#### 4.4.3.3.1

### Setting the Serial Security Services in CSS

**Prerequisites:** Obtain the required credentials information (local service account password and elevated privileges password) to configure the site devices before proceeding. The user credentials information includes both the current and new credentials. Without the current credentials, you cannot access the device and cannot change the user credentials. See [Local Password and SNMPv3 Passphrase Troubleshooting on page 161](#). Changing to the incorrect user credentials may lead to not being able to access the device through Configuration/Service Software (CSS) or Secure SHell (SSH).

**Procedure:**

- 1 Connect to the device using CSS through a serial port link. See [Connecting Through a Serial Port Link on page 116](#).
- 2 From the menu, select **Security** → **Device Security Configuration** → **Security Services (Serial)**.
- 3 From the **Security Services Configuration** dialog box, set the **Test Application Configuration** field according to your organizational policies. The recommended secure configuration is **Disabled**.
- 4 Set the **Authentication Services** field to **Enabled**. Click **Apply**.  
This field enables local authentication services and must be enabled as a prerequisite for centralized authentication.
- 5 Set the **Password Reset Mechanism** field.  
This field allows a reset of the passwords for two built-in device accounts to their default values.
- 6 To update the password for the device, select either **Service Account** or **Elevated Privilege** from the drop-down list. Click **Update password**.
- 7 In the **Change Account Password** dialog box, enter the old password, then enter a new password, and confirm the new password before clicking **Change Password**.
- 8 To save the new password, click **OK**.  
The **Change Account Password** dialog box closes.

## 4.4.3.4

[\*\*Resetting SNMPv3 User Credentials to Factory Defaults in CSS\*\*](#)

**Prerequisites:** Obtain the required credentials information (local service account password and elevated privileges password) to configure the site devices before proceeding. The user credentials information includes both the current and new credentials. Without the current credentials, you cannot access the device and cannot change the user credentials. To obtain the keys for resetting either password or SNMPv3 passphrases for the device, contact Motorola Solutions Support Center (SSC). Changing to the incorrect user credentials may lead to not being able to access the device through Configuration/Service Software (CSS) or Secure SHell (SSH).

**Procedure:**

- 1 Connect to the device using CSS through a serial port link. See [Connecting Through a Serial Port Link on page 116](#).
- 2 From the menu, select **Security** → **SNMPv3 Configuration** → **Reset SNMPv3 Configuration (Serial)**.  
The **Reset SNMPv3 Configuration** dialog box opens.
- 3 Click **Reset SNMPv3 Configuration**.  
The SNMPv3 configuration is reset to factory defaults in the device.
- 4 Click **Exit**.  
The **Reset SNMPv3 Configuration** dialog box closes.
- 5 To reboot the device for the SNMPv3 user credentials to take effect, perform the following actions:
  - a From the menu, select **Tools** → **Set IP Address/Box Number** or **Set IP Address/BR\_CM Pairing Number**.

**b** In the dialog box, click **Reset**.

The device reboots.

**6** Proceed to [Changing SNMPv3 Configuration and User Credentials in CSS on page 124](#).

#### 4.4.4

## Connecting Through an Ethernet Port Link

**Prerequisites:** Load Configuration/Service Software (CSS) on the service computer/laptop. See the *Private Network Management Client* manual if necessary or see the instructions in the CSS DVD jewel box for instructions on loading the CSS onto the service computer/laptop.

**When and where to use:** Use the Ethernet port link to configure all CSS parameters for the device.

### Procedure:

**1** Connect a service computer/laptop to a device using one of the following methods:



**NOTICE:** Normally the service computer/laptop is connected through the local site switch or remotely through the network. Do not connect directly to the Ethernet service port of the device unless downloading software or individually configuring the device.

**a Remote Connection to Network or Local Site Switch:**

- 1 Connect remotely to the network or to the local site switch using a straight-through an Ethernet straight-through Ethernet cable.
- 2 If connecting to the local site switch, configure the Ethernet interface of the service computer/laptop to a Speed/Duplex setting of **Auto-Negotiate**. Set the IP address of the service computer/laptop to an unused IP address on the subnet of the local site. The IP address on the subnet varies depending on the site and zone numbers.

**b Direct Connection to Front Ethernet Service Port:**

- 1 Connect directly to the front panel Ethernet service port with a straight-through Ethernet cable.
- 2 If connecting to a base radio or receiver, set the IP address of the service computer/laptop to 192.168.x, where x is any number between 2 and 253.
- 3 If connecting to a site controller or reference distribution module, set the IP address of the service computer/laptop to an unused IP address on the subnet of the local site. The IP address on the subnet varies depending on the site and zone numbers.
- 4 Configure the Ethernet interface of the service computer/laptop to a Speed/Duplex setting of **Auto-Negotiate**



**NOTICE:** The comparator does not support a direct connection to the front panel Ethernet service port. The connection must be done remotely through the network or through the local site switch.

- 2 Open the CSS application.
- 3 From the menu, select **Tools** → **Connection Configuration**.
- 4 From the **Connection Screen**, in the **Connection Type** area, select **Ethernet**.
- 5 If connected directly to the front panel Ethernet service port of a base radio or receiver, click **Front Panel Ethernet** and go to [step 7](#).
- 6 Perform one of the following actions:

If...	Then...
<b>If you know the IP address for the device,</b>	<p>perform the following actions:</p> <ol style="list-style-type: none"> <li data-bbox="571 291 1354 348">a In the <b>Device IP Address</b> field, enter the IP address for the device.</li> <li data-bbox="571 359 783 390">b Click <b>Connect</b>.</li> <li data-bbox="571 401 750 432">c Go to <a href="#">step 7</a>.</li> </ol>
<b>Trunked Device: If you do not know the IP address, but know the system identification of the device (the zone, physical site, subsite, and device ID of the device),</b>	<p>perform the following actions:</p> <ol style="list-style-type: none"> <li data-bbox="571 508 1354 566">a Click <b>Device Name Wizard</b> to open the <b>Device Name Wizard</b> dialog box.</li> <li data-bbox="571 576 1354 608">b From the <b>Device</b> drop-down list, select the relevant device type.</li> <li data-bbox="571 618 1354 675">c In the <b>Zone</b>, <b>Physical Site</b>, <b>Subsite</b>, and <b>Device ID</b> fields, enter the proper values.</li> <li data-bbox="612 686 1321 798">  <b>NOTICE:</b> Some fields, such as <b>Subsite</b>, do not allow entries for some devices. Therefore, select the device first.             </li> <li data-bbox="571 808 718 840">d Click <b>OK</b>.</li> </ol> <p>The Domain Name Services (DNS) information of the device automatically appears in the <b>Device IP Address</b> field.</p> <ol style="list-style-type: none"> <li data-bbox="571 918 783 950">e Click <b>Connect</b>.</li> <li data-bbox="571 960 750 992">f Go to <a href="#">step 7</a>.</li> </ol>
<b>Conventional Device: If you do not know the IP address,</b>	<p>perform the following actions:</p> <ol style="list-style-type: none"> <li data-bbox="571 1072 1354 1129">a Establish a serial connection to the device. See <a href="#">Connecting Through a Serial Port Link on page 116</a>.</li> <li data-bbox="571 1140 1354 1262">b For a base radio, receiver, or comparator, from the menu, select <b>Tools</b> → <b>Set IP Address/BR_CM Pairing Number</b>. For a site controller or reference distribution module, select <b>Set IP Address/Box Number</b>.</li> <li data-bbox="571 1273 1240 1305">c In the <b>Device IP Address</b> field, record the IP address.</li> <li data-bbox="571 1315 1354 1372">d Re-establish an Ethernet connection and repeat steps 1 through 4.</li> <li data-bbox="571 1383 1354 1440">e In the <b>Device IP Address</b> field, enter the IP address for the device.</li> <li data-bbox="571 1450 750 1482">f Go to <a href="#">step 7</a>.</li> </ol>

7 To make the connection, click **Connect**.

If this device is SNMPv3-capable, the **SNMPv3 Passphrase Prompt** dialog box appears.

Figure 41: SNMPv3 Passphrase Prompt



- 8 In the **SNMPv3 Passphrase Prompt** dialog box, enter the **User Information** and **Passphrase Information**. Click **OK**. If Authentication Services are not enabled on a device, click **OK** when the dialog box appears.
- 9 From the menu, select **File** → **Read Configuration From Device**.

The parameters download from the device to the service computer/laptop. When the download is complete, the CSS main window opens. Use the map on the left side of the screen to view configuration information for the device.

#### 4.4.5

### Ethernet Connection Configurations

The following procedures set configuration parameters in the Configuration/Service Software (CSS) using an Ethernet connection.

#### 4.4.5.1

### Setting the BR/CM Pairing Number in CSS

#### When and where to use:

Set the pairing number for the base radio, receiver, and comparator using Configuration/Service Software (CSS) when operating in a voting, multicast, or simulcast IP configuration using an Ethernet connection.

#### Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 From the menu, select **Service** → **BR/CM Pairing Number**.

- 3 Enter the pairing number. Click **OK**.

The pairing number is set.

#### 4.4.5.2

### Setting the Date and Time in CSS

This procedure provides the date and time to the device.

**When and where to use:** During installation, the date and time is set through an Ethernet cable connected directly to the Ethernet port of the device. After installation, this procedure may be performed remotely.



**NOTICE:** If a power outage occurs, the device does not retain the date and time settings.

#### Procedure:

- 1 Connect to the device using CSS through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 From the menu, select **Tools** → **Set Device Date and Time**.
- 3 Enter the current date and time. Click **OK**.

The date and time are set.

#### 4.4.5.3

### Changing SNMPv3 Configuration and User Credentials in CSS

**Prerequisites:** Obtain the required SNMPv3 credentials information (Authentication passphrase, Encryption passphrase, and Authoritative Engine ID) to configure the device before proceeding. The user credentials information includes both the current and new credentials. Without the current credentials, you cannot access the device and cannot change the user credentials. See [Local Password and SNMPv3 Passphrase Troubleshooting on page 161](#). Changing to the incorrect user credentials may lead to not being able to access the device from the Unified Network Configurator (UNC), or for the device to be unable to send alarms to the Unified Event Manager (UEM) (for fault management).

**When and where to use:** This procedure changes the SNMPv3 configuration and user credentials from Configuration/Service Software (CSS) on a selected device in the site. For more information on this feature, see the [SNMPv3](#) manual.



**NOTICE:** During installation, perform this procedure through an Ethernet cable connected directly to the Ethernet port of the device. After installation, this procedure may be performed remotely from CSS.

#### Procedure:

- 1 Connect to the device using CSS through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 From the menu, select **Security** → **SNMPv3 Configuration** → **Configure SNMPv3 Users (Ethernet)**.

The **SNMPv3 Passphrase Prompt** dialog box appears with **MotoAdmin** as the selected SNMPv3 user.

- 3 In the **SNMPv3 Passphrase Prompt**, enter the appropriate **Authentication** and **Encryption Passphrases** in the text fields.



**NOTICE:** When accessing the device for the first time, if the default passphrases do not work, the passphrases may have been set to default values by a different system release of software. See “Reset SNMPv3 Configuration (Serial)” in the *CSS Online Help* to reset the passphrases to the current software release defaults.

- 4 If connecting remotely through the network to a different device, perform one of the following actions. Otherwise, go to [step 5](#).

If...	Then...
<b>If you know the IP address for the device,</b>	<p>perform the following actions:</p> <ol style="list-style-type: none"> <li>In the <b>Device IP Address</b> field, enter the IP address for the device.</li> <li>Go to <a href="#">step 5</a>.</li> </ol>
<b>If you do not know the IP address, but know the system identification of the device (the zone, physical site, subsite, and device ID of the device),</b>	<p>perform the following actions:</p> <ol style="list-style-type: none"> <li>Click <b>Device Name Wizard</b>.</li> <li>From the <b>Device</b> list box, select the desired device type.</li> <li>In the <b>Zone</b>, <b>Physical Site</b>, <b>Subsite</b>, and <b>Device ID</b> fields, enter the proper values.</li> </ol> <p> <b>NOTICE:</b> Some fields, such as <b>Subsite</b>, do not allow entries for some devices. Therefore, select the device first.</p> <ol style="list-style-type: none"> <li>Click <b>OK</b>. The Domain Name Services (DNS) information of the device automatically appears in the <b>Device IP Address</b> field.</li> <li>Click <b>Connect</b>.</li> <li>Go to <a href="#">step 5</a>.</li> </ol>

- 5 Click **OK**.

If the passphrases are authenticated, the **Configure SNMPv3 Users** window appears. If the connection fails, a message appears.

- 6 To update the SNMPv3 credentials for a selected user, from the **User Information** section, select a Username in the **Username** drop-down list.

The CSS retrieves the current credentials from the device for a selected user.



**NOTICE:** Depending on the user selected, some fields on this dialog box become read-only or disabled. Click **Cancel** at any time to discard changes made to a selected user.

- 7 To change or update the SNMPv3 security level for a selected user, from the **User Information** section, select the security level in the **Security Level** drop-down list.

The security level options are:

**NoAuthNoPriv**

Neither the **Authentication Passphrase** nor **Encryption Passphrase** are needed for communicating with the device.

**AuthNoPriv**

**Authentication Passphrase** is needed; but no **Encryption Passphrase** is needed for communicating with the device.

**AuthPriv**

Both **Authentication Passphrase** and **Encryption Passphrase** are needed for communicating with the device.

The **User Status** field reflects the current operational status of the selected SNMPv3 User. The **Status Types** include:

**Active**

User configured on the device; the **Update** and **Delete** options are enabled.

**Not in service**

User configured on the device; the **Update** and **Delete** options are enabled.

**Not ready**

User configured on the device; the **Update** and **Delete** options are enabled.

**Not present**

Not present on the device; the **Create** option is enabled.

The security level of the selected user is set.

**8** To change the Authentication Passphrase for the selected SNMPv3 user, if applicable to the selected security level, perform the following actions:

**a** From the **Authentication Passphrase** section, enter the passphrase into the **Old Passphrase** field.



**NOTICE:** If you do not know the passphrase, select the **I do not remember old passphrase** check box.

**b** Enter the new passphrase into the **New Passphrase** field.



**NOTICE:** The passphrase must be between 8 and 64 characters in length and consist of upper or lowercase alphanumeric characters (excluding the @ # \$ ^ or \_ characters).

**c** Enter the same new passphrase into the **Confirm New Passphrase** field.

**9** To change the encryption passphrase for the selected SNMPv3 user, if applicable to the selected security level, perform the following actions:

**a** From the **Encryption Passphrase** section, enter the old passphrase into the **Old Passphrase** field.



**NOTICE:** If you do not know the passphrase, select the **I do not remember old passphrase** check box.

**b** Enter the new passphrase into the **New Passphrase** field.

**c** Enter the same new passphrase into the **Confirm New Passphrase** field.

**10** To change the Authoritative Engine Identifier, applicable to MotoInformA and MotorInformB users only, perform the following actions:

**a** From the **Authoritative Engine ID** section, select the desired current engine ID from the **Current Engine ID** drop-down list.

**b** In the **New Engine ID** field, enter the new engine ID.



**NOTICE:** The new engine ID must be between 1 and 27 characters and comply with the Engine ID Domain Name Syntax.

**11** To create, update, or delete SNMPv3 users, go to [Adding or Modifying an SNMPv3 User in CSS on page 127](#).

#### 4.4.5.3.1

### Adding or Modifying an SNMPv3 User in CSS

**When and where to use:** Use this procedure to create, update, or delete an SNMPv3 user from the **Configure SNMPv3 Users** window.

#### Procedure:

- 1 From the **Configure SNMPv3 Users** window, to add or modify the selected SNMPv3 user, click one of the following:
  - **Create:** Creates a user when the status is Not Present.
  - **Update:** Updates an existing user.
  - **Delete:** Removes an existing user.

A **Confirmation** dialog box appears and prompts if you want to continue.

- 2 Click **Yes**.

The **Processing Requests** dialog box appears and processes the request. A green square X indicates OK and a red square X indicates failure.

- 3 After reviewing the processing status, click **OK**.



**NOTICE:** If you encounter any errors, go back to the appropriate step and correct the information entered.

- 4 Repeat these steps for any SNMPv3 users you wish to create, update, or delete.

- 5 Click **Cancel** to exit the **Configure SNMPv3 Users** window.

The **Configure SNMPv3 Users** window closes, and the CSS main window returns.

#### 4.4.5.3.2

### Performing an SNMPv3 Connection Verification in CSS

**When and where to use:** When the SNMPv3 user credentials have been created, modified, or deleted, ensure that the device is properly configured for SNMPv3. Follow this procedure to verify the SNMPv3 connection.

#### Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 When the passphrase prompt screen opens, select the configured security level and enter the required passphrases.
- 3 If the connection was successful, click **OK**.

#### 4.4.5.4

### DNS Configurations



**NOTICE:** This procedure is not applicable for a K core site.

The **Network Services Configuration** window allows you to configure the network Domain Name Services (DNS) for this device, if part of a secure network.

Configuring DNS in CSS on page 128 describes the steps for configuring DNS for a device using Configuration/Service Software (CSS). Configuring the DNS is required before entering the Fully Qualified Domain Name (FQDN) for servers on the **Network Security Configuration** window in CSS.

For information on DNS-related failures that may occur during or after DNS configuration, see the “AD/DNS Troubleshooting” chapter in the *Authentication Services* manual.


#### 4.4.5.4.1

### Configuring DNS in CSS

#### Procedure:

- 1 Obtain the IP addresses for a Primary, Secondary and/or Tertiary Domain Name Services (DNS) server IP. If necessary, contact your system administrator for this information before continuing to step 2.
- 2 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 121](#).
- 3 On the navigation pane, select **Network Services Configuration**.
- 4 In the **Network Services Configuration** window, select the **DNS Configuration** tab.

**Figure 42: CSS Network Services Configuration – DNS Tab**



- 5 Enter the **Requested DNS Server IP** address for the Primary, Secondary, and Tertiary DNS servers.



**NOTICE:** The **Primary Row Status** must be enabled before the **Secondary** row is ungrayed. The **Secondary** row status must be enabled before the **Tertiary** row is ungrayed.

- 6 In the **Row Status** field, select whether the IP address for the Primary, Secondary, or Tertiary DNS server is **Enabled** or **Disabled**. Choose **Enabled** to use the DNS server IP address.

- 7 In the **Requested DNS Domain Name** field, enter up to 191 alphanumeric characters. The **Primary Row Status** must be set to **Enabled** for this field to be active.



**NOTICE:** Base domain names for site devices on the site ID and zone ID (such as siteXzoneZ).

For assistance in completing the **Requested DNS Domain Name** field, click **DNS Service Wizard**.

- 8 In the **Requested DNS Host Name** field, enter up to 63 alphanumeric characters for the network in which this device resides. A **Requested DNS Domain Name** must be entered for this field to be active.



**NOTICE:** This field is available only when configuring a conventional device AND a **Requested DNS Domain Name** has been entered.

For assistance in completing the **Requested DNS Host Name** field, click **DNS Service Wizard**.

- 9 The **System Name** field is not user editable and is filled only after using the DNS Service Wizard.



**NOTICE:** This field is used only when configuring a conventional device.

- 10 Click **DNS Service Wizard** for assistance in completing the fields in the **DNS Service Configuration** screen. See the *CSS Online Help* for configuration details.

#### 4.4.5.5

### Customizing the Login Banner in CSS

This procedure describes how to edit the login banner security notice.

#### Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 From the menu, select **Security** → **Device Security Configuration** → **Remote Access/Login Banner (Ethernet)**.
- 3 From the **Remote Access/Login Banner** screen, **Remote Access Configuration** tab, click the **Login Banner** tab.
- 4 Edit the text of the banner.
- 5 Click one of the following:
  - **Refresh:** re-reads the original Login Banner text.
  - **Apply:** saves the changes and keep the screen open.
  - **OK:** saves the changes and close the screen.
  - **Cancel:** closes the screen without saving the changes.

#### 4.4.5.6

### Setting the SWDL Transfer Mode in CSS

This procedure sets the Software Download Manager (SWDL) transfer mode.

**When and where to use:** Follow this procedure to set the SWDL transfer mode to Ftp (clear) or Sftp (secure) before performing a software download on the device.




**NOTICE:** The SWDL transfer mode must be set to **Ftp** (clear) if any PSC 9600, STR 3000, QUANTAR®, or ASTRO-TAC® 9600 device is present at a site.

#### Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 From the menu, select **Security** → **Device Security Configuration** → **Remote Access/Login Banner (Ethernet)**.

The **Remote Access/Login Banner** screen appears displaying the **Remote Access Configuration** tab.

**Figure 43: Remote Access Configuration Tab**

3 In the **Software Download Transfer Mode (Requested)** field, choose either **Ftp** (clear) or **Sftp** (secure). Click **OK**.

 **NOTICE:** Secure Shell Service (Requested) and Secure FTP (Requested) are automatically set to **Enabled** and grayed out when you choose **Sftp**.

#### 4.4.5.7

### Manager IP Address Settings in CSS

When IP addresses exceed the allowed total, remove the IP addresses that are no longer used at the site. This removal allows the Unified Event Manager (UEM) to be identified as the current manager and handles traps for the device.

See “Clearing Manager IP Address” in the *CSS On-line Help* for removing these IP addresses.

#### 4.4.5.8

### NTP Server Settings in CSS

Network Time Protocol (NTP) provides a clock synchronization mechanism for various network devices and computers, and allows the NTP server to provide the date and time synchronization for a particular device. The NTP server IP address must be entered on the **Manager / NTP Definition** screen.

For security purposes, the receiver can restrict NTP messages from only the site controller. This restriction can be accomplished by configuring two site controller IP addresses into the **NTP Server IP Address** fields on the receiver.

See “Configuring the NTP Servers” in the *CSS On-line Help* for defining, editing, and removing these settings.

## 4.4.5.9

## Setting the Local Password Configuration in CSS


**When and where to use:** Use this procedure to set the complexity requirements and controls for the local service account password. The updated password criteria is enforced on the next password change for the device local service account. Password Configuration is an optional feature. For information, see "Password Configuration" in the *CSS Online Help*.

**Procedure:**

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 In the navigation pane, click the **Password Configuration** element.

The **Password Configuration** window appears.

**Figure 44: Password Configuration Window**



- 3 Complete the following fields:

**Minimum Password Length**

This field allows you to enter a value as the minimum length for the password. The minimum can be between 8 and 255 characters, with a default of 10 characters.

**Number of Required Special Characters**

This field allows you to enter a value for the required number of special characters which must be included in the password. The value can be between 0 and 255, with a default of 1.

**Number of Required Numeric Characters**

This field allows you to enter a value for the required number of numeric characters which must be included in the password. The value can be between 0 and 255, with a default of 2.

**Number of Required Uppercase Characters**

This field allows you to enter a value for the required number of uppercase alphabetic characters which must be included in the password. The value can be between 0 and 255, with a default of 2.

**Number of Required Lowercase Characters**

This field allows you to enter a value for the required number of lowercase alphabetic characters which must be included in the password. The value can be between 0 and 255, with a default of 2.

**Number of Consecutive Characters**

This field allows you to enter the maximum number of consecutive repeated characters permitted in the password.

**Set Values to Default**

This field returns all fields to their system default values.

**Password Aging Time [days]**

This field allows you to enter a value between 0 and 65535 for the maximum number of days a local password is valid. After the **Password Aging Time** has elapsed, the password must be changed. The default value is 0.

**Change Interval Limit [days]**

This field allows you to enter a value between 0 and 65535 for the number of days which must elapse before a local password can be changed. The default value is 1.

#### 4.4.6

## Setting CSS Configuration Parameters for the GPW 8000 Receiver (Trunked Simulcast)

**Prerequisites:**

Before proceeding with this process, complete the initial configuration of the device in [Configuring a GPW 8000 Initially Using CSS on page 115](#).

For configuration parameters on each field for a trunked simulcast GPW 8000 Receiver, see "Multi-Site or Simulcast Subsystem" in the *CSS Online Help*.

**Process:**

1 Connect to the receiver through an Ethernet port link and then read the configuration file from the receiver. See [Connecting Through an Ethernet Port Link on page 121](#).

2 In the **System** tree, click **System** and complete the fields.

3 In the **System** tree, click **Site** and complete the fields.

4 In the **System** tree, click **Channel** and complete the fields.

5 In the **System** tree, click **Subsite** and complete the fields.

6 In the **System** tree, click **Configuration** and complete the fields on all four tabs.

As part of Remote Multicoupler (RMC) configuration, set the DIP switches on the RMC/Low Noise Amplifier (LNA) modules. See [Setting RMC System Gain on page 134](#).

7 In the **System** tree, click **Network Services Configuration** and complete the fields on the three tabs.

For configuration details for DNS and RADIUS Services, see the *Authentication Services* manual. For configuration details for SYSLOG Services, see the *Centralized Event Logging* manual.

8 In the **System** tree, click **Password Configuration** and complete the fields.

**Password Configuration** is required only if you have passwords entered for local accounts. It sets the password complexity and controls. For details on password complexity and controls, see "Password Configuration" in *CSS Online Help*.

9 From the menu, select **File** → **Save As** to save the configuration data to a new archive file, or select **File** → **Save** to overwrite the existing archive file.



**IMPORTANT:** Save any configuration changes to a local or network drive so that if the transceiver module fails, you can load your settings to a replacement transceiver. If the configuration file is not saved to a local or network drive, repeat the setup steps after replacing a transceiver module.

10 To write the configuration data to the receiver, from the menu, select **File** → **Write Configuration to Device**.

Set the hardware platform to GPW 8000 Receiver.

#### 4.4.7

## Setting CSS Configuration Parameters for the GPW 8000 Receiver (Conventional)

### Prerequisites:

The **Ethernet Type** field for a standalone conventional receiver must be set to 10 Mbit, half-duplex.

Before proceeding with this process, complete the initial configuration of the device in [Configuring a GPW 8000 Initially Using CSS on page 115](#).

For configuration parameters for a conventional GPW 8000 Receiver, see the following in the CSS *Online Help*:

- **Analog-only, Digital-only, or Mixed Mode GTR 8000 Base Radio:** Conventional Site - ASTRO 7.12 and Later

### Process:

1 Connect to the receiver through an Ethernet port link and then read the configuration file from the receiver. See [Connecting Through an Ethernet Port Link on page 121](#).

2 In the **System** tree, click **Site** and complete the fields.

3 In the **System** tree, click **Hardware Configuration** and complete the fields on the two tabs.



**NOTICE:** As part of Remote Multicoupler (RMC) configuration, set the DIP switches on the RMC/Low Noise Amplifier (LNA) modules. See [Setting RMC System Gain on page 134](#).

4 In the **System** tree, click **Options** and complete the fields.

5 In the **System** tree, click **Infrastructure Interface** and complete the fields on the three tabs.

6 In the **System** tree, click **Channel Configuration** and complete the fields.

7 In the **System** tree, click **Repeater Configuration** and complete the fields.

8 In the **System** tree, click **Receiver Scan** and complete the fields.

9 In the **System** tree, click **Repeater Access** and complete the fields.

10 In the **System** tree, click **WildCard Tables** and complete the fields on the three tabs.

11 In the **System** tree, click **Network Services Configuration** and complete the fields on the three tabs.



**NOTICE:** For configuration details for RADIUS Services, see the *Authentication Services* manual. For configuration details for SYSLOG Services, see the *Centralized Event Logging* manual.

12 In the **System** tree, click **Password Configuration** and complete the fields.



**NOTICE: Password Configuration** is required only if you have passwords entered for local accounts. It sets the password complexity and controls. For details on password complexity and controls, see "Password Configuration" in *CSS Online Help*.

13 From the menu, select **File** → **Save As** to save the configuration data to a new archive file, or select **File** → **Save** to overwrite the existing archive file.



**IMPORTANT:** Save any configuration changes to a local or network drive so that if the receiver fails, you can load your settings to a replacement receiver. If the configuration file is not saved to a local or network drive, you will need to repeat the setup steps after replacing a receiver.

14 From the menu, select **File** → **Write Configuration to Device** to write the configuration data to the receiver.

Set the hardware platform to GPW 8000 Receiver.

## 4.4.8

## Configuring Battery Type

**When and where to use:** As part of the site configuration process, configure the **Battery Type** on the **Hardware Configuration** tab in Configuration/Service Software (CSS).



**NOTICE:** Configuring the battery type applies only to the transceiver in the bottom slot of the chassis. In the CSS, the top slot transceiver battery configuration option is grayed out.

**Procedure:**

- 1 Open CSS.
- 2 Connect to the device through an Ethernet port link. Read the configuration file from the device. See [Connecting Through an Ethernet Port Link on page 121](#).
- 3 From the navigation tree, select **Configuration**.
- 4 From the **Configuration** window, select the **Hardware Configuration** tab.
- 5 Select the **Battery Type** (manufacturer and model, or select the generic listing for the class of battery).
- 6 From the menu, select **File** → **Save** or **File** → **Save As** to save the configuration to an archive on your local or network drive.
- 7 To write the configuration to the device, select **File** → **Write Configuration to Device** from the menu.

## 4.4.9

## Setting RMC System Gain

**When and where to use:**

The Receive Multicoupler (RMC) system gain must be set up according to your GPW 8000 Receiver configuration.



**NOTICE:** For receivers, calculate and enter a value for system gain. Calculate the system gain from the receiver multicoupler input to the receivers Rx input. If there is no multicoupler, enter zero.

**Procedure:**

- 1 Open Configuration/Service Software (CSS).
- 2 Connect to the device through an Ethernet port link. Read the configuration file from the device. See [Connecting Through an Ethernet Port Link on page 121](#).
- 3 From the menu, select **File** → **Read Configuration from Device**.
- 4 From the navigation tree, select **Configuration**.
- 5 Select the **Receive Multicoupler (RMC) Configuration** tab.
- 6 In the **GTR 8000 Configuration** field, select **GTR 8000 Base Radio Standalone**.
- 7 In the **System Gain** field, enter a dB value.
- 8 From the menu, select **File** → **Save** or **File** → **Save As** to save the RMC configuration to an archive on your local or network drive.
- 9 From the menu, select **File** → **Write Configuration to Device** to write the configuration data to the receiver.

The RMCs automatically use the resulting system gain. In addition, an appropriate transceiver attenuation is automatically calculated and saved in the configuration file.

#### 4.5

## Configuring Centralized Authentication on Devices in VoyenceControl

**When and where to use:** This process provides the procedures for configuring centralized authentication on devices using the VoyenceControl component of the Unified Network Configurator (UNC) application.



**NOTICE:** VoyenceControl does not apply for a K core or non-networked site.

#### Process:

- 1 Configure Domain Name Service (DNS) on the device. See “Configuring DNS on RF Site and VPM Devices in VoyenceControl” in the *Authentication Services* manual.
- 2 Configure Authentication Sources for the device. See “Configuring Authentication Sources for RF Site and VPM Devices in VoyenceControl” in the *Authentication Services* manual.
- 3 Configure RADIUS parameters for the device. See “Configuring Radius Parameters for RF Site and VPM Devices in VoyenceControl” in the *Authentication Services* manual.
- 4 Set the Local Cache Size for Centralized Authentication for the device. See “Setting the Local Cache Size for Central Authentication on RF Site and VPM Devices in VoyenceControl” in the *Authentication Services* manual.
- 5 Enable/Disable Centralized Authentication for the device. See “Enabling/Disabling Centralized Authentication on RF Site and VPM Devices in VoyenceControl” in the *Authentication Services* manual.
- 6 Enable/Disable Centralized Event Logging for the device. See “Enabling/Disabling Centralized Event Logging on RF Site Devices and VPMs in VoyenceControl” in the *Centralized Event Logging* manual.

#### 4.6

## Configuring the Trunked GPW 8000 Receiver in Circuit Simulcast Using CSS

Use this procedure to configure the trunked GPW 8000 Receiver in a circuit simulcast configuration.

#### Prerequisites:

This procedure requires use of the following:

- Standard or crossover RJ-45 Ethernet cable
- A service computer/laptop with the Configuration/Service Software (CSS) application installed

**When and where to use:** If possible, configure the Trunked GPW 8000 Receiver before it is required, and save the configuration to an archive file.

#### Procedure:

- 1 Connect the Ethernet cable between the Ethernet port on the service computer/laptop and the Ethernet service port on the front of the trunked GPW 8000 Receiver. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 Upon completion of a successful read, click **OK** to continue.

**3** In the **Hardware Configuration** screen, set **Ethernet Type** to **10Mbit, half duplex**.

The Ethernet port on the backplane of the trunked GPW 8000 Receiver is set after the configuration is written to the device.

**4** In the **Hardware Configuration** screen, set **Hardware Platform [R]** to **GPW 8000 Satellite Receiver**.

**5** Set the **BR type** to **GPW 8000** (the default setting is GTR 8000).

**6** Configure the Trunked GPW 8000 Receiver using one of the following methods:

- Replacing QUANTAR:

**1** Print out the Codeplug report archived in the “Archiving the QUANTAR Codeplug Report using WinRSS” procedure in the *Quick Guide for Replacing a Trunked 3600 QUANTAR with a GTR 8000 Base Radio*. Use it as a reference to configure the trunked GPW 8000 Receiver.

**2** Launch the WinRSS application and open the archived QUANTAR station codeplug file. At the same time, open the CSS application and compare WinRSS parameters to their equivalent CSS parameters.

**3** For a listing comparing RSS to CSS parameters, see “ASTRO Trunked 3600 IntelliRepeater Parameters” in the *Quick Guide for Replacing a Trunked 3600 QUANTAR with a GTR 8000 Base Radio*.

- Replacing ASTRO-TAC

**1** Print out the Codeplug report archived in the “Archiving the ASTRO-TAC Codeplug Report using WinRSS” procedure, and use it as a reference to configure the trunked GPW 8000 Receiver.

**2** Launch the WinRSS application and open the archived ASTRO-TAC receiver codeplug file. At the same time, open the CSS application and compare WinRSS parameters to their equivalent CSS parameters.

**3** For a listing comparing RSS to CSS parameters, see *ASTRO-TAC 3000 COMPARATOR Radio Service Software User's Guide, Software Part No.: RVN-4154*.

**7** Set the relevant parameters in the CSS screens to match the values from the QUANTAR station codeplug. For an ASTRO Simulcast GPW 8000 Receiver, see the “Trunking Site – 3600 Simulcast Site” section in *CSS Online Help*.

**8** From the menu, select **File** → **Save As** to save the new configuration to an archive file.

**9** To write the configuration data to the receiver, from the menu, select **File** → **Write Configuration to Device**.

**10** Close the CSS application and disconnect the service computer/laptop.

## Chapter 5

# GPW 8000 Receiver Optimization

Your Motorola Solutions Field Representative or Motorola Solutions Support Center (SSC) can advise you on optimization activities required for your system, if any. See [Motorola Solutions Support Center on page 162](#).

This chapter contains optimization procedures and recommended settings relating to GPW 8000 Receiver.

5.1

## Aligning the Internal Frequency Reference Oscillator

The transceiver option card within a receiver provides an internal 10 MHz frequency reference which can be used as the primary or backup frequency reference source for the device. For conventional receiver operation, it also provides the analog interfaces and wildcard I/Os.

After a receiver is installed or after the transceiver option card is replaced, align the internal frequency reference oscillator.

Align the transceiver option card internal frequency reference oscillator to within 1 ppb (parts per billion). The measuring equipment used to make this alignment must be accurate to within 1 ppb. This accuracy typically requires test equipment with a double oven or a Rubidium reference oscillator.



**NOTICE:** The receiver must be turned on for at least one week before the internal frequency reference oscillator is aligned.

Align the internal frequency reference oscillator for an Oven Controlled Crystal Oscillator (OCXO) transceiver option card:

- Upon installation of the receiver for all bands.
- Once every two years after installation for 700/800/900 MHz systems.
- Once every five years after installation for UHF systems.
- VHF systems do not require alignment after initial installation.

Align the internal frequency reference oscillator for a Temperature Compensated Crystal Oscillator (TCXO) transceiver option card:

- Upon installation of the receiver for UHF.
- Every year after installation for UHF.

The internal frequency reference oscillator can only be aligned on a GPW 8000 Receiver using the auto alignment procedure.

See **“Base Radio Service Help → Service Screens → Alignment Screens”** in the *CSS Online Help* for the alignment procedures.

## 5.1.1

**GPW 8000 Receiver Time and Frequency Inputs**

Various external time and frequency inputs can be provided to the receiver for normal operation or for Internal Frequency Reference Oscillator alignment. The following table provides a list of acceptable input signal types and levels for each input port.

Table 29: Time and Frequency Inputs

Input Port	Frequency	Waveform	Level	Impedance	Note
Ext Freq Ref	5 MHz	Sine	2.6–5.3 Vpp	100k ohms	AC coupled
Ext Freq Ref	5 MHz	Square	45–55% duty cycle	100k ohms	AC coupled
Ext Freq Ref	10 MHz	Sine	2.6–5.3 Vpp	100k ohms	AC coupled
Ext Freq Ref	10 MHz	Square	45–55% duty cycle	100k ohms	AC coupled
Ext Freq Ref	20 MHz	Sine	2.6–5.3 Vpp	100k ohms	AC coupled
Ext Freq Ref	20 MHz	Square	45–55% duty cycle	100k ohms	AC coupled
Ext Freq Ref	5 MHz/ 1PPS*	Square	2.6–5.3 Vpp	100k ohms	AC coupled; 25% modula- tion 1pps ar- rives on 75% duty cycle
1PPS	1PPS	Pulse	2.6–5.3 Vpp	100k ohms	DC coupled
Front Panel Ext Freq Ref	5 MHz	Sine	2–5 Vpp; 10–18 dBm	50 ohms	AC coupled
Front Panel Ext Freq Ref	5 MHz	Square	45–55% duty cy- cle	50 ohms	AC coupled
Front Panel Ext Freq Ref	10 MHz	Sine	2–5 Vpp; 10–18 dBm	50 ohms	AC coupled
Front Panel Ext Freq Ref	10 MHz	Square	45–55% duty cy- cle	50 ohms	AC coupled
Front Panel Ext Freq Ref	5 MHz/ 1PPS*	Square	2.6–5.3 Vpp	50 ohms	AC coupled; 25% modula- tion 1pps ar- rives on 75% duty cycle

\* 25% modulation, 1PPS arrives on 75% duty cycle.



**NOTICE:** The Front Panel EXT FREQ REF connection is the Frequency Calibrator (BNC connector) on the transceiver module.



**NOTICE:**

- The trunked GPW 8000 Receiver uses an integrated reference input through the CP2 link from the Reference Distribution Modules
- Reference oscillator alignment is not required for GPB 8000 RDM with trunked GPW 8000 Receiver in trunked receive-only remote sites.

**5.2**

## Battery Equalization

Battery Equalization configures the power supply to set the proper charge and capacity for the storage batteries connected to the receiver. Sites equipped with storage batteries that provide power in case of primary power failure require that the battery cells be equalized periodically.

See “**Base Radio Service Help → Service Screens → Alignment Screens**” in the *CSS Online Help* for the alignment procedures.



**NOTICE:** Some batteries do not require equalization. See the battery manufacturer recommendations.

**5.3**

## Carrier Squelch Alignment

A Carrier Squelch (CSQ) Alignment is typically performed at an RF level which corresponds to 12 dB SINAD, or an RF level which corresponds to 20 dB quieting, or any other RF level selected.

The **CSQ Alignment** screen facilitates the measurement of 12 dB SINAD for the receiver under testing by allowing the Rx Qualifiers to be set to Open. When the Rx Qualifiers are set to Open, receive audio is gated to the WL2 wireline port or to the speaker, regardless of the RF input level. The preferred SINAD measurement port is the WL2 wireline port; however, the speaker can also be used.

When measuring SINAD, the pre-emphasis and high pass filters are set as they would be for analog voice operation. Because the channel characteristics are different, this procedure allows for CSQ Alignment and is done for both 12.5 kHz and 25 kHz channel bandwidth. If the station is configured for only one channel bandwidth, there is no need to perform a CSQ Alignment for the other bandwidth.

See “**Base Radio Service Help → Service Screens → Alignment Screens**” in the *CSS Online Help* for the alignment procedures.

**5.4**

## Rx Wireline Alignment

Rx Wireline Alignment is used only for a receiver that processes analog receive audio and is connected with a 2- or 4-wire link to a console or a comparator in an analog only topology or an ASTRO® 25 Analog/Mixed mode topology.

See “**Base Radio Service Help → Service Screens → Alignment Screens**” in the *CSS Online Help* for the alignment procedures.

**5.5**

## Tuning a Preselector

The optional VHF or UHF preselector assembly is mounted on the back of a receiver. The preselector assembly is a 3-pole (UHF) or a 5-pole (VHF) bandpass filter equipped with tuning slugs to adjust the passband corresponding to the operating frequencies of the receiver. If the preselector assembly is replaced in the field, or if the receiver operating frequencies are modified, the preselector must be field tuned.



**IMPORTANT:** Tuning for best SINAD or Bit Error Rate (BER) response DOES NOT result in optimum tuning of the preselector assembly. Use this field tuning procedure to obtain optimum preselector performance.

The following test equipment is required to properly tune the preselector assembly:

- RF Signal Generator - Aeroflex 3900 Series Service Monitor (or equivalent)
- Dip/peak Monitor - HP435B Powermeter (or equivalent) with an HP8484A sensitive power head, Boonton Model 92E with BNC input, or Aeroflex 3900 Series Service Monitor using the spectrum analyzer function
- Torque driver capable of delivering 12 in-lb of torque and 10 mm deep well socket
- Tuning probe - Motorola Solutions Part No. 3082059X01, p/o TRN4083A tuning kit
- Flat-blade screwdriver



**NOTICE:** An R2600 Communications Analyzer can both generate and measure simultaneously. A service monitor may be used for either the generator or the monitor function, but not both simultaneously. When using service monitor as the signal generator, RF signal must be taken from the antenna port.

### 5.5.1

## VHF Tuning Procedures

VHF tuning procedures include the following:

- [Calculating Proper VHF Alignment Frequency on page 140](#)
- [Preparing the Equipment for VHF Alignment on page 141](#)
- [Tuning The VHF Preselector on page 141](#)

#### 5.5.1.1

### Calculating Proper VHF Alignment Frequency

Use either [Calculating The VHF Alignment Frequency For a Single Receive Frequency on page 140](#) or [Calculating The VHF Alignment Frequency for Multiple Receive Frequencies on page 141](#) to calculate the VHF alignment frequency generated by the signal generator.

#### 5.5.1.1.1

### Calculating The VHF Alignment Frequency For a Single Receive Frequency

**When and where to use:** For a receiver with a single receive frequency, calculate the frequency of the alignment signal as follows:

#### Procedure:

- 1 From the site documentation or the Configuration/Service Software (CSS), determine the receive frequency.
- 2 If the frequency is 148 MHz or 156 MHz, subtract 250 kHz. Otherwise, note the actual frequency.

**Step example:** If the receive frequency is 138.575 MHz, subtract 250 kHz because the frequency is less than 148 MHz: 138.575 MHz – 250 kHz =138.325 MHz.

- 3 If the preselector is Range 1 (136–154 MHz), determine the alignment frequency as follows:  
If frequency (from Step 2) is > 152 MHz, alignment frequency = 152 MHz.  
Otherwise, use actual frequency from Step 2.
- 4 If the preselector is Range 2 (150–174 MHz), determine the alignment frequency as follows:

If the frequency (from Step 2) is < 152 MHz, alignment frequency = 151.075 MHz.

If frequency (from Step 2) is > 172 MHz, alignment frequency = 172 MHz.

Otherwise, use actual frequency from Step 2.

#### 5.5.1.1.2

### Calculating The VHF Alignment Frequency for Multiple Receive Frequencies

**When and where to use:** For receiver with multiple receive frequencies, calculate the frequency of the alignment signal as follows:

**Procedure:**

- 1 From the site documentation or the Configuration/Service Software (CSS), note the receive frequency for each channel.
- 2 Calculate a midpoint frequency as follows:  
$$F_{\text{mid}} = (F_{\text{highest}} + F_{\text{lowest}}) \div 2$$
- 3 Using  $F_{\text{mid}}$  in place of the receive frequency, perform steps 3 and 4 from [Calculating The VHF Alignment Frequency For a Single Receive Frequency on page 140](#).

#### 5.5.1.2

### Preparing the Equipment for VHF Alignment

Perform the following procedure to prepare the equipment for VHF alignment.

**Procedure:**

- 1 Ensure the receiver (with preselector assembly) is installed in a functional station cage equipped with a power supply module.
- 2 Detune the preselector as follows:
  - a If the alignment frequency (calculated in [Calculating The VHF Alignment Frequency For a Single Receive Frequency on page 140](#) or [Calculating The VHF Alignment Frequency for Multiple Receive Frequencies on page 141](#)) is greater than 148 MHz (Range 1) or 156 MHz (Range 2), turn the five tuning screws clockwise until 1/8 inch protrudes past each of the tension nuts.
  - b If the alignment frequency is less than or equal to 148 MHz (Range 1) or 156 MHz (Range 2), turn the five tuning screws counterclockwise until 3/4 inch protrudes past each of the tension nuts.
- 3 Using the torque driver and deep well socket, tighten the five tension nuts on the adjustment screws to 6 in-lb.
- 4 See [Figure 45: Preselector Tuning — VHF on page 142](#).


#### 5.5.1.3

### Tuning The VHF Preselector



**NOTICE:** When tuning for peak or dip, turn the tuning screw 1/2 turn past the peak or dip to verify that you have obtained a true peak or dip. After you have found true peak or dip, turn the screw back to the location of the original peak or dip.

See the figure for the location of the tuning screws and cavity probe holes.

**Figure 45: Preselector Tuning — VHF****Procedure:**

- 1 Turn the receiver power supply **ON** (to provide a 50 Ohm termination).
- 2 Adjust the signal generator to the frequency calculated in [Calculating The VHF Alignment Frequency For a Single Receive Frequency on page 140](#) or [Calculating The VHF Alignment Frequency for Multiple Receive Frequencies on page 141](#). Set the level to +5 dBm.
- 3 Insert tuning probe into cavity H1 and adjust tuning screw 1 for a **PEAK**.
- 4 Leave tuning probe in cavity H1 and adjust tuning screw 2 for a **DIP**.
- 5 Insert tuning probe into cavity H2 and adjust tuning screw 3 for a **DIP**.
- 6 Insert tuning probe into cavity H3 and adjust tuning screw 4 for a **DIP**.
- 7 Insert tuning probe into cavity H4. Decrease output from the signal generator to -5 dBm.
- 8 Adjust tuning screw 5 for a **DIP**. Then turn tuning screw 5 an additional 1/4 turn counterclockwise. (**DIP** is not as sharp for screw 5 as it was for screws 2 through 4.)

**5.5.2****UHF Tuning Procedures**

UHF tuning procedures include the following:

- [Calculating Proper UHF Alignment Frequency on page 143](#)
- [Preparing the Equipment for UHF Alignment on page 144](#)
- [Tuning The UHF Preselector on page 144](#)

### 5.5.2.1

## Calculating Proper UHF Alignment Frequency

Use either [Calculating The UHF Alignment Frequency For a Single Receive Frequency on page 143](#) or [Calculating the UHF Alignment Frequency for Multiple Receive Frequencies on page 143](#) to calculate the alignment frequency generated by the signal generator.

### 5.5.2.1.1

## Calculating The UHF Alignment Frequency For a Single Receive Frequency

**When and where to use:** For receiver with a single receive frequency, calculate the frequency of the alignment signal as follows:

### Procedure:

- 1 From the site documentation or the Configuration/Service Software (CSS), determine the receive frequency. **Add 200 kHz.**
- 2 If the frequency is 380–435 MHz, determine the alignment frequency as follows:  
If frequency (from Step 1) is >431 MHz, alignment frequency = 431 MHz.  
If frequency (from Step 1) is <382 MHz, alignment frequency = 382 MHz.  
Otherwise, use actual frequency from Step 1.
- 3 If the frequency is 435–470 MHz, determine the alignment frequency as follows:  
If the frequency (from Step 1) is >468 MHz, alignment frequency = 468 MHz.  
If frequency (from Step 1) is <440 MHz, alignment frequency = 440 MHz.  
Otherwise, use actual frequency from Step 1.
- 4 If the frequency is 470–524 MHz, determine the alignment frequency as follows:  
If the frequency (from Step 1) is >518 MHz, alignment frequency = 518 MHz.  
If frequency (from Step 1) is <472 MHz, alignment frequency = 472 MHz.  
Otherwise, use actual frequency from Step 1.

### 5.5.2.1.2

## Calculating the UHF Alignment Frequency for Multiple Receive Frequencies

**When and where to use:** For receiver with multiple receive frequencies, calculate the frequency of the alignment signal as follows:

### Procedure:

- 1 From the site documentation or the Configuration/Service Software (CSS), note the receive frequency for each channel.
- 2 Calculate a midpoint frequency as follows:  
$$F_{\text{mid}} = (F_{\text{highest}} + F_{\text{lowest}}) \div 2$$
- 3 Using  $F_{\text{mid}}$  in place of the receive frequency, perform steps 1 through 4 from [Calculating The UHF Alignment Frequency For a Single Receive Frequency on page 143](#).

## 5.5.2.2

**Preparing the Equipment for UHF Alignment**

Perform the following procedure to prepare the equipment for UHF alignment.

**Procedure:**

- 1 Ensure the receiver (with preselector assembly) is installed in a functional station cage equipped with a power supply module.
- 2 Using the torque driver and deep well socket, loosen the three tension nuts on the adjustment screws.
- 3 Detune the preselector by turning tuning screws 3 and 4 clockwise until they bottom out. Be careful not to apply more than 3 in-lb of torque to prevent warping preselector cover and housing.
- 4 See [Figure 46: Preselector Tuning — UHF on page 144](#).


## 5.5.2.3

**Tuning The UHF Preselector**

**NOTICE:** When tuning for peak or dip, turn the tuning screw 1/2 turn past the peak or dip to verify that you have obtained a true peak or dip. After you have found true peak or dip, turn the screw back to the location of the original peak or dip.

See the figure for the location of the tuning screws and cavity probe holes.

**Figure 46: Preselector Tuning — UHF**

**Procedure:**

- 1 Turn the power supply **ON** (to provide a 50 Ohm termination).
- 2 Adjust the signal generator to the frequency calculated in [Calculating The UHF Alignment Frequency For a Single Receive Frequency on page 143](#) or [Calculating the UHF Alignment Frequency for Multiple Receive Frequencies on page 143](#). Set the level to +5 dBm.
- 3 Insert the tuning probe into cavity U2 and adjust tuning screw 2 for a **PEAK**.

- 4 Tighten the tension nut on tuning screw 2 to at least 12 in-lb and fine-tune tuning screw 2 for a **PEAK**.
- 5 Keep the tuning probe in cavity U2 and adjust tuning screw 3 for a **DIP**.
- 6 Tighten the tension nut on tuning screw 3 to at least 12 in-lb and fine-tune tuning screw 2 for a **DIP**.
- 7 Insert tuning probe into cavity U3. Decrease output from the signal generator to  $-5$  dBm.
- 8 Adjust tuning screw 4 for a **DIP**.
- 9 Tighten the tension nut on tuning screw 4 to at least 12 in-lb and fine-tune tuning screw 4 for a **DIP**.

## 5.6

## Testing the GPW 8000 Receiver Performance with a Service Monitor

Use the service monitor to test and measure the receive characteristics of the receiver. The Service Monitor may be connected to a receiver to perform tests and measurements designed to determine whether the equipment is operating within specifications.

The sections that follow contain procedures performed when you first set up your system, and can be scheduled on a regular basis as part of the maintenance policies of your organization.

## 5.6.1

### Deviation Standards (Digital Operation)



**NOTICE:** These specifications allow a tolerance of  $\pm 10\%$ . However, because the accuracy of the service monitor is only  $\pm 5\%$ , the allowable tolerance in the measured deviation is  $\pm 5\%$  and not  $\pm 10\%$ .

Table 30: Deviation Standards for ASTRO 25 System Test Patterns

Signal	Minimum Deviation	Nominal Deviation	Maximum Deviation
low signal deviation	0.84 kHz	0.93 kHz	1.02 kHz
sow signal wide pulse deviation	undetermined	1.00 kHz	undetermined
standard deviation	2.55 kHz	2.83 kHz	3.11 kHz
standard wide pulse deviation	undetermined	3.00 kHz	undetermined
V.52 deviation	2.91 kHz	3.23 kHz	3.55 kHz
V.52 wide pulse deviation	undetermined	3.00 kHz	undetermined
C4FM deviation	2.91 kHz	3.23 kHz	3.55 kHz
C4FM wide pulse deviation	undetermined	3.00 kHz	undetermined
GNSS test pattern - simulcast	undetermined	3.00 kHz	undetermined
ASTRO® 25 system voice	3.24 kHz	3.60 kHz	3.96 kHz
ASTRO® 25 system wide pulse	undetermined	3.00 kHz	undetermined

## 5.6.2

## Monitoring the Power Supply Module


Perform the following procedure to monitor the power supply.

**Procedure:**

- 1 Connect to the receiver in Configuration/Service Software (CSS) through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 From the menu, select **Service** → **Metering Screens**.

The **Metering Screen** window opens on the **Power Supply** tab.

**Figure 47: Metering Screen Window**



**NOTICE:** If a transceiver is installed only in the top slot of the chassis, the power supply meters display **N/A** because the top slot cannot manage the power supply.

## 5.6.3

## Verifying Receiver Performance (Digital Operation)

**When and where to use:** Use this procedure to verify receiver performance by measuring the Bit Error Rate (BER) and Received Signal Strength Indication (RSSI) for digital operation.

**Procedure:**

- 1 Connect to the transceiver module in Configuration/Service Software (CSS) through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 From the menu, select **Service** → **Test And Measurement Screen**.
- 3 Select the **ASTRO BER RSSI Report** tab.
- 4 Make the following connections to the receiver:
  - a Disconnect the BNC antenna cable (or N connector if preselector is present) from the receive Antenna Port.
  - b Connect the service monitor GEN port to the receiver Antenna Port.
- 5 Set up the service monitor:
  - a Set modulation to Project 25 (C4FM) (with a Standard 1011 or 1031) test pattern.
  - b Set the service analyzer to generate at the receive frequency.
  - c Set the RF level an initial value of -47 dBm.

- 6 If the receiver is not already in service mode perform the follows substeps, otherwise go to [step 7](#).
  - a Click **Change to Service Mode**.
  - b At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.
  - c Re-open the **Test And Measurement Screen** as described in [step 2](#).
- 7 Set up the test in CSS:
  - a From the **Pattern Type** field, select **Project 25**.
  - b Enter the number of required seconds from the **Sampling Period (sec)** list box.

The time specifies the window over which the BER is calculated.
- 8 Measure the BER and RSSI:
  - a Click **Start BER Measurement**.

The **Test And Measurement Screen** dialog box displays the following results:

    - BER results in percentage
    - RSSI results expressed in dBm

 **NOTICE:** With the initial setting of the service monitor set for a carrier level of -47 dBm, expect a BER of 0.0 % and an RSSI level between -49 dBm and -45 dBm. Compensate for the loss of the cable connecting the service monitor to the receiver. If the receiver is inhibited, RSSI displays a meaningless value.
  - b To create a log file for the BER and RSSI measurement, click **Start Log**.

The **Log Save As** window appears.
  - c Change the RF level and read the BER and RSSI again at the level appropriate for the receiver. The value should be less than 5%. See [GPW 8000 Receiver Specifications on page 41](#) for the appropriate value.
  - d To stop the test, click **Stop BER Measurement**.
- 9 If no further testing is needed, place the receiver in Normal Mode.
  - a Click **Change to Normal Mode**.
  - b At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.
- 10 Remove and restore the following connections to the receiver:
  - a Remove the service monitor GEN port connection from the Antenna Port.
  - b Restore the antenna connection to the Receive Antenna Port.

#### 5.6.4

### Verifying Receiver Performance (Analog Operation)

#### When and where to use:

Use this procedure to verify receiver performance by measuring the receiver sensitivity (SINAD) for an analog GPW 8000 Receiver.



**NOTICE:** This procedure uses an internal SINAD in the receiver. If a field technician chooses to use a service monitor as an external SINAD meter, see “SINAD Measurement Procedure (measured by Service Monitor)” in the **Base Radio Service Help** → **Service Screens** → **Alignment Screens** → **Carrier Squelch Alignment** tab in the **CSS Online Help**.

**Procedure:**

- 1 Connect to the transceiver module in Configuration/Service Software (CSS) through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 From the menu, select **Service** → **Alignment Screens**.
- 3 If the receiver is not already in Service Mode perform the following substeps, otherwise go to [step 4](#).
  - a Click **Change to Service Mode**.
  - b At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.
  - c Re-open the **Alignment Screen** by selecting **Service** → **Alignment Screens** from the menu.
- 4 Select the **Carrier Squelch Alignment** tab.
- 5 Make the following connections to the receiver:
  - a Disconnect the BNC antenna cable or N connector if a preselector is present from the Receive Antenna Port.
  - b Connect the service monitor GEN port to the receiver Antenna Port with a BNC connector.
- 6 Set up the service monitor.
  - a For 25 kHz channels, set the modulation to 1 kHz tone at 3 kHz deviation.
  - b For 12.5 kHz channels, set the modulation to 1 kHz tone at 1.5 kHz deviation.
  - c Set the service monitor to generate at the receive frequency.
  - d Set the RF level an initial value of –80 dBm.
- 7 To measure 25 kHz channel SINAD, click **25 kHz**. To measure 12.5 kHz channel SINAD, click **12.5 kHz**.
- 8 Select the **SINAD measurement** box.
- 9 Click **Start SINAD Measurement**.

The **SINAD Measurement Value** box displays wait, and after 10 seconds starts to display the SINAD results in dB.



**NOTICE:** With the initial setting of the service monitor, set for a carrier level of –80 dBm, expect a SINAD of >26 dB. Compensate for the loss of the cable connecting the service monitor to the receiver. If the receiver is inhibited, SINAD displays a meaningless value.

- 10 Change the service monitor RF level and read the SINAD again until the value is 12 dB.

**NOTICE:** When the SINAD value is close to 12 dB, wait 10 seconds after changing the RF signal generator level. The receiver needs 10 seconds to stabilize the SINAD measurement. Compensate for the loss of the cable connecting the service monitor to the receiver.
- 11 Record the signal generator RF level. Compare this value to the sensitivity specifications. See [GPW 8000 Receiver Specifications on page 41](#) for the appropriate value.
- 12 To stop the measurement, click **Stop SINAD measurement**.

**13** Unselect the **SINAD measurement** box.

**14** If no further testing is needed, place the receiver in Normal Mode:

- a** Click **Change to Normal Mode**.
- b** At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.

**15** Remove and restore the following connections to the receiver:

- a** Remove the service monitor GEN port connection from the Antenna Port.
- b** Restore the antenna connection to the Receive Antenna Port.

#### 5.6.5

### Checking Receiver Sensitivity (Self-Test Method) (IV and D)

#### When and where to use:

Use this procedure to check the receiver sensitivity for the station without any test equipment. The receiver uses a factory calibrated low-level noise source at the receiver input to check performance. This procedure can be performed remotely.

#### Procedure:

**1** Connect to the transceiver module in Configuration/Service Software (CSS) through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 121](#).

**2** From the menu, select **Service** → **Test And Measurement Screen**. Select the **ASTRO BER RSSI Report** tab.

**3** If the receiver is not already in Service Mode perform the following substeps, otherwise go to [step 4](#).

- a** Click **Change to Service Mode**.
- b** At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.

- c** Re-open the **Test And Measurement Screen** as described in [step 2](#).

**4** Click **Start Receiver Test**.

A confirmation dialog box appears indicating test progress. After a few seconds, the test concludes with a pass or fail message.

**5** Click **OK**.

**6** If no further testing is needed, place the receiver in Normal Mode, as follows:

- a** Click **Change to Normal Mode**.
- b** At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.

This page intentionally left blank.

## Chapter 6

# GPW 8000 Receiver Maintenance

This chapter describes periodic maintenance procedures relating to the GPW 8000 Receiver.

### 6.1

## Fan Grill Cleaning Instructions

If the station equipment is installed in a dusty environment, take precautions to filter the air used for a forced cooling of the station. Excessive dust drawn across and into the device circuit modules by the cooling fans can adversely affect heat dissipation and circuit operation. In such installation, be sure to clean or replace external filtering devices periodically.

If dust has accumulated on the fan grills, cleaning the fan grills is recommended. When cleaning, take care to prevent dust from being pulled into the modules. Use a damp cloth to wipe the front of the fan grills. When removing the power supply, turn off the unit before proceeding.

### 6.2

## Aligning the Internal Frequency Reference Oscillator



**NOTICE:** The receiver must be turned on for at least one week before the internal frequency reference oscillator is aligned. Reference Oscillator Alignment is not required for GPB 8000 Reference Distribution Modules with Trunked GPW 8000 Receivers in Receive-Only Remote Sites.

See “**Base Radio Service Help → Service Screens → Alignment Screens**” in the *CSS Online Help* for the alignment procedures.

This page intentionally left blank.

## Chapter 7

# GPW 8000 Receiver Operation

This chapter details tasks performed after the GPW 8000 Receiver is installed and operational on your system.

### 7.1

## GPW 8000 Receiver Operational States for Trunked Simulcast

GPW 8000 Receiver modules can be in any one of the following four operational states:

- Standby
- Idle
- Assigned
- Isolated

During initialization, the receiver powers up into the **standby** state and waits for a status packet from the comparator. When initial contact with the comparator has been made, the receiver enters **idle** mode. The receiver sends a status message back to the comparator indicating that it is ready for the assignment.

After a receiver has been **assigned**, it can begin to handle inbound traffic. In the case where the receiver fails to receive status packets from the comparator, it enters **isolated** mode and dekeys. This isolated mode is reported in the Unified Event Manager (UEM).

If the receiver becomes operational again, and receives the status packets from the comparator, it again replies with a channel status message. The receiver returns to the idle state and is ready for an assignment from the comparator.

### 7.2

## GPW 8000 Receiver Conventional Operational States

A GPW 8000 Receiver can be in one conventional operational state:

- Standby/Receiving

During initialization, the receiver powers up into the **standby/receiving** state and is enabled for service. The receiver listens for any received transmissions.

#### 7.2.1

### Packet Data Interactions with Multiple NACs

If a receiver supports multiple Network Access Codes (NACs), such as when using the community receiver feature (F7F/F7E), in addition to a default NAC, inbound data can be received on any incoming NAC.

#### 7.2.2

### Supplementary Signaling Interactions with Multiple NACs

If a receiver supports multiple Network Access Codes (NACs), such as when using the community receiver feature (F7F/F7E), in addition to a default NAC, inbound supplementary signaling can be received on any incoming NAC.

## 7.3

## Illegal Carrier Determination Feature (Trunked)

The Illegal Carrier Determination feature allows receiver channels to continue operating with system-configurable levels of channel interference. In an ASTRO® 25 system, the receiver uses Received Signal Strength Indicator (RSSI), an RF Threshold Value, and the Malfunction Timer Value to implement this feature.

Table 31: Illegal Carrier Determination

If the channel receives a... and is assigned:	and is not assigned:
Valid Network Access Code (NAC)	The receiver does not change since the carrier is considered valid.  If the RF Threshold Value is exceeded, the receiver enters the Illegal Carrier state and generates an Illegal Carrier message to Unified Event Manager (UEM).
Invalid Network Access Code (NAC) OR Carrier activity without NAC	If the RF Threshold Value level is exceeded, the Malfunction Timer Value is activated. After the timer expires, the receiver enters the Illegal Carrier state and generates an Illegal Carrier message to UEM.  If the illegal carrier disappears or drops below the RF Threshold Value for 12.5%, but not less than 10 seconds of the time period defined by the Malfunction Timer Value, an event is sent to UEM.

## 7.4

## RF Channel Interference Determination Feature (Conventional)

The RF Channel Interference Determination Feature allows radio channels to detect RF interference and log it to the station log. RF Channel Interference is declared when the Carrier Squelch level is exceeded and none of the receive qualifiers are met. Receive qualifiers are the programmed Private Line (PL), Digital Private Line (DPL), or receive Network Access Code (NAC) for the currently active channel.

## Chapter 8

# GPW 8000 Receiver Troubleshooting

This chapter provides fault management and troubleshooting information relating to the GPW 8000 Receiver.

GPW 8000 Receiver troubleshooting requires an understanding of hardware-based and software-based diagnostics, as well as testing tools. Support is available from Motorola Solutions to assist with all steps in the troubleshooting process.

8.1

## GPW 8000 Receiver General Troubleshooting

Table 32: GPW 8000 Receiver General Troubleshooting

Problem	Troubleshooting
General connectivity problems	<ol style="list-style-type: none"><li>1 If you have access to the equipment, check the LEDs to verify that each piece of equipment is connected and operational. See <a href="#">GPW 8000 Receiver LEDs on page 191</a>.</li><li>2 In Configuration/Service Software (CSS), check the condition of the receiver and all associated devices and links.</li><li>3 Verify the receiver configuration through CSS. Verify that the IP address for the receiver is correct. In CSS, send a diagnostic command to enable the receiver.</li><li>4 For a conventional receiver, verify that the DNS Hostname for the receiver is correct. If the DNS Hostname was incorrect and then corrected, further corrections may be needed on the DNS server, UNC, and UEM. See the Troubleshooting chapter in the <i>Authentication Services</i> manual.</li><li>5 Verify that the receiver Domain Name Services (DNS) Hostname is correct. If the DNS Hostname was incorrect and then corrected, further corrections may be needed on the DNS server, Unified Network Configurator (UNC), and Unified Event Manager (UEM). See the Troubleshooting chapter in the <i>Authentication Services</i> manual.</li><li>6 Verify that the physical cabling is firmly connected and in good condition. Check for any sharp bends or kinks in cabling. Test suspected cabling for noise, continuity, attenuation, and crosstalk. Replace the cabling if necessary.</li><li>7 Run ping, traceroute, pathping, and other network administration commands to identify any link or intermediate devices (switch or routers) with high latency or connection problems.</li><li>8 If the connection fails to operate normally, send a restart command to the receiver through CSS. Consider cycling power to the receiver if necessary.</li></ol>

*Table continued...*

Problem	Troubleshooting
	<p><b>9</b> If it still fails to operate properly, create a backup of the current configuration, then reinstall the software and reconfigure the receiver.</p> <p><b>10</b> Replace the receiver if necessary.</p>
Device does not power up	<p><b>1</b> If you have access to the equipment, check the LEDs to determine which equipment is connected and operational. See <a href="#">GPW 8000 Receiver LEDs on page 191</a>.</p> <p><b>2</b> Check the power cabling and verify that the power source for the receiver is supplying the appropriate voltage. Try connecting the receiver to another power source or replace the power cabling if necessary.</p> <p> <b>NOTICE:</b> Check all power sources as there may be more than one.</p> <p><b>3</b> Check for any physical damage to the modules and check whether the modules were properly grounded.</p> <p><b>4</b> Replace any defective modules.</p>
Device is in a continuous reset state	Assure reference inputs are connected to the appropriate input.
Analog (4-wire) Portion of V.24 Hybrid Link Failure	<p>In a mixed mode configuration, with hybrid links, and when analog link monitor tone is enabled (Analog Link Idle Check is enabled in the CSS), the receiver detects a link failure when the analog link monitor tone and call activity are absent on the receive line (WL1). Disable Analog Idle Link Check in the CSS when the comparator type is ASTRO-TAC with DIGITAC or ASTRO-TAC with MLC 8000. When these failure conditions are met, the receiver:</p> <p><b>1</b> Logs an occurrence of the failure in the local event log. This log is retrievable through the configuration interface.</p> <p><b>2</b> If connected to centralized fault management equipment (optional), transmits an alarm indication to the fault manager to alert the system administrator of the failure.</p> <p><b>3</b> A local visual indication is active due to this failure.</p> <p>Recovery of the link failure results in a similar set of actions to indicate that the failure event cleared.</p> <p> <b>NOTICE:</b> A failure of the transport line or a failure of the opposing host on the wireline link both appear to the receiver as a link failure. The receiver cannot distinguish between these two cases.</p>
V.24 Portion of Hybrid Link Fails	<p>In a mixed-mode configuration, with hybrid links, the receiver detects a V.24 link failure when packet activity is absent for a time on the outbound transmit line. When these failure conditions are met, the receiver:</p> <p><b>1</b> Logs an occurrence of the failure in the local event log. This log is retrievable through the configuration interface.</p> <p><b>2</b> If connected to centralized fault management equipment (optional), transmits an alarm indication to the fault manager to alert the system administrator of the failure.</p>

*Table continued...*

Problem	Troubleshooting
	<p>3 A local visual indication is active due to this failure.</p> <p>4 Invokes a failure announcement for the 4-wire link because control signaling on the V.24 link drives activity on the 4-wire link. A 4-wire link cannot be used when the V.24 link is down.</p> <p>Recovery of the link failure results in a similar set of actions to indicate that the failure event cleared.</p> <p> <b>NOTICE:</b> A failure of the transport line or a failure of the opposing host on the wireline link both appear to the receiver as a link failure. The receiver cannot distinguish between these two cases.</p>
Transceiver Option Card Hardware Malfunction	<p>In the event the receiver detects a hardware issue with the transceiver option card, when used for analog and mixed mode operation, it:</p> <ol style="list-style-type: none"> <li>1 Logs an occurrence of the failure in the local event log. This log is retrievable through the configuration interface.</li> <li>2 If connected to centralized fault management equipment (optional), transmits an alarm indication to the fault manager to alert the system administrator of the failure. The alarm is associated with the receiver control module.</li> <li>3 A local visual indication is active due to this failure.</li> </ol>
Front Fan Malfunction	<p>In the event the fan assembly malfunctions, the receiver:</p> <ol style="list-style-type: none"> <li>1 Logs an occurrence of the failure in the local event log. This log is retrievable through the configuration interface.</li> <li>2 If connected to centralized fault management equipment (optional), transmits an alarm indication of “warning” severity to the fault manager to alert the system administrator of the failure. The alarm is associated with the receiver control module.</li> <li>3 Provides a local visual indication associated with the failure.</li> <li>4 If the receiver detects the maximum operable temperature has been exceeded, it transitions to a critical malfunction state, logs the state change, and generates a fault indication if connected to the UEM.</li> </ol>
Power Consumption is greater than 35 W with power efficiency package	<p>The following conditions must be met to obtain a power consumption of less than or equal to 35 W:</p> <ul style="list-style-type: none"> <li>• DC source only</li> <li>• Speaker turned OFF (if equipped with a transceiver option card)</li> <li>• No activation of Aux Out Relays (if equipped with a transceiver option card)</li> <li>• No 29 V AUX loads. For example, active draws by a site controller</li> <li>• No 29 V AUX loads. For example, active draws by a Reference Distribution Module (RDM) or gateways</li> <li>• CSS configured for applications not requiring receiver diversity</li> <li>• Ambient temperature of 104 °F (40 °C) or less (single fan operation – disabling one of the fans within the fan module. See <a href="#">Replacing the</a></li> </ul>

Table continued...

Problem	Troubleshooting
	<p>Fan Assembly on page 177 for instructions on how to disable the fan.)</p> <p> <b>NOTICE:</b> To validate the 35 W standby power consumption specification, wait for the main fans to turn off.</p> <ul style="list-style-type: none"> <li>Transceiver, power supply, fan, and optional TCXO transceiver option card are all power efficiency package versions</li> </ul>
<p>The GPW 8000 reports an unexpected fault for the power supply. For a multi-site GPW 8000 Receiver, the fault may be reported at a Major Failed or Critical Failed severity, which causes the device to be taken out of service.</p>	<p>A GEN 1 transceiver is incorrectly installed in the bottom slot of the dual-slot chassis with AUX PWR IN connected. The GEN 1 transceiver hardware does not support detection of the AUX PWR IN, may incorrectly report Power Supply Faults, and may go out of service.</p> <p>Corrective Action:</p> <ol style="list-style-type: none"> <li>Install the GEN 1 transceiver in the top slot of the dual-slot chassis. See <a href="#">Replacing a GPW 8000 Receiver Transceiver Module on page 171</a>. This action may be taken only for release 7.14 or later.</li> <li>Confirm that the power supply in the chassis is operational, and then disconnect the AUX PWR IN from the chassis.</li> </ol>
<p>The transceiver reports on the <b>CSS Status Panel</b> screen, that the power supply state is Shared, rather than reporting the actual chassis power supply state of Operational (multi-site GPW 8000 Receiver), AC or DC Power (Conventional GPW 8000 Receiver), or Failed (either multi-site or Conventional GPW 8000 Receiver)</p>	<p>A transceiver is installed in the top slot of the dual-slot chassis, but no transceiver is installed in the bottom slot.</p> <p>Connect the CSS to the bottom slot transceiver to verify the chassis power supply state.</p>
<p>Unable to perform a password reset</p>	<p>If the device module has been replaced and serial port access is not available to configure the IP address, the device may have the account locked out or the backplane slot has passwords enabled. Connect to the front-panel local Ethernet service port using a fixed IP address and perform the password reset.</p> <p>See <a href="#">Connecting Through an Ethernet Port Link on page 121</a> and <a href="#">Setting the Local Password Configuration in CSS on page 131</a>.</p>

## 8.2

## GPW 8000 Receiver Troubleshooting Tools

Several tools are available for viewing and monitoring equipment and troubleshooting suspecting problems:

- LEDs
- Unified Event Manager (UEM) to monitor links and components
- Unified Network Configurator (UNC)

- Configuration/Service Software (CSS)
- MOSCAD Network Fault Management (NFM)



**NOTICE:** The Unified Event Manager (UEM) can be established as a more centralized fault management solution replacing the MOSCAD GMC. See the *Unified Event Manager* and the *UEM GMC MOSCAD Transition Guide* for details.

### 8.2.1

## Links and Components Monitoring in Unified Event Manager

The Unified Event Manager (UEM) monitors critical links and components in the system. Monitoring may take place remotely from a central operations center. Two types of monitoring include:

- Real-time monitoring of UEM Topology Maps, which alert faults as they occur.
- Evaluation of UEM Active Alarms Window on a regularly scheduled basis.

### 8.2.1.1

## Unified Event Manager Active Alarm Window Analyzation

The Unified Event Manager (UEM) **Active Alarms Window** is useful for troubleshooting because it captures alarms that may occur intermittently or during off-hours. For example, you can review the **Active Alarms Window** to correlate reported loss of service with patterns of critical alarms for links and equipment.

When analyzing the **Active Alarms Window**, look for the following patterns:

- Failures sent with time stamps on or about the same time
- Failures from related equipment:
  - Cards in the same device
  - Equipment part of the same subsystem

Many devices send out events that report both critical and non-critical events. Learn to distinguish between critical and non-critical events.

See the *Unified Event Manager* manual or *UEM Online Help* for further details.

### 8.2.1.2

## Diagnostic Options in Unified Event Manager

This table summarizes the receiver diagnostic options in the Unified Event Manager (UEM).

Table 33: Receiver Diagnostic Options in UEM

Option	Description
Restart	Requests that the receiver performs a reset.
Service	Requests that the receiver enters service mode, allowing a technician to make alignment adjustments and run other tests while the receiver is offline.
Enabled	Requests that the receiver enters the enabled mode and handle traffic.

## 8.2.2

**MOSCAD Network Fault Management for GPW 8000 Receiver**

If MOSCAD Network Fault Management (NFM) equipment is supported at the site, additional status and alarm information for a device can be viewed through the MOSCAD NFM.

**Figure 48: MOSCAD Network Fault Management — Tab 1**



**Figure 49: MOSCAD Network Fault Management — Tab 2**



When an alarm condition occurs, the alarm box for one of the modules begins to flash red. Selecting the LED box opens an alarm pop-up window indicating details of the alarm. To view the status of all alarms for a particular module within the device, select the alarm LED box corresponding to the particular module. Alarms can be acknowledged by pressing **Acknowledge** on the screen.



**NOTICE:** Select tab 2 to manage the other transceiver.

See the *MOSCAD Network Fault Management* manual for details.



**NOTICE:** The Unified Event Manager (UEM) can be established as a more centralized fault management solution replacing the MOSCAD GMC. See the *Unified Event Manager* and the *UEM GMC MOSCAD Transition Guide* for details.

#### 8.2.3

### Device Troubleshooting in Unified Network Configurator

Use the Unified Network Configurator (UNC) to verify configuration data during system commissioning and later when you maintain or expand the system. Use UNC to do the following to the device:

- Verify configuration
- Correct configuration errors

See the *Unified Network Configurator* manual for further details.

#### 8.2.4

### GPW 8000 Receiver Troubleshooting in Configuration/Service Software

The GPW 8000 Receiver can be locally or remotely configured or serviced through Configuration/Service Software (CSS). CSS provides access to alarms, status information, and configuration settings for the receiver.

Use CSS for the following tasks which may be useful when troubleshooting the receiver. See the CSS *Online Help* for specific details and instructions when performing these tasks.

- Enable and disable channels and services
- View and save a log of alarms
- Verify the configuration
- Gather troubleshooting information that can be escalated to Motorola Solutions for evaluation

#### 8.2.4.1

### Internal Diagnostic Test Alarm Log

The receiver has been designed with internal diagnostic tests that occur on power up and reset. Diagnostic tests are available for the control module and power supply. If a problem occurs during operation, it is reported as an alarm. All alarms are stored in the Alarm Log, accessible with Configuration/Service Software (CSS). The alarm log contains the name of the diagnostic test that failed and the time since the last power up.

#### 8.2.4.2

### Local Password and SNMPv3 Passphrase Troubleshooting

The password reset mechanism in the Configuration/Service Software (CSS) application can be enabled/disabled. See “Secure Remote Access Configuration > Device Security Configuration - Security Services (Serial)” in the CSS *Online Help* for information. To obtain the keys for resetting either password or SNMPv3 passphrases for the device, contact Motorola Solutions Support Center (SSC).



**NOTICE:** The default values for the local passwords and SNMPv3 passphrases, as well as the keys for the local password reset procedure, may vary by system release. These default values and keys are treated as sensitive information and are provided to your organization through secured communication.

Table 34: Local Password and SNMPv3 Passphrase Troubleshooting

Scenario	SNMPv3 Passphrase Known	Local Password Known	To Reset SNMPv3 Passphrase	To Reset Local Login Password
User is locked out of the local login, but knows SNMPv3 pass-phrases	✓	✗	See the <i>CSS Online Help</i> "SNMPv3 User Configuration".	See the <i>CSS Online Help</i> "Resetting Device Passwords."
User knows the local login, but not the SNMPv3 pass-phrases	✗	✓	See the <i>CSS Online Help</i> "Reset SNMPv3 Configuration (Serial)".	See the <i>CSS Online Help</i> "Device Security Configuration – Security Services (Serial)".
User knows both passphrases and local service password	✓	✓	See the <i>CSS Online Help</i> "SNMPv3 User Configuration".	See the <i>CSS Online Help</i> "Device Security Configuration – Security Services (Serial)".
User does not know SNMPv3 passphrase nor service account password	✗	✗	Contact Motorola Solutions SSC.	Contact Motorola Solutions SSC.

## 8.3

## Motorola Solutions Support Center

Motorola Solutions Support Center (SSC) can help technicians and engineers resolve system problems, and ensure that warranty requirements are met. Check your contract for specific warranty information.

Motorola Solutions assigns a tracking ticket number that identifies each support call. This ticket number allows Motorola Solutions to track problems, resolutions, and activities for the call, and if possible, communicate the resolution and a status of call so that the SSC can note the resolution and close the ticket.

### 8.3.1

### Information Necessary to Contact Motorola Solutions Support Center

Before calling the Motorola Solutions Support Center (SSC), log all steps taken to troubleshoot the problem and any results of those steps. The SSC can use this information to determine the appropriate support actions.

Listed is the following information to collect before calling the SSC:

- System ID number (such as 2CB5). Each zone in the system has a unique system ID number
- Location of the system
- Date the system was put into service
- Software and firmware versions
- Symptom or observation of the problem, such as:
  - When did it first appear?
  - Can it be reproduced?
  - Are there any other circumstances contributing to the problem (for example, loss of power)?
- Maintenance action preceding the problem, such as:
  - Upgrade of software or equipment
  - Changes to hardware or software configuration
  - Reload of software from a backup disk, CD, or DVD with the version and date

Dispatch Support:

- Site ID
- Description of problem
- Severity of issue

Tech Support:

- Site ID
- Billing information (If not being billed under contract)
- Name or model number of product causing the issue (Helps get you over to proper tech support group)

Return Authorization:

- Site ID
- Part Number and/or description of part
- How being billed
- Where it is being billed
- Where it is being shipped

### 8.3.2

## Where to Call for Service

After collecting the required information and writing a detailed problem report, contact the Motorola Solutions Support Center (SSC) to help with the problem.

### 8.3.2.1

## Motorola Solutions Support Center

The Motorola Solutions Support Center (SSC) is the primary Motorola Solutions contact. Call Motorola Solutions SSC:

- Before any software reload
- To confirm troubleshooting results and analysis before removing and replacing a Field Replaceable Unit (FRU) or Field Replaceable Equipment (FRE) to repair the system

Motorola Solutions SSC contact information:

- Phone: (800) 221-7144 for domestic calls and (302) 444-9800 for international calls
- Fax: (847) 725-4073

### 8.3.3

## Subcontractors

The Motorola Solutions Service Subcontractor Assessment program ensures that service people Motorola Solutions contracts meet strict minimum requirements before they can work on any system. For more information on this program, contact the Motorola Solutions representative.

## Chapter 9

# GPW 8000 Receiver FRU and FRE Procedures

GPW 8000 Receivers are composed of numerous Field Replaceable Units (FRUs) and Field Replaceable Entities (FREs). If you must replace a FRU, FRE, or part, obtain the precise FRU/FRE Kit Number or part number. Review the replacement procedures provided, including all safety precautions and system impact information.

This chapter lists the FRUs and FREs, and includes replacement procedures applicable to GPW 8000 Receiver.

## 9.1

## GPW 8000 Receiver Field Replaceable Units and Parts

When ordering Field Replaceable Units (FRUs), provide the FRU Kit Number. When ordering field replaceable parts, provide the part number. Contact Motorola Solutions Support Center (SSC) as needed for numbers not provided here (for cables internal to a GPW 8000 Receiver, the part numbers are not listed in this documentation, but you can locate the part number on the cable before contacting Motorola Solutions SSC). See [Motorola Solutions Support Center on page 162](#).



**WARNING:** To guard against personal injury and/or damage to equipment, switch a trunked receiver to Service Mode when performing service. Switch the receiver back to Normal Mode when service is complete.

Table 35: GPW 8000 Receiver Field Replaceable Units

Component Type	FRU Kit Number	Replacement Procedure
Transceiver Module (700/800 MHz)**	DLN6885A	
Transceiver Module (900 MHz)**	DLN6882A	
Transceiver Module (UHF R1, 380–435 MHz)**	DLN6888A	
Transceiver Module (UHF R2, 435–524 MHz)**	DLN6884A	
Transceiver Module (VHF, 136–174 MHz)**	DLN6892A	<a href="#">Replacing a GPW 8000 Receiver Transceiver Module on page 171</a>
Transceiver Module w/OCXO Transceiver Option Card (700/800 MHz)**	DLN6883A	
Transceiver Module w/OCXO Transceiver Option Card (900 MHz)**	DLN6923A	
Transceiver Module w/OCXO Transceiver Option Card (UHF R1, 380–435 MHz)**	DLN6889A	

*Table continued...*

Component Type	FRU Kit Number	Replacement Procedure
Transceiver Module w/OCXO Transceiver Option Card (UHF R2, 435–524 MHz)**	DLN6886A	
Transceiver Module w/OCXO Transceiver Option Card (VHF 136–174 MHz)**	DLN6893A	
Fan Module	DLN6898A	<a href="#">Replacing the Fan Assembly on page 177</a>
AC/48V DC Power Supply	DLN6781A (0182516W14) or DLN6805A (0182516W20)  (for module compatibility, see <a href="#">Table 37: GPW 8000 Power Supply Compatibility with AUX PWR Connected on page 167</a> )	<a href="#">Replacing a Power Supply on page 178</a>
Power Efficiency AC/48V DC Power Supply	DLN6793B (0182516W19)	

\* Available only for non-simulcast conventional systems.

\*\* The transceiver field replacement units are not compatible with ASTRO® 25 receiver software distributed before July 2013. BEFORE installing the replacement transceiver, ensure that all receivers at the site meet the minimum software version requirements listed. Contact Motorola Solutions SSC at 800-422-4210 if you do not have access to compatible software. See [Transceiver Software and Feature Compatibilities on page 168](#) for details.

Table 36: GPW 8000 Power Supply Compatibility with AUX PWR Not Connected

Power Supply Version	Bottom Slot Transceiver		Top Slot Transceiver	
	GEN 1	GEN 2	GEN 1	GEN 2
0182516W12	Yes	Yes	Yes	Yes
0182516W14	Yes	Yes	Yes	Yes
0182516W15	Yes	Yes	Yes	Yes
0182516W19	Yes	Yes	Yes	Yes
0182516W20	Yes	Yes	Yes	Yes

Table 37: GPW 8000 Power Supply Compatibility with AUX PWR Connected

Power Supply Version	Bottom Slot Transceiver		Top Slot Transceiver	
	GEN 1	GEN 2	GEN 1	GEN 2
0182516W12	No*	Yes	Yes	Yes
0182516W14	No*	Yes	Yes	Yes
0182516W15	No*	Yes	Yes	Yes
0182516W19	No*	Yes	Yes	Yes
0182516W20	No*	Yes	Yes	Yes

\* Receivers are taken out of service when a power supply fails, even with AUX PWR connected.

Table 38: GPW 8000 Receiver Field Replaceable Parts

Component Type	Part Number	Replacement Procedure
Power Supply Fan Module	5985167Y02	Replacing a Power Supply Fan on page 180
GPW 8000 Receiver Backplane	0180706K45	Replacing a GPW 8000 Receiver Backplane on page 182
Preselector 700 MHz	0185171Y02	
Preselector 800 MHz	0185171Y01	
Preselector Mounting Bracket	0785024Y01	
Preselector QMA Cable End	3085664Y01	
Preselector BNC to QMA Cable	3085665Y01	
Preselector Mini UHF N-Bulkhead Cable	3085664Y02	Replacing a GPW 8000 Receiver Preselector Filter and Splitter on page 187
Preselector Mini UHF BNC Cable	3085664Y03	
Preselector UHF 380–433 MHz	CFX1075A	
Preselector UHF 435–470 MHz	TLE5992A	
Preselector UHF 470–524 MHz	TLE5993A	
Preselector VHF 136–154 MHz	TFD6511A	
Preselector VHF 150–174 MHz	TFD6512A	
Splitter	0182017V14	
External Speaker Kit	HSN1006A	
Microphone Kit	GMMN4063B	

Table 39: GPW 8000 Receiver Cabinet Field Replacement Parts

Component Type	Part Number	Replacement Procedure
Static Rail Bracket	07009411001	See Removing/Replacing a Cabinet Door on page 84.
Cabinet, 15 RU, 600D, EIA 19 in.	15009721001	

Table continued...

Component Type	Part Number	Replacement Procedure
Cabinet Door, 15 RU	15009728001	
Rodent Proof Grommet for 3.5 in. Hole	15009729001	
Cabinet, 24 RU, 600D EIA 19 in.	15009721002	
Cabinet Door, 24 RU	15009728003	
M6 Cage Nut	0285504U05	

Table 40: GPW 8000 Receiver Cables

Component Type	Part Number
System Connector Cable – SCSI2 Receiver to Champ	30009466002
External Speaker Cable	0185180U01
Cable DC Red/Black 2806mm	30009459002
Cable DC Black/Blue 2806mm	30009459004
Battery Temp Sensor 3000mm	30009478001
Cable Battery Temp Extension 15500mm	30009461003
V.24 or Wireline Cable	30009455002

## 9.2

## Transceiver Hardware Generations

As of July 2013, the GPW 8000 Receiver is shipped with a new generation of transceiver hardware (referred to in this manual as GEN 2). The hardware updates are intended to extend the life of the device as seamlessly as possible. This section details relevant differences and compatibility requirements for GEN 1 and GEN 2 hardware.

### 9.2.1

### Transceiver Software and Feature Compatibilities

The GEN 2 transceiver hardware is backwards compatible and interchangeable with GEN 1 transceiver hardware on ASTRO® 25 7.7 and later systems. GEN 1 transceivers can no longer be ordered; however, spare inventory of GEN 1 transceivers can be used as Field Replaceable Unit (FRU) replacements.

 **NOTICE:** GEN 1 transceivers are supported only in the top slot of the GPW 8000 Receiver dual-slot chassis. GEN 2 transceivers can be used in either top or bottom slots.

All ASTRO® 25 system features are supported on GEN 1 and GEN 2 transceivers, with the following exceptions.

Table 41: System Feature Exceptions

Feature	GEN 1 Transceiver	GEN 2 Transceiver
X2 TDMA	Supported	Not Supported
3600 Operation	Not Supported	Supported

GEN 2 transceiver hardware is not compatible with ASTRO® 25 GPW 8000 Receiver software distributed before July 2013. The transfer operation fails if you perform a software download using a SWDL application released before July 2013.

BEFORE installing a FRU replacement or expansion channel at an existing site, ensure that you are using the latest available SWDL application, and that all base radios and receivers at the site meet the minimum software version requirements listed. Contact Motorola Solutions Support Center (SSC) at 800-422-4210 if you do not have access to compatible software.

Table 42: Minimum Software Download Version Requirements

ASTRO® 25 System Release	HPD	Site Repeater	Multi-Site	Conventional	3600
7.6 and earlier	Not Supported			N/A	N/A
7.7	HPDBR_R07.7X.023	SiteRptrBR_R07.7X.031	MsBR_R07.7X.033	N/A	N/A
7.8	HPDBR_R07.8X.033	SiteRptrBR_R07.8X.038	MsBR_R07.8X.038	N/A	N/A
7.9	HPDBR_R07.9X.049	SiteRptrBR_R07.9X.050	MsBR_R07.9X.051	ConvRptrBR_R07.9X.051	Any Version
7.11	HPDBR_R07.BX.098	SiteRptrBR_R07.BX.102_P2 SiteRptrBR_R07.BX.102_P2	MsBR_R07.BX.102_X2 MsBR_R07.BX.102_P2	ConvBR_R07.BX.100	Any Version
7.12	HPDBR_R07.CX.051	SiteRptrBR_R07.CX.051_X2 SiteRptrBR_R07.CX.051_P2	MsBR_R07.CX.051_X2 MsBR_R07.CX.051_P2	ConvBR_R07.CX.057	Any Version
7.13	HPDBR_R07.DX.073	SiteRptrBR_R07.DX.079_X2 SiteRptrBR_R07.DX.079_P2	MsBR_R07.DX.079_X2 MsBR_R07.DX.079_P2	ConvBR_R07.DX.074	Any Version
7.14 and later	Any Version				



**CAUTION:** It is crucial that a site software download is performed at a trunked ASTRO® 25 site to ensure that all devices are on the same software version, VLAN, and active bank. Failure to perform this step, results in the replacement transceiver or expansion channel to have a mismatch in software versions. If a mismatch in software versions occurs, the transceiver may go into a configuration mode of operation with a reason of 'Invalid Software Version'.

A site software download is not available for conventional or trunked 3600 devices.

## 9.2.2

## Identifying Transceiver Hardware Generation


### Label

GEN 1 and GEN 2 transceiver modules can be identified by examining the physical hardware label. GEN 2 modules have a light blue label with 'GEN 2' clearly noted on it, while GEN 1 modules have a white label with no GEN identification.

**Figure 50: GEN 1 Transceiver Module**



**Figure 51: GEN 2 Transceiver Module**



### Configuration/Service Software

GEN 1 and GEN 2 transceiver modules already installed in a system can be identified through the **Hardware Version** screen of the Configuration/Service Software (CSS).

## 9.2.3

## Transceiver FRU Number Mappings

**Table 43: Transceiver FRU Number Mappings**

Transceiver FRU Number	GEN 1 (Shipped before Nov 2013)	GEN 2 (Shipped starting July 2013)
Transceiver Module (700/800 MHz)	DLN6566A	DLN6885A
Transceiver Module (900 MHz)	DLN6778A	DLN6882A
Transceiver Module w/OCXO Transceiver Option Card (900 MHz)	N/A	DLN6923A

*Table continued...*

Transceiver FRU Number	GEN 1 (Shipped before Nov 2013)	GEN 2 (Shipped starting July 2013)
Transceiver Module w/OCXO Transceiver Option Card (700/800 MHz)	DLN1430A	DLN6883A
Transceiver Module w/OCXO Transceiver Option Card (900 MHz)		DLN6923A
Transceiver Module (UHF R2, 435–524 MHz)	DLN1346A	
Power Efficiency Transceiver Module (UHF R2, 435–524 MHz)	DLN6789A	DLN6884A
Transceiver Module w/OCXO Transceiver Option Card (UHF R2, 435–524 MHz)	DLN1433A	DLN6886A
Power Efficiency Transceiver Module w/TCXO Transceiver Option Card (UHF R2, 435–524 MHz)	DLN6790A	DLN6887A
Transceiver Module (UHF R1, 380–435 MHz)	DLN1395A	
Power Efficiency Transceiver Module (UHF R1, 380–435 MHz)	DLN6786A	DLN6888A
Transceiver Module w/OCXO Transceiver Option Card (UHF R1, 380–435 MHz)	DLN1432A	DLN6889A
Power Efficiency Transceiver Module w/TCXO Transceiver Option Card (UHF R1, 380–435 MHz)	DLN6787A	DLN6890A
Transceiver Module (VHF, 136–174 MHz)	DLN1376A	DLN6892A
Transceiver Module w/OCXO Transceiver Option Card (VHF 136–174 MHz)	DLN1431A	DLN6893A

### 9.3

## Replacing a GPW 8000 Receiver Transceiver Module

This procedure explains how to remove and install a transceiver module in a dual-slot chassis. The chassis may contain one or two transceiver modules.



**NOTICE:** If only one transceiver is used, install it into the bottom slot.

**Figure 52: Transceiver Module**

GTR8000\_XCVR\_wSAC

[Figure 53: GPW 8000 Receiver on page 172](#) shows the captive screws that secure the transceiver module to the dual-slot chassis.

**Figure 53: GPW 8000 Receiver**

GPW\_8000\_receiver\_front\_no\_fan\_A



**NOTICE:** The IP address for the device is available through a serial port connection in Configuration/Service Software (CSS). From the menu, select **Tools** → **Set IP Address**.

**Prerequisites:** Before replacing the transceiver, pull configuration and hardware information from the transceiver into the Unified Network Configurator (UNC) by performing a “Pull All” procedure. See “Scheduling the Pull of Device Configurations” in the *Unified Network Configurator* manual. This step may not be possible if communication is severed between the transceiver and the UNC, or if the transceiver is within a K core or non-networked site.

#### Procedure:

- 1 Wear an Electrostatic Discharge (ESD) strap and connect its cable to a verified good ground.
 

**CAUTION:** Wear the ESD strap throughout this procedure to prevent ESD damage to any components.
- 2 Locate the transceiver module being replaced.
- 3 If the transceiver module is not operational, go to [step 9](#).
- 4 Connect to the transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
- 5 Save the receiver configuration to the service computer/laptop as follows:
  - a From the menu, select **File** → **Read Configuration From Device**.
  - b At the confirmation screen, click **OK**.
  - c When the **Progress Monitor** screen is complete, click **OK**.
  - d From the menu, select **File** → **Save As**.

- e On the **Properties** screen, enter the IP address of the receiver. Click **OK**.
- f On the **Save** window, select the directory where you want to save the configuration file. Type a meaningful name for the file (use .cpl as the extension or do not type an extension). Press **ENTER**.

The receiver configuration is saved to the location indicated. The configuration file is reloaded later to the replacement transceiver.

- 6 For a trunked receiver, place in Service Mode before replacing the module so the system does not attribute the loss of channel to a failure, as follows:



**NOTICE:** It is not necessary to turn off the power supply for the transceiver module being replaced, because the modules can be swapped out with the power on.

- a From the menu, select **Service** → **Test and Measurement Screen**.

The **Test and Measurement Screen** appears.

- b Click **Change to Service Mode**.

- c At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.

- 7 If you choose to turn off the power, set the rocker switch on the front of the associated power supply to the Off (O) position.



**WARNING:** If you chose to turn off the power, disconnect the cable from the AUX PWR IN connector. If not, power is not off entirely.

- 8 Disconnect the Ethernet cable from the service port on the transceiver being replaced.

- 9 Remove the fan assembly to gain access to the transceiver module. See [Replacing the Fan Assembly on page 177](#).



**IMPORTANT:** Although the transceiver module can be swapped out without shutting the power off, minimize the amount of time the fan assembly is removed so the circuitry that remains powered on does not overheat and shut down.

- 10 Label and disconnect all cables from the ports on the transceiver.

- 11 Using a T20 bit, loosen the two captive screws on the front of the transceiver module to disengage them from the chassis.

- 12 Using the handle, gently pull the transceiver module straight out along the guides on which it sits.

- 13 Slide in the replacement transceiver module along the guiding rails until it is engaged. A slight push may be required to securely engage the module.



**NOTICE:** If only one transceiver is used, install it into the bottom slot.

GPW 8000 Receiver GEN 1 transceivers are supported only in the top slot of the dual-slot chassis. GEN 2 transceiver can be used in either top or bottom slots.

The LEDs on the transceiver turn on when it is engaged.

- 14 Using a T20 bit, tighten the two captive screws on the front of the module to secure the transceiver module to the chassis.

- 15 Reconnect all cables to the ports on the transceiver.

- 16 Reinstall the fan assembly. See [Replacing the Fan Assembly on page 177](#).

- 17 If you chose to turn off the power, reconnect the cable to the AUX PWR IN connector, and set the rocker switch on the front of the associated power supply to the On (I) position.

- 18 Perform basic device configuration through the serial port in CSS. See [Connecting Through a Serial Port Link on page 116](#).
  - a Set the IP Address and BR\_CM Pairing Number for the device. See [Setting the Device IP Address and Pairing Number in CSS on page 118](#).
  - b Set the Serial Security Services. See [Setting the Serial Security Services in CSS on page 119](#).
- 19 On systems with MAC Port Lockdown implemented, disable MAC Port Lockdown. The switch port needs to be Unlocked before connecting with CSS or performing a software download. See the MAC Port Lockdown manual for instructions on how to disable MAC Port Lockdown.
- 20 Open the Software Download Manager application, and perform the following:
  - a From the **Advanced Options** menu, select the transfer type.
  - b From the menu, select **File** → **File Manager**.  
The **Software Depot File Manager** opens.
  - c From the menu, select **Component Operations** → **Import Fileset**.  
The **Import a Fileset Into the Software Depot** dialog box appears.
  - d Click **Browse** and search for the `swdlv3.cfg` file, or follow the path: `E:\swdl\swdlv1.cfg` or `swdlv3.cfg`. Click **Open**.  
The file appears in the **Configuration File Path** field of the dialog box.
  - e Click **Generate**. Click **OK**.  
The **Import a Fileset Into the Software Depot** dialog box closes and the software component appears in the **Components In the Software Depot** list of the **Software Depot File Manager** window.
  - f Exit the **Software Depot File Manager**.
- 21 For a conventional device, perform a single device download to transfer and install the latest receiver software in Software Download Manager, as follows:

 **CAUTION:** Load the correct version of the software. A mismatch in software versions may occur when replacing the transceiver module with an on-hand spare. A mismatch in software versions may cause all receivers to go into a configuration mode of operation with a reason of 'Invalid Software Version'. To exit the receiver from the configuration mode, see "CSS Procedures → Changing from Configuration to Normal Mode" in the *CSS Online Help*.

  - a Click **Open Single Device Mode**.
  - b Enter the `<IP address>` of the device. Click **Connect**.  
A **Security Level** screen appears.
  - c Choose the required security level. Click **OK**.
  - d In the **Select an Option** drop down list, select **Upgrade**.
  - e In the **Operation Type** drop down list, select **Transfer and Install**.
  - f In the **Application Type**, select the application to install.
  - g In the **Software Version** drop down list, select the appropriate software version.
  - h In the **Bank Selection** drop down list, select the bank to receive the software. Select **Automatic** to store the software in the bank that is more suitable for the device.
  - i Click **Start Operation**.

j In the window that appears, click **Proceed**.

If the transfer was successful, the progress bar in the **Operation Status** tab displays green. If the transfer failed, the progress bar displays red.

**22** Perform a site software download and installation for a trunked receiver. See [Performing a Site Software Download With GCP 8000 Site Controllers on page 199](#).

A site software download is not available for conventional devices.



**CAUTION:** It is crucial to perform a site software download at the site to ensure that all devices are on the same software version, VLAN, and active bank. Failure to perform this step results in the replacement transceiver or expansion channel to have a mismatch in software versions. If a mismatch in software versions occurs, the transceiver may go into a configuration mode of operation with a reason of 'Invalid Software Version'.

**23** Disconnect the service computer/laptop from the transceiver DB-9 serial port.

**24** Perform basic device configuration through the Ethernet port in CSS. See [Connecting Through an Ethernet Port Link on page 121](#).

a Set the current date and time. See [Setting the Date and Time in CSS on page 124](#).

b Set the local Password Configuration (optional). See [Setting the Local Password Configuration in CSS on page 131](#).



**NOTICE:** An IP address must be configured to set up the local password. If the serial port access is not available to configure the IP address, the transceiver may have the account locked out or the backplane slot has passwords enabled. Connect to the front-panel local Ethernet service port using a fixed IP address to perform the password reset. See [Connecting Through an Ethernet Port Link on page 121](#).

**25** Complete the configuration of the Information Assurance (IA) features in CSS, as follows:

a Change the SNMPv3 configuration and user credentials. See [Changing SNMPv3 Configuration and User Credentials in CSS on page 124](#).

b Create, update, or delete an SNMPv3 user. See [Adding or Modifying an SNMPv3 User in CSS on page 127](#).

c Verify the SNMPv3 credentials. See [Performing an SNMPv3 Connection Verification in CSS on page 127](#).

d Set the Software Download Manager (SWDL) transfer mode. See [Setting the SWDL Transfer Mode in CSS on page 129](#).

e Configure Domain Name Services (DNS). See "Configuring DNS with CSS" in the *Authentication Services* manual.

f Configure for Secure SHell (SSH). See "Configuring SSH for Devices at an RF Site" in the *Securing Protocols with SSH* manual or see "Device Security Configuration – Remote Access/Login Banner (Ethernet)" in the *CSS Online Help*.



**NOTICE:** Restore the Clear Protocols parameters.

g Enable RADIUS Authentication. See "Configuring RADIUS Sources and Parameters with CSS" in the *Authentication Services* manual.

h Enable Centralized Authentication. See "Enabling/Disabling Centralized Authentication with CSS" in the *Authentication Services* manual.

i Set the Local Cache Size for Centralized Authentication. See "Setting the Local Cache Size for Central Authentication with CSS" in the *Authentication Services* manual.

- j Enable Centralized Event Logging (if required). See “Enabling/Disabling Centralized Event Logging on Devices with CSS” and “Event Logging Client Configuration” for proper hostnames in the *Centralized Event Logging* manual.
- k Set the Network Time Protocol (NTP) Server Settings. See [NTP Server Settings in CSS on page 130](#).

**26** From CSS, restore Codeplug Archive from the backup. Reload the configuration file onto the new device, as follows:

- a From the menu, select **File** → **Open**.
- b Locate and open the previously saved configuration file for the receiver.



**NOTICE:** If you were not able to back up the receiver configuration from the previous receiver, use the configuration from your system documentation, or use the default receiver configuration file. Specific settings for the receiver must still be configured. See the *CSS Online Help* for detailed configuration instructions.

- c On the **Properties** window, click **OK**.
- d When the **Progress Monitor** screen is complete, click **OK**.
- e From the menu, select **File** → **Write Configuration To Device**. Click **OK**.
- f On the Ethernet connection confirmation screen, click **OK**.
- g On the **Connection** screen, enter the <IP Address>. Click **Connect**.
- h On the **SNMPv3 PassPhrase Prompt** dialog box, enter the **User Information** and **Passphrase Information**. Click **OK**. If Authentication Services are not enabled on a device, click **OK** when the dialog box appears.
- i On the confirmation screen, click **OK**.
- j When the **Progress Monitor** screen is complete, click **OK**.

The configuration from the file selected is loaded into the receiver. Communication with the receiver is not available until the reset is complete.

**27** Read the receiver, as follows:

- a From the menu, select **File** → **Read Configuration From Device**.
- b On the confirmation screen, click **OK**.
- c When the **Progress Monitor** screen is complete, click **OK**.

**28** Place the receiver into Normal Mode, as follows:

- a From the menu, select **Service** → **Mode Screen**.
- The **Mode Screen** appears.
- b Click **Change to Normal Mode**.
- c At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.

**29** On systems with MAC Port locking, disable the locking and then re-enable the locking with the MAC address of the receiver. The device being replaced may be connected to an Ethernet port on a switch which implements MAC Port locking (HP switch or RDM). If so, the Ethernet switch port must be unlocked and relocked to the MAC address of the replacement device. See the *MAC Port Lockdown* manual for instructions on disabling and enabling MAC Port locking.



**NOTICE:** Following receiver restoration, if it was connected to an HP switch port, the HP switch port may have been disabled due to an unexpected MAC address. If so, re-enable the port on the HP switch.

- 30 Replace the receiver in the Unified Network Configurator (UNC). See “Replacing a Device” in the *Unified Network Configurator* manual.
- 31 Discover the receiver in the Unified Event Manager (UEM). See the *Unified Event Manager* manual.
- 32 Verify that the receiver is operating properly:
  - The Status LED on the front of the transceiver is green.
  - Proper operation is confirmed using software tools, such as UEM in CSS.

#### 9.4

## Replacing the Fan Assembly



**WARNING:** When removing a fan module, avoid contacting moving fan blades before and after removal with tools, hands, or other objects. If removing the fan module to access or replace the modules behind it, turn off the equipment power and allow the modules to cool before performing any work as the surfaces of the modules can be hot.




**CAUTION:** To prevent overheating, this fan must be in place at all times, except during servicing.



**IMPORTANT:** The fan assembly can be swapped out without shutting the power off. The replacement fan assembly must be in place within a reasonable amount of time so that the device module does not overheat and shut down.

**Figure 54: Fan Assembly**



### Procedure:

- 1 Wear an Electrostatic Discharge (ESD) wrist strap and connect its cable to a verified good ground.

**CAUTION:** Wear the ESD strap throughout this procedure to prevent ESD damage to any components.
- 2 Using a T20 bit, loosen the three captive screws on the front of the fan assembly to disengage them from the chassis.
- 3 Using the handle on one end and the edge on the other side, gently pull the fan assembly straight out to disengage the connector.

4  **NOTICE:** All fan modules are delivered from the factory for dual-fan operation. If the receiver is part of a power efficiency package configuration, the DLN6898A fan module must be used and converted for single fan operation.

Convert for single-fan operation as follows:

- a Lift the connector harness out of the rubber retainer.
- b Disconnect the connector harness.
- c Place each connector end into the individual pockets of the rubber retainer.



**NOTICE:** The DLN6898A fan module can be used in a non-power efficiency package configuration. However, the fan module must be configured for dual-fan operation.

- 5 Using the guide pins and the connector on the back of the new fan assembly, push the fan assembly into place until it feels secure.
- 6 Using a T20 bit, tighten the three captive screws on the front of the fan assembly. Torque to  $17\pm2$  in-lb.
- 7 Verify that the fan assembly is operating properly, and the fan Alarm LED is off. You can also use software tools, such as Unified Event Manager (UEM) or CSS to verify the status of the equipment.

## 9.5

### Replacing a Power Supply



**WARNING:** The power supply module contains dangerous voltages which can cause electrical shock to personnel or damage equipment.



**NOTICE:** When a power supply is inserted into a GPW 8000 Receiver dual-slot chassis where the chassis is currently powered from AUX IN power, and the power supply is switched on, the bottom slot transceiver automatically resets to initialize the power supply.

For a trunked device, place the channel in Service Mode before replacing the module so that the system does not attribute the loss of channel to a failure. Placing a channel into Service Mode is performed using either the Unified Event Manager (UEM) or the Configuration/Service Software (CSS).

Figure 55: Power Supply



**Procedure:**

- 1 Wear an Electrostatic discharge (ESD) wrist strap and connect its cable to a verified good ground.  
**CAUTION:** Wear The ESD strap throughout this procedure to prevent ESD damage to any components.
- 2 For a trunked receiver, place in Service Mode before replacing the module being replaced so the system does not attribute the loss of channel to a failure.
  - a Connect to the transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
  - b From the menu, select **Service** → **Test and Measurement Screen**.
  - c Click **Change to Service Mode**.
  - d At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.
- 3 Push the power rocker switch to Off (O) on the power supply unit.
- 4 Using a T20 bit, loosen the two captive screws on the front of the power supply to disengage them from the chassis.  
**WARNING:** Let the power supply module cool before performing the following step which exposes surfaces of the module that can be hot.
- 5 Pull on the metal handle to disengage the power supply from the backplane, and remove it completely from the chassis.
- 6 Slide the replacement power supply into place, pushing gently until it seats.
- 7 Using a T20 bit, tighten the two captive screws on the front of the power supply.
- 8 Turn the power button to On (I), and verify that the power supply is operating properly:
  - The power supply Status LED is green.
  - The power supply Alarm LED is off.
  - The power supply Fan LED is off.

- Confirm proper operation using software tools, such as the UEM, and the **Power Supply Metering Screen** in CSS.

9 Place the receiver in Normal Mode, as follows:

- a From the menu, select **Service → Test and Measurement Screen**.
- b Click **Change to Normal Mode**.
- c At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.

## 9.6

## Replacing a Power Supply Fan



**WARNING:** The power supply module contains dangerous voltages which can cause electrical shock to personnel or damage equipment.




**NOTICE:** When a power supply is inserted into a GPW 8000 Receiver dual-slot chassis where the chassis is currently powered from AUX IN power, and the power supply is switched on, the bottom slot transceiver automatically resets to initialize the power supply.

Replacing the power supply fan requires removing the power supply module. Removal of a power supply with AUX PWR IN power off results in the loss of all transceivers until the replacement power supply is inserted and turned ON. Removal of a power supply with AUX PWR IN power on results in the loss of only the bottom transceiver until the replacement power supply is inserted and turned ON (while the transceiver resets to reconfigure the hardware).

Place a trunked device in Service Mode before replacing the module so that the system does not attribute the loss of a channel to a failure. Placing the device in Service Mode is performed using either the Unified Event Manager (UEM) or Configuration/Service Software (CSS).

Figure 56: Power Supply Fan



GTR8000\_PS\_Fan\_Front1

**Procedure:**

- 1 Wear an Electrostatic Discharge (ESD) wrist strap and connect its cable to a verified good ground.
 

**CAUTION:** Wear the ESD strap throughout this procedure to prevent ESD damage to any components.
- 2 For a trunked device, place the receiver associated with the power supply fan being replaced in Service Mode.
  - a Connect to the transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
  - b From the menu, select **Service** → **Test and Measurement Screen**.
  - c Click **Change to Service Mode**.
  - d At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.
- 3 Set the rocker switch on the front of the power supply to Off (O).
- 4 Using a T20 bit, loosen the two captive screws on the front of the power supply module to disengage them from the chassis.
 

**WARNING:** Let the power supply module cool before performing the next step, which exposes surfaces of the module that can be hot.
- 5 Pull on the metal handle to disengage the power supply from the backplane, and remove it completely from the chassis.

- 6** Remove the fan cover from the power supply module:
  - a** Using a T15 bit, remove the four screws that connect the cover to the sides of the power supply module.
  - b** Slide the cover off (tilting the top edge out and lifting the bottom edge above the power supply handle).
- 7** Disconnect the power cable located above the fan.
- 8** Remove the two screws that secure the fan to the power supply.
- 9** Remove the fan and insert the new fan.
- 10** Secure the fan to the power supply with the two screws removed in step 8.
- 11** Attach the power cable for the fan to the connection on the power supply.
- 12** Replace the fan cover:
  - a** Slide the cover on, tilting the bottom edge in, past the power supply handle.
  - b** Using a T15 bit, insert and tighten the four screws that connect the cover to the sides of the power supply module.
- 13** Slide the power supply into place, pushing gently until it seats.
- 14** Using a T20 bit, tighten the two captive screws on the front of the power supply module.
- 15** Turn the power button to On (I), and verify that the power supply is operating properly:
  - The power supply Status LED is green.
  - The power supply Alarm LED is off.
  - The power supply Fan LED is off and the fan is operating.
  - Proper operation is confirmed using software tools, such as the UEM, and the **Power Supply Metering Screen** in CSS.
- 16** Place the receiver in Normal Mode, as follows:
  - a** From the menu, select **Service** → **Test and Measurement Screen**.
  - b** Click **Change to Normal Mode**.
  - c** At the confirmation screen, click **OK**.


The receiver halts activity in the current mode and switches operation to the requested mode.

## 9.7

### Replacing a GPW 8000 Receiver Backplane

In a GPW 8000 Receiver, the backplane is the circuit board at the rear of the card cage which connects the power supply and transceiver. The figure shows the ports and cables that must be disconnected to remove the metal cover to access the backplane.

Figure 57: GPW 8000 Receiver Showing Connections to Backplane Through Backplane Cover



GPW\_8000\_receiver\_backplane\_w\_callouts\_C

**Prerequisites:** The procedure assumes the following service access clearances:

- At least 60.96 cm (2 ft) access at the rear of the rack, or
- At least 60.96 cm (2 ft) access on one side of the rack, and at least 6 inches at the rear of the rack

**Procedure:**

- 1 Wear an Electrostatic Discharge (ESD) strap and connect its cable to a verified good ground.



**CAUTION:** Wear the ESD strap throughout this procedure to prevent ESD damage to any components.

- 2 If the receiver is not operational, go to [Step 4](#).
- 3 Place the receiver with the backplane being replaced in Service Mode, so the system does not attribute the loss of channel to a failure:
  - a Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 121](#).
  - b From the menu, select **Service** → **Test Measurement Screen**.
  - c Click **Change to Service Mode**.
  - d At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.

- 4 Push the power rocker switch power supply unit to Off (O).
- 5 Label and disconnect all cables from the receiver backplane.
- 6 Label then disconnect all cables from the front ports on the transceiver.
- 7 Remove the power supply module from the chassis as follows:
  - a Using a T20 bit, loosen the two captive screws on the front of the power supply to disengage them from the chassis.



**WARNING:** Let the power supply module cool before performing the following step which exposes surfaces of the module that can be hot.

- b** Pull on the metal handle to disengage the power supply module from the backplane, and remove it completely from the chassis.
- 8** Remove the fan assembly to gain access to the transceiver modules. See [Replacing the Fan Assembly on page 177](#).
- 9** Disengage the transceiver module from the backplane as follows:


  - a** Using a T20 bit, loosen the two captive screws on the front of each module, so they disengage from the chassis.
  - b** Using the handles, gently pull the modules until the modules disengage from the backplane.
- 10** Using a T20 bit, remove the screw that secures the tab on the right Electromagnetic Interference (EMI) spring panel. See [Figure 59: EMI Spring Panel Guide Rail Alignment on page 186](#).
-  **NOTICE:** Removing the left EMI spring panel is optional.
- 11** Carefully slide the EMI spring panel forward, noting how the panel is affixed onto the power supply guide rail. The panel does not need to be removed.
- 12** Remove the fan cable from the backplane, from the front of the chassis, with the backplane still secured to the chassis, as follows:

  - a** Follow the fan cable with your hand from its connector at the front of the chassis to its connection to the backplane, through the card cage section from where the power supply module was removed.
  - b** Remove the fan cables multi-pin connector from the backplane by squeezing the top and bottom of the connector and pulling the connector straight out from the backplane.
- 13** Using a T20 bit, remove the five screws that secure the metal backplane cover and the backplane circuit board to the rear of the chassis.
- 14** Remove the metal backplane cover and the backplane circuit board.
- 15** Place the new backplane circuit board in the same location and orientation as the one removed.
-  **IMPORTANT:** Start threading all five screws into the backplane circuit board and backplane cover before they are fully seated and secured.

Secure the new backplane circuit board and the backplane cover to the rear of the receiver chassis with the five screws removed in step 13. Torque to 18+/-2 in-lb.
- 17** Connect the fan cable to the new backplane, from the front of the chassis, with the backplane secured to the chassis, as follows:


  - a** Locate the port in the new backplane for the fan cable multi-pin connector.
  - b** Follow the fan cable with your hand from its connector at the front of the chassis to the connector at the other end of the cable.
  - c** Push the fan cables multi-pin connector, with the tab up, into the correct location in the backplane.

**Figure 58: Fan Cable Connector**



GTR\_GCP\_Fan\_Cable\_Connector

**18** Slide the EMI spring panel back into the cabinet. Ensure that the offset tabs on the panel are to the right (inside) of the power supply guide rail, so that the panel does not catch on the fan cable.

**Figure 59: EMI Spring Panel Guide Rail Alignment**

- 19 Using a T20 bit, reinstall the screw into the EMI spring panel tab.
- 20 Slide the transceiver modules into the new backplane. A slight push may be required to fully engage the modules.
- 21 Reconnect all cables to the front ports on the transceiver, if applicable.
- 22 Using a T20 bit, secure the transceiver modules to the chassis with the two captive screws on the front of each module.
- 23 Reinstall the fan assembly. See [Replacing the Fan Assembly on page 177](#).
- 24 Slide the power supply into the chassis, pushing gently until it securely seats in the new backplane.

 **NOTICE:** If the power supply does not seat properly, remove it and adjust the EMI spring panel properly against the mounting flange.

- 25 Using a T20 bit, tighten the two captive screws on the front of the power supply.
- 26 Reconnect all cables at the rear of the receiver.
- 27 Set the power supply rocker switch to On (I).
- 28 Verify that the LEDs indicate the modules you removed and reinstalled are operational:

- The Status LEDs are green.
- The Alarm LEDs are off.
- The power supply Fan LED is off.

**29** In CSS, place the receiver in Normal Mode, as follows:

- From the menu, select **Service → Test Measurement Screen**.
- Click **Change to Normal Mode**.
- At the confirmation screen, click **OK**.

The receiver halts activity in the current mode and switches operation to the requested mode.

**30** Re-configure the Security Settings into the Backplane. See [Setting the Serial Security Services in CSS on page 119](#).

**31** Verify proper operation using software tools, including:


- Unified Event Manager (UEM)
- CSS

## 9.8


## Replacing a GPW 8000 Receiver Preselector Filter and Splitter


Use this procedure to remove either the preselector (cast) filter, splitter, or both from the GPW 8000 Receiver

**Figure 60: Preselector Filter and Splitter Mounted to GPW 8000 Receiver**



**Figure 61: Preselector Filter**




**Figure 62: Preselector Cabling**

GPW\_8000\_cabling\_preselector\_A


**Figure 63: Splitter**

GPW\_8000\_Receiver\_Splitter\_A

**Figure 64: Splitter Cabling**

GPW\_8000\_cabling\_splitter\_only\_A

Figure 65: Preselector and Splitter Cabling



GPW\_8000\_cabling\_preslector\_w\_splitter\_A



**IMPORTANT:** You can replace a preselector filter without shutting the power down.

**Procedure:**

- 1 Wear an Electrostatic Discharge (ESD) strap and connect its cable to a verified good ground.  
 **CAUTION:** Wear the ESD strap throughout this procedure to prevent ESD damage to any components.
- 2 Remove the preselector or splitter from the receiver as follows:
  - a Using T20 bit, remove the two screws which secure the preselector or splitter to the flange of the receiver.
  - b Label and disconnect the left and right RF cables from the preselector or splitter.
- 3 If both the preselector filter and splitter are installed, label and disconnect the cable running from one to the other.
- 4 Install the preselector or splitter to the receiver as follows:
  - a Using T20 bit, secure the slide rail to the receiver flange using the two screws removed in step 2a.
  - b Reconnect the left and right RF cables to the preselector.
  - c If both the preselector filter and splitter are installed, reconnect the cable running from one to the other
  - d Tune the preselector. See [Tuning a Preselector on page 139](#).
- 5 Verify that the system is operating properly using the Unified Event Manager (UEM).

This page intentionally left blank.

## Chapter 10

# GPW 8000 Receiver Reference

This chapter contains supplemental reference information relating to GPW 8000 Receiver and its subsystems, including LED states and specifications for individual GPW 8000 Receiver Radio Frequency Distribution System (RFDS) modules.

### 10.1

## GPW 8000 Receiver LEDs

Many of the LEDs on the GPW 8000 Receiver provide an indication for one or more the following conditions:

### **Lamp Test**

The Lamp Test state verifies that the indicators are operational. For Lamp Test, the LEDs stay in this state for a second or less.

### **Failure**

A failure has occurred that can be fixed only through replacement. If a reason other than a hardware fault is causing the state, Impaired is noted.

### **Impaired**

The device is not fully operational due to internal or external causes. Some corrective action must be taken to get back to 100% operation.

### **Booting Up**

The device is not in service due to running of diagnostics or initializing.

### **Online**

The device is fully operational.

The LEDs for the transceiver modules can be viewed through the door next to the fans with the door opened or closed.


### 10.1.1

## GPW 8000 Receiver Transceiver LEDs

The GPW 8000 Receiver LEDs include the following:

- Status and Alarm
- Ethernet Link Status
- Application-Controlled

- Services-Controlled

**Figure 66: Transceiver LEDs (viewable through a drop-down door)****10.1.1.1****Transceiver Status and Alarm LEDs**

The Status LED is green, and the Alarm LED is red. These LEDs are either off, on, or blinking depending on the condition of the transceiver.

**Table 44: Transceiver Status and Alarm LEDs**

Condition	Green (Status LED)	Red (Alarm LED)
No Power	Off	Off
Lamp Test (During Test)	On	On
Impaired Operation	On	Blinking
Critical Failure	Off	On
Booting Up	Blinking	Off
Operational	On	Off

For detailed information on current operation and fault status, use the Configuration/Service Software (CSS) **Status Panel** screen.

**10.1.1.2****Transceiver Ethernet Link Status LEDs**

The following LEDs indicate Ethernet link and status connections between the transceiver, LAN, and the front panel service port.

**Table 45: Transceiver Ethernet Link Status LEDs**

LED Name	Indication	LED Status
ENET SC-A (external connection to SITE CTRL A on the rear of the chassis)	Ethernet link inactive (Remote PHY/MAC not detected.)	Off
	Ethernet link established (Remote PHY/MAC detected and auto-negotiation completed.)	Green

*Table continued...*

LED Name	Indication	LED Status
	GPW 8000 Receiver Ethernet link active (Actively receiving data.)	Amber (blinking)
ENET SCB (external connection to SITE CTRL B on the rear of the chassis)	Ethernet link inactive (Remote PHY/MAC not detected.)	Off
	Ethernet link established (Remote PHY/MAC detected and auto-negotiation completed.)	Green
	GPW 8000 Receiver Ethernet link active (Actively receiving data.)	Amber (blinking)
ENET SVC (front panel service port)	Ethernet link inactive (Remote PHY/MAC not detected.)	Off
	Ethernet link established (Remote PHY/MAC detected and auto-negotiation completed.)	Green
	GPW 8000 Receiver Ethernet link active (Actively receiving data.)	Amber (blinking)

#### 10.1.1.3

### Transceiver Application-Controlled LEDs

The application-controlled LEDs can be green, red, or amber depending on the conditions.

Table 46: Transceiver Application-Controlled LEDs

Condition	LED 1 Receive Status	LED 2 Control Channel Status	LED 3 Tx/Service Status	LED 4 Infrastructure Payload Link Status
Booting Up*	Green	Green	Green	Green
Lamp Test	Amber	Amber	Amber	Amber
Receiver Inhibited	Amber (blinking)			
Receiver Active	Green			
RF Channel Interference	Red (blinking)			
Monitor Before Data Transmit	Green			
Illegal Carrier	Red (blinking)			
Control Channel (Operating)		Green		
Control Channel (Failsoft)		Green (blinking)		
Service Mode			Amber	
Transmitter Inhibited			Amber (blinking)	

*Table continued...*

Condition	LED 1 Receive Status	LED 2 Control Channel Status	LED 3 Tx/Service Status	LED 4 Infrastructure Payload Link Status
Infrastructure Link Connected (V.24, IP, and 4-wire/V.24)				Green
Partial Infrastructure Link Established (V.24 link established, 4-wire link not established)				Amber
Infrastructure Link Disconnected (V.24, IP, and 4-wire/V-24)				Green (blinking)

\* During a normal boot up sequence, LEDs 1 through 4 blink from left to right and from right to left continuously for several seconds.

#### 10.1.1.4

### Transceiver Services-Controlled LEDs

For the service-controlled LEDs, the color of all LEDs must be observed to interpret the condition of the transceiver.

Table 47: Transceiver Services-Controlled LEDs


Condition	LED 5 SWDL/ VLAN	LED 6 Fault	LED 7
Lamp Test	Amber	Amber	Amber
Receiver Inhibited		Red	
Receiver Reference Failure		Red	
Transmitter Inhibited		Red	
SWDL (Software Download transfer in progress)	Green		
Warning		Amber	
Minor Hardware Failure		Amber (blinking)	
Major Hardware Failure		Red (blinking)	
Critical Hardware Failure		Red	
VSWR Fault		Red	

#### 10.1.2

### Transceiver Option Card Intercom LED

The Transceiver Option Card has a single Intercom LED that indicates the intercom function between the ON (amber) and OFF (green) states.

Figure 67: Transceiver Option Card Intercom LED (viewable behind the fan module)




#### 10.1.3

### Fan Module LED

The fan module has one Fan Alarm LED visible on the lower right corner of its front panel. The Alarm is red during Lamp Test (for 1 second or less), and remains red if the fan fails. A fan failure alarm occurs if the built-in speed sensor detects if either fan drops 30% below rated speed. A red Fan Alarm indicates that the fan module must be replaced.

Figure 68: Fan Module-Alarm LED (lower right corner)



**NOTICE:** The fan operates at full capability for at least seven days after the fan alarm first occurs, allowing normal operation without requiring an immediate service call.

#### 10.1.4

### Power Supply LEDs

The power supply has three LEDs visible from the front panel. To interpret its condition, observe the color of all the power supply LEDs. For example:

- If the Alarm and Fan LEDs are red and the Status LED is green, the condition is "Lamp Test"
- If the Alarm LED is red and the Fan and Status LEDs are not lit, the condition is "Power Supply Failure"

**Figure 69: Power Supply Module**

G\_series\_power\_supply\_A

**Table 48: Power Supply LEDs**

Condition	Fan	Status	Alarm
Power Off	Off	Off	Off
Lamp Test	Red	Green	Red
Online	Off	Green	Off
Impaired	Off	Green	Red (blinking)
Power Supply Failure	Off	Off	Red
Power Supply Fan Failure	Red	Off	Red

## 10.2

## GPW 8000 Receiver RFDS Equipment Specifications

The GPW 8000 Receiver Radio Frequency Distribution System (RFDS) options include the preselector and splitter. This section provides specifications for the GPW 8000 Receiver RFDS equipment.

The addition of these options affects the sensitivity performance. These performance specifications are also included.

When ordered from the factory, all of these options are assembled with the appropriate cables and mounting hardware.



**IMPORTANT:** Specifications are subject to change without notice.

### 10.2.1

## Preselector Filter Specifications (700/800 MHz)

Table 49: Preselector Filter Specifications (700/800 MHz)

	Preselector Spec Limit (700/800 MHz)	Typical
Frequency range	792–806 MHz 792–825 MHz	
Insertion loss	1 dB	0.7 dB
VSWR max.	1.5:1	1.3:1
Input Connector	QMA	
Output Connector	QMA	

### 10.2.2

## Preselector Filter Specifications (UHF)

Table 50: Preselector Filter Specifications (UHF)

	Preselector Spec Limit (UHF)	Typical
Tuning range	380–433 MHz, 435–470 MHz, 470–524 MHz	
Bandwidth	4 MHz	
Insertion loss	2 dB	1.3 dB
VSWR max.	1.9:1	1.5:1
Input Connector	Mini-UHF	
Output Connector	Mini-UHF	

### 10.2.3

## Preselector Filter Specifications (VHF)

Table 51: Preselector Filter Specifications (VHF)

	Preselector Spec Limit (VHF)	Typical
Tuning range	136–154 MHz, 150–174 MHz	
Bandwidth	4 MHz	
Insertion loss	1.3 dB	1.1 dB

*Table continued...*

	Preselector Spec Limit (VHF)	Typical
VSWR max.	1.9:1	
Input Connector	Mini-UHF	
Output Connector	Mini-UHF	

## 10.2.4

## Splitter Specifications

Table 52: Splitter Specifications

Parameter	Splitter Spec Limit	Typical
Frequency Range	100–1000 MHz	
Insertion Loss:		
VHF	4.0 dB	3.4 dB
350-524 MHz	4.0 dB	3.6 dB
794-902 MHz	4.5 dB	3.8 dB
Isolation Between Outputs	20 dB	23 dB
Return Loss:		
VHF		23 dB
350-524 MHz		21 dB
794-902 MHz		20 dB
Connectors	BNC Female	

## 10.2.5

## Performance Sensitivity with RFDS Options

Table 53: Specifications with RFDS Options

Parameter	700, 800, or 900 MHz	UHF	VHF
Sensitivity Degradation with Preselector	1.0 dB	2.0 dB	2.0 dB
Sensitivity Degradation with Splitter	4.5 dB	4.0 dB	4.0 dB
Sensitivity Degradation with Preselector and Splitter	5.0 dB	5.0 dB	5.0 dB
Preselector Bandwidth	Full band	4 MHz	4 MHz

## Chapter 11

# GPW 8000 Receiver Disaster Recovery

This chapter provides references and information that assist in the recovery of a GPW 8000 Receiver in the event of failure.

### 11.1

## Recovering the GPW 8000 Receiver

Perform the following procedure to recover the GPW 8000 Receiver.

#### Process:

- 1 To replace, install, connect power, and cable the receiver, see [GPW 8000 Receiver Hardware Installation on page 79](#).
- 2 Replace the transceiver modules, see [Replacing a GPW 8000 Receiver Transceiver Module on page 171](#) and follow steps 1 through 17.  
 **NOTICE:** GPW 8000 Receiver GEN 1 transceivers are supported only in the top slot of the dual-slot chassis. GEN 2 transceiver can be used in either top or bottom slots.
- 3 To replace other hardware devices with or on the chassis, see [GPW 8000 Receiver FRU and FRE Procedures on page 165](#).
- 4 To perform basic device configuration and SWDL download, see [Replacing a GPW 8000 Receiver Transceiver Module on page 171](#) and follow steps 18 through 32.

### 11.2

## Performing a Site Software Download With GCP 8000 Site Controllers

Use the following procedure to perform a site software download with GCP 8000 site controllers.

#### Procedure:

- 1 Connect an Ethernet straight through cable between the Ethernet port on the service computer/laptop and the Ethernet service port on the site controller. The service computer/laptop IP address must be set to an address on the subnet of the local site, which varies depending on the site and zone numbers. See [Connecting Through an Ethernet Port Link on page 121](#).  
 **NOTICE:** If 802.1x services are enabled on the site controller, an 802.1x login account to connect to the Ethernet port is needed. An 802.1x account is a centrally managed account. See Chapter 6, “802.1x Service Port Procedures for GCP 8000 Site Controller” in the *802.1x Service Ports on Switches* manual.
- 2 Open the Software Download Manager application.  
 **CAUTION:** Load the correct version of the software. There is a possibility of a mismatch in software versions when replacing the transceiver module with an on-hand spare. If a mismatch in software versions occurs, the transceiver may go into a configuration mode of operation with a reason of ‘Invalid Software Version’. To exit out of configuration mode, see “CSS Procedures > Changing from Configuration to Normal Mode” in the *CSS Online Help*.

- 3 From the **Advanced Options** menu, select the transfer type.
- 4 Download and install the necessary software onto the site controllers and receivers as follows:
  - a From the menu, select **Action** and choose one of the following:
    - **Use DNS Server:** This is the default option and is recommended for most cases.
    - **Use Standard ASTRO IPs (non-Tsub):** Legacy option which relies upon a built-in IP Plan rather than the DNS Server. This option is not supported for Trunking Subsystems (Tsubs).
    - **DNS Override:** Use when running the Software Download Manager from a server that is not joined to the ASTRO® 25 system domain. In order to use a DNS server in the ASTRO® 25 system domain, the **Override DNS Server** dialog box is used to specify the DNS server IP address (defaults to the ASTRO® 25 system level DNS server).
    - **Load DNS File:** Use only in situations where a custom DNS configuration file has been provided. Typically, this option is selected when the site IP addresses are not configured to be part of an ASTRO® 25 system.
  - b From the menu, select **File** → **File Manager**.
  - c From the **Software Depot File Manager** menu, select **Component Operations** → **Import Fileset**.
  - d From the **Import a Fileset Into the Software Depot** dialog box, click **Browse** and search for the `swdlv3.cfg` file, or follow path `E:\swdl\swdlv1.cfg` or `swdlv3.cfg`. Click **Open**.

The file appears in the **Configuration File Path** field of the **Import a Fileset Into the Software Depot** dialog box.

- e Click **Generate**. Click **OK**.
- the **Import a Fileset Into the Software Depot** dialog box closes and the software component appears in the **Components In the Software Depot** list of the **Software Depot File Manager** window.
- f Exit the **Software Depot File Manager**.
- g From Software Download Manager, click **Open Site Mode**.
- h Select the **ASTRO 25 Site Type:Simulcast**.
- i Select the **Zone**, **Site**, and if applicable, the **Subsite**. The Subsite ID is only available when the **Site ID** is between 1-64.
- j Click **Connect**.
- k If the device supports SNMPv3 protocol, a pop-up window appears with the security level option. Choose the required security level. Click **OK**.



**NOTICE:** Depending on the size of the system, the window takes a few minutes to update.

If the Ethernet connection to the site uses the Site Controller Service Port, you might need to enter an 802.1x login account to connect to the SC Service Port. An 802.1x account is a centrally managed account.

The system connects to the specified zone and site.

- l If this is a simulcast site, from the **Site View** tab, click the icon in front of the **Prime LAN** folder, and **Subsite** folders.

The entries under the **Running Version** column display the current version. The **VLAN** column displays the VLANs for all devices.

- m In the **Operation Type**, select **Transfer and Install**.

- n In the **Application Type**:
  - For a trunked simulcast site: select **Multisite Site Controller** and **Multisite Base Radio**.
  - For a simulcast site with a GPB 8000 Reference Distribution Module: select **Multisite Base Radio**, and **GPB 8000 Reference Distribution Module**
- o In the **Software Component** drop-down list, select the version for each site device.
  -  **NOTICE:** Both device software must be chosen as part of the site software download.
- p In the **Simultaneous Channels Install** drop down list, select the number of the channels to install simultaneously.

Software Download Manager always installs all channels. For example: setting the **Simultaneous Channels Install** field to a specific number value means that those amounts of channels are installed simultaneously.

  -  **NOTICE:** The **Simultaneous Channels Install** field decreases the installation time. A warning is displayed if the site goes into failsoft, due to this setting.
- q Click **Start Operation**.
  -  **NOTICE:** If the **Start Operation** button is grayed out, SWDL has determined that there is a problem performing this operation to the selected devices. The button becomes active, when the appropriate operation set details are selected.  
If a fileset is damaged, the Transfer operation stops. Import a correct fileset and repeat the operation.
- r In the window that appears, click **Proceed**.

The Transfer operation begins first. After the transfer is successfully completed, SWDL begins the Install operation.

If the install was successful, the **Operation Status** bar displays green. If the install failed, the **Operation Status** bar displays red.
- s Disconnect and reconnect to verify that the selected devices have installed the desired version of the software.
  -  **NOTICE:** After installation, the new software version is present in the **Running Version** column. If the new version is not present, it indicates a problem.  
For more information, consult the “Fixing a Transfer Failure” section of the *Software Download Manager* manual.

In many cases, a second attempt at transferring the software corrects the failure. If further attempts continue to fail, contact Motorola Solutions Support (MSS).

This page intentionally left blank.

## Chapter 12

# Standalone GPB 8000 Reference Distribution Module

This chapter provides an overview of the standalone GPB 8000 Reference Distribution Module (RDM), including installation, operation, troubleshooting, and disaster recovery.

### 12.1

## Standalone GPB 8000 Reference Distribution Module Introduction

The standalone GPB 8000 Reference Distribution Module (RDM) is used only in receive-only trunked sites, and is installed in a standard rack including:

- Standalone Expansion Hub (XHub) modules that allow an RDM to support additional GPW 8000 Receivers beyond what the RDM can support on their own. One RDM supports up to five XHubs, with each XHub supporting up to six base radios or GPW 8000 Receivers.
- GPW 8000 Receivers




**NOTICE:** The standalone RDM components are supported only for use with a trunked GPW 8000 Receiver.

**Figure 70: GPB 8000 Reference Distribution Module**



GCP\_site\_controller\_GPB\_RDM\_FRU

**Figure 71: GPB 8000 Reference Distribution Module (Inside Chassis)**

RDM\_front\_wo\_cover1

The standalone GPB 8000 Reference Distribution Module consists of two redundant modules, a fan module, and a power supply housed in a chassis.

Site architectures supported include:

- Trunked IP or circuit simulcast subsystem with receive-only subsite (receive-only remote site)
- Colocated trunked IP or circuit receive-only remote site at the prime site
- Trunked IP or circuit Single Transmit Receiver Voting (STRV) subsystem (receive-only remote site)

#### 12.1.1

### GPB 8000 Reference Distribution Module Port Default Speed/Duplex Settings

Table 54: GPB 8000 Reference Distribution Module Port Default Speed/Duplex Settings

RDM Port	Speed/Duplex
Net/Aux	Auto-Negotiate
RDM Expansion 1	100BaseT/Full Duplex
RDM Expansion 2	100BaseT/Full Duplex
RDM Expansion 3	100BaseT/Full Duplex
RDM Expansion 4	100BaseT/Full Duplex
RDM Expansion 5	100BaseT/Full Duplex
Service Port	Auto-Negotiate
Router	100BaseT/Full Duplex
Base Radio 1	100BaseT/Full Duplex
Base Radio 2	100BaseT/Full Duplex
Base Radio 3	100BaseT/Full Duplex
Base Radio 4	100BaseT/Full Duplex
Base Radio 5	100BaseT/Full Duplex
Base Radio 6	100BaseT/Full Duplex
Alarm	Auto-Negotiate

## 12.2

# GPB 8000 Reference Distribution Module Function

Each The GPB 8000 Reference Distribution Module (RDM) provides integrated Ethernet LAN switching and integrated site reference distribution to the GPW 8000 Receivers, ensuring that a single point of failure in the reference or switch does not cause the loss of any channels at the site.

## Ethernet LAN Switches

Both RDMs maintain a built-in Ethernet LAN switch providing each GPW 8000 Receiver at the site with two Ethernet LAN switch connections. The GPW 8000 Receivers determine which switch to use based on the condition of the RDMs.

## Dual GNSS Unit Function

Each RDM has an optional connected Global Navigation Satellite System (GNSS) unit that provides the necessary references to either of the RDMs. A high-stability oversized crystal oscillator within the RDMs train to the GNSS units. The RDMs then generate the output time reference to the receivers. Both GNSS units are active and provide protection against a single GNSS unit failure/interference at the site.

If an optional TRAK Simulcast Site Reference (SSR) at the remote site is used as an extended holdover backup, the RDMs can be configured in the following configurations to either provide support or act as a replacement for the GNSS units:

- Each RDM connected to a GNSS unit
- One RDM connected to a GNSS unit
- No RDMs connected to a GNSS unit

## Network Time Protocol Sources

Network Time Protocol (NTP) provides a clock synchronization mechanism to the RDMs and other NTP clients at the site. The NTP clients must use the TRAK 9100 SSR, at the prime site as the primary time source; and an ntp02.zoneN device at a zone core as the secondary time source. The RDMs at the site also act as an NTP time source. The receivers use RDM A as the primary NTP time source, and RDM B as the secondary NTP time source.

## Time Synchronization and Frequency Reference Function

The RDMs provide a 1PPS and 10 MHz reference signaling to the GPW 8000 Receivers. The time reference synchronizes transmissions with the GPW 8000 Receivers, and the high stability frequency reference provides a reference for receive frequency synthesizers in the GPW 8000 Receivers. The time and frequency reference is supplied from a high-stability ovenized crystal oscillator within the RDMs to the GPW 8000 Receivers.

## 12.3

# GPB 8000 Reference Distribution Module Operational States

The GPB 8000 Reference Distribution Modules (RDMs) provide redundant reference and Ethernet switching to the receivers. If a failure occurs with one of the RDMs, the other RDM maintains the site. If a Global Navigation Satellite System (GNSS) unit on an RDM fails, the RDM switches to using the 1PPS reference from the GNSS unit on the other RDM.

If both GNSS units are non-operational, both RDMs maintain 1PPS reference accuracy for at least four hours. If both RDMs fail, the remote site loses connection to the prime site.

## 12.4

## GPB 8000 Reference Distribution Module Installation


This section provides connection reference information to interface the standalone GPB 8000 Reference Distribution Module with GPW 8000 Receivers.

## 12.4.1

### Standalone GPB 8000 Reference Distribution Module Rear Connections

The standalone GPB 8000 Reference Distribution Module (RDM) backplane connectors are shown in the figure.

**Figure 72: Standalone GPB 8000 RDM Backplane Connectors**



Cable connections for a standalone GPB 8000 RDM are provided in the table.



**NOTICE:** For an example of power connections supporting standalone trunked GPW 8000 Receivers, RDMs, and Expansion Hubs (XHubs), see [GPW 8000 Receiver Power Connections on page 87](#).

**Table 55: GPB 8000 RDM Backplane Connections**

Port	Description
RFDS	Monitors RFDS alarms from the power monitor and receiver multi-coupler.
Remote GPS 'A'	Optional connection between the Global Navigation Satellite System (GNSS) A and the RDM.
Internal Alarm	Not in use
Remote GPS 'B'	Optional connection between the GNSS B and the RDM.
External Alarm	Not in use

*Table continued...*

Port	Description
SC A to Base Radio 1-6/ RJ-45	Connection between RDM A and the GPW 8000 Receiver.
SC B to Base Radio 1-6/ RJ-45	Connection between RDM B and the GPW 8000 Receiver.
EXT FREQ REF	Not in use
1PPS	An optional connection between the RDM and TRAK 9100 SSR for time reference. The 1PPS input must have a BNC "T" connected to it. A 50 Ohm termination is on one leg of the "T" and the cable to the RDM is on the other side of "T".
Battery Temp	Connection to temperature sensor, allowing for temperature compensated battery charging.
AUX PWR Output	Auxiliary Power Output to other chassis.
AUX PWR Input	The auxiliary input is connected with a GPW 8000 Receiver as a secondary power source.
+ Batt/DC	Input from and output to a 48 VDC power supply or backup battery. When AC power is not available, the device switches to operate from a DC source if the optional DC power (8AWG; length 9 ft), CA01400AA is ordered and installed. One end connects into the Batt/DC port and the other end connects into the DC source. The contacts are 39-83503N02 (AMP #53880-2), the receptacle housings are 15-83502N01 (AMP #53884-1) and the mounting ears are 07-83504N01 (AMP #53887-1). 3084869Y06 cable is used for a positive ground system. 3084869Y02 cable is used for a negative ground system.
AC	Input from 90/264 VAC nominal power source.
GND	Two grounding lugs and cable.

Table 56: Standalone GPB 8000 RDM and GPW 8000 Receiver Cabling Detail (Example)

Device	Port	Connects to Device /Port
RDM A, Rear (Chassis)	SC A-2 to Base Radio 2	GPW 8000 Rear (Chassis) / XVCR2 / LAN A
RDM A, Rear (Chassis)	SC A-1 to Base Radio 1	GPW 8000 Rear (Chassis) / XVCR1 / LAN A
RDM A, Rear (Chassis)	SC A-4 to Base Radio 4	GPW 8000 Rear (Chassis) / XVCR4 / LAN A
RDM A, Rear (Chassis)	SC A-3 to Base Radio 3	GPW 8000 Rear (Chassis) / XVCR3 / LAN A
RDM A, Rear (Chassis)	SC A-6 to Base Radio 6	GPW 8000 Rear (Chassis) / XVCR6 / LAN A
RDM A, Rear (Chassis)	SC A-5 to Base Radio 5	GPW 8000 Rear (Chassis) / XVCR5 / LAN A
RDM B, Rear (Chassis)	SC B-2 to Base Radio 2	GPW 8000 Rear (Chassis) / XVCR2 / LAN B

Table continued...

Device	Port	Connects to Device /Port
RDM B, Rear (Chassis)	SC B-1 to Base Radio 1	GPW 8000 Rear (Chassis) / XVR1 / LAN B
RDM B, Rear (Chassis)	SC B-4 to Base Radio 4	GPW 8000 Rear (Chassis) / XVR4 / LAN B
RDM B, Rear (Chassis)	SC B-3 to Base Radio 3	GPW 8000 Rear (Chassis) / XVR3 / LAN B
RDM B, Rear (Chassis)	SC B-6 to Base Radio 6	GPW 8000 Rear (Chassis) / XVR6 / LAN B
RDM B, Rear (Chassis)	SC B-5 to Base Radio 5	GPW 8000 Rear (Chassis) / XVR5 / LAN B
RDM, Front	Expansion Ports (1 through 5)	XHub, Front / EXPNS Input (CP3) (see NOTE)




**NOTICE:** Route the cables from the 0 RDM to the XHub (CP3) out the slot in the side of the fan housing. RDM Expansion Ports 2 through 5 can be used to interface with additional XHub devices.

#### 12.4.2

### Standalone GPB 8000 Reference Distribution Module Front Connections

The standalone GPB 8000 Reference Distribution Module (RDM) front connectors are shown in the figure.

**Figure 73: GPB 8000 RDM Front Connectors**



**Table 57: GPB 8000 RDM Front Connections**

Port / Type	Connects to This Device/ Port	Description
Ethernet service port, RJ-45	Service PC, LAN port	Ethernet service port for local access using Configuration/Service

*Table continued...*

Port / Type	Connects to This Device/ Port	Description
		Software (CSS). Also may be used for localized software downloads.
		 <b>NOTICE:</b> Supports only 10 Mb half duplex operation.
Serial service port, DB-9	Service PC, RS-232 port	Serial service port for initial configuration of the IP address.
Gateway port, RJ-45	Gateway, LAN 1, RJ-45	Connection to Gateway.
Expansion Ports 1-5, RJ-45	XHub, RJ-45	Connection to XHub, Front / EXPSN Input (CP3).
Reference frequency input, BNC	Service monitor	Connection port to service monitor for frequency calibration.

 **NOTICE:** Expansion Port 1 on the front of the RDM is used to interface with the EXPSN Input (CP3) on the front of an XHub. Route the cable from the RDM to XHub (CP3) out the front slot on the side of the fan housing. RDM Expansion Ports 2 through 5 can be used to interface with additional XHub devices as necessary.

#### 12.4.3

### GNSS Unit Installation

Remote-only sites with GPB 8000 Reference Distribution Modules (RDMs) use Global Navigation Satellite System (GNSS) units that lock onto a satellite system. The RDMs use the signals from the GNSS unit to generate the time and frequency reference for the remote site. Alignment of timing is handled by each remote site independently locking to the satellite system.



#### IMPORTANT:

- Improper installation of the GNSS unit (mainly reflection issues) can lead to improper position information, and is reported by the GNSS unit.
- During initial startup, if the GNSS unit is not locked onto at least four satellites, the system may not operate properly. These satellites are used to establish a three-dimensional fix (latitude, longitude, and altitude) for the site. Once the three-dimensional fix has been determined, only one satellite is required to maintain proper operation.
- Wait until the GNSS units have locked onto the satellites before verifying proper operation.



**NOTICE:** Reconfiguring the Time Reference Configuration causes the RDM to base radio links to temporarily fail, causing the base radios to report alarms. These alarms clear automatically once the RDMs have transitioned to the new time reference sources.

The RDMs can free-run for approximately four hours. However, after that period, the system will not operate properly without the GNSS signals. The GNSS units must be properly positioned, and the cables and connectors must be properly maintained to ensure the operation of the system.

#### 12.4.3.1

### **GNSS Equipment**

The Global Navigation Satellite System (GNSS) equipment is ordered in a quantity of one per GPB 8000 Reference Distribution Module (RDM) or GCP 8000 Site Controller. Redundant RDMS or site controllers are required, therefore each item must be ordered in a quantity of two.

The following lists the equipment to install the GNSS units:

- GNSS Antenna/Receiver: PMUG1017A
- Wall Mounting Brackets: DSWM4
- Mounting Pole: DSP04268
- GNSS Primary Surge Protector: DSIX2L1M1DC48IG
- GNSS Antenna/Receiver to RDM/SC Cable (125 ft): DS30C87465CO1
- GNSS Antenna/Receiver to RDM/SC Cable (350 ft): DS30C87465CO2

#### 12.4.3.1.1

### **GNSS Unit**

The Global Navigation Satellite System (GNSS) unit includes the antenna and the receiver/modem. Because the actual receiver is integrated with the antenna, the connection between the GNSS unit and the GPB 8000 Reference Distribution Module (RDM) or GCP 8000 Site Controller is digital using a 6-pair twisted pair cable.

#### 12.4.3.1.2

### **Surge Suppression**

This primary surge suppression is used at the point where the cable enters the site building. There should be one surge suppression for each GPB 8000 Reference Distribution Module (RDM) or GCP 8000 Site Controller at the site. The surge suppression is installed by cutting the cable at the point where the cable enters the site building and connecting both ends to the surge suppressor.

#### 12.4.3.1.3

### **GNSS Cables**

Choose the cable length required for the site configuration. One cable is required for each GPB 8000 Reference Distribution Module (RDM) or GCP 8000 Site Controller (SC) at the site. These cables have a Deutsch connector at one end that connects to the Global Navigation Satellite System (GNSS) unit and a DB15 connector that connects to the RDM or SC.

In a typical installation using 6-pair twisted pair cable, the recommended cable length should be 106.7 m (350 ft) or less. This cable length is sufficient for most installations. For cable lengths greater than 106.7 m (350 ft), contact Motorola Solutions Support Center (SSC) for guidance on the installation and configuration.


#### 12.4.3.2

### **Assembling the GNSS Antenna**

Perform this procedure to assemble a Global Navigation Satellite System (GNSS) antenna.

The following figure presents the exploded view of the GNSS antenna.

**Figure 74: GNSS Antenna Assembly – Exploded View**



The following part numbers are valid for the relevant elements:

**GNSS Antenna Assembly**

PMUG1017A

**Mounting Pole (steel pipe)**

DSP04268

**GNSS Antenna/Receiver to RDM/SC Cable**


- DS30C87465C01 (125 ft)
- DS30C87465C02 (350 ft)

**Prerequisites:** Verify that you have the Allen wrench (included in the set), a T30 screwdriver, and a Phillips screwdriver.

**Procedure:**


- 1 Run the digital cable through the steel pipe and collar bracket. Attach the digital cable connector to bottom of the antenna module (male to female Deutsch connector).

**Figure 75: GNSS Antenna Assembly – Cable**




- 2 Align four bracket screw holes with the GNSS antenna bottom mounting holes and screw the collar bracket to the bottom of the antenna module using a Phillips screwdriver.

**Figure 76: GNSS Antenna Assembly – Collar Bracket**




- 3 Fix the mounting pipe to the mounting bracket by tightening the two set screws.

**Figure 77: GNSS Antenna Assembly – Securing the Pipe**



- 4 Attach the mounting pipe to the support structure.
- 5 Attach the grounding cable to the antenna module by tightening a T6 screw using a T30 screwdriver.

**Figure 78: GNSS Antenna Assembly – Grounding Cable**



#### 12.4.3.3

### Installing the GNSS Units

Follow this process to install the Global Navigation Satellite System (GNSS) units.

#### Process:

- 1 Mount the GNSS units with an unrestricted aerial down view to within ten degrees of the horizon in all directions.
- 2 Mount the GNSS units high enough so they have an un-obstructed view of the sky. Adjacent structures (such as trees, buildings, and antenna towers) are considered obstructions. If an un-obstructed view is not possible, install the GNSS units so they have a clear view of the appropriate sky region. Adjacent antenna towers at the RF site which protrude into the required region have a minimal effect on GNSS unit reception due to their narrow, largely open profiles and are not considered obstructions.
  - For northern hemisphere installations, ensure that an un-obstructed view of the southern sky is maintained.
  - For southern hemisphere installations, ensure that an un-obstructed view of the northern sky is maintained.
- 3 Isolate the GNSS units from RF interference by mounting the units at a distance of at least 3.66 m (12 ft) horizontally from the other units.
- 4 Validate the correctness of the position information (latitude, longitude, elevation) reported by the GNSS unit. Proper timing operation is dependent on proper position identification.
- 5 Validate both GPB 8000 Reference Distribution Modules (RDMs) or GCP 8000 Site Controllers (SCs) in the CSS Reference Service Screen and are within 250 nsec of each other. If not, verify the position information (latitude, longitude, elevation) reported by the GNSS units on both RDMs.

6 Configure the Time Reference for both RDMs or SCs in Configuration/Service Software (CSS). For details, see the following in the CSS *Online Help*:

- For an RDM: **Site Controller Configuration & Service Help** → **GPB 8000 Reference Distribution Module (RDM)** → **Service Screens** → **Reference Service Screen**
- For a site controller: **Site Controller Configuration & Service Help** → **High Performance Data (HPD) Site Controller** → **Service Screens** → **Reference Service Screen**

#### 12.4.3.4

### Alarm Indication (No Lock on GNSS Signal)

A system alarm indicates when the GNSS signal cannot be located and that the GNSS unit must be repositioned.


#### 12.4.3.5

### GNSS Lightning Arrestor

A lightning arrestor must be installed between a GCP 8000 Site Controller or GPB 8000 Reference Distribution Module (RDM) and the Global Navigation Satellite System (GNSS) unit. One GNSS unit is connected to each of the site controllers or RDMs. Each GNSS unit requires its own arrestor.

[Figure 79: Lightning Arrestor – System Connections on page 213](#) shows the connections between the lightning arrestor and the GCP 8000 Site Controller or RDM.

**Figure 79: Lightning Arrestor – System Connections**



[Figure 80: Lightning Arrestor DS109–0129H-A Model Wiring on page 214](#) shows one possible configuration of the connections and terminal assignments for installing the DS109–0129H-A model lightning arrestor.

Figure 80: Lightning Arrestor DS109-0129H-A Model Wiring





Figure 81: Lightning Arrestor DS-IX-2L1M1DC48-IG Model Wiring on page 215 shows one possible configuration of the connections and terminal assignments for installing the DS-IX-2L1M1DC48-IG model lightning arrestor.

Figure 81: Lightning Arrestor DS-IX-2L1M1DC48-IG Model Wiring



## 12.5

# Parameter Configuration for a GPB 8000 Reference Distribution Module

This following procedure provides steps required to configure the parameters for the standalone GPB 8000 Reference Distribution Module.

### 12.5.1

## Configuring the Parameters for a GPB 8000 Reference Distribution Module

#### Prerequisites:

Before proceeding with this process, complete the initial configuration of the device in [Device Configuration in CSS on page 115](#).

For configuration details of the GPB 8000 Reference Distribution Module, see **Site Controller Configuration & Service Help** → **GPB 8000 Reference Distribution** in the [CSS Online Help](#).

#### Process:

- 1 Connect to the device through an Ethernet port link and read the configuration file from the device. See [Connecting Through an Ethernet Port Link on page 121](#).
- 2 Click **Site** in the System tree and complete the fields.

- 3 Click **Configuration** in the System tree and complete the fields.
- 4 Click **Network Services Configuration** in the System tree and complete the fields on the three tabs.
 

 **NOTICE:** For configuration details for DNS and RADIUS Services, see the *Authentication Services* manual. For configuration details for SYSLOG Services, see the *Centralized Event Logging*, manual.
- 5 Click **Password Configuration** in the System tree and complete the fields.
 

 **NOTICE:** Password Configuration is only required if you have passwords entered for local accounts. Password Configuration sets the password complexity and controls. For details on password complexity and controls, see “Password Configuration” in CSS *Online Help*.
- 6 Click **Switch Configuration** in the System tree and complete the fields.
- 7 Configure the Time Reference for both RDMs in Configuration/Service Software (CSS). For details, see Site Controller Configuration & Service Help > GPB 8000 Reference Distribution Module (RDM) > Service Screens > Reference Service Screen in the CSS *Online Help*.
- 8 From the menu, select **File** → **Save As** to save the configuration data to a new archive file, or select **File** → **Save** to overwrite the existing archive file.
 

 **IMPORTANT:** Save any configuration changes to a local or network drive in case the device fails you can load your settings to a replacement device. If the configuration file is not saved to a local or network drive, repeat the set-up steps after replacing a device.
- 9 From the menu, select **File** → **Write Configuration to Device** to write the configuration data to the device.

## 12.6

## GPB 8000 Reference Distribution Module General Troubleshooting

Table 58: GPB 8000 Reference Distribution Module General Troubleshooting

Problem	Troubleshooting
General connectivity problems	<ol style="list-style-type: none"> <li>1 If you have access to the equipment, check the LEDs to verify that each piece of equipment is connected and operational.</li> <li>2 In the Configuration/Service Software (CSS), check the alarms of the GPB 8000 Reference Distribution Module (RDM) and all associated devices and links. See <a href="#">GPB 8000 Reference Distribution Module LEDs on page 227</a>.</li> <li>3 Verify the configuration of the RDM through Unified Network Configurator (UNC) and CSS. Verify that the IP address for the RDM is correct. In CSS, send a diagnostic command to enable the RDM.</li> <li>4 Verify redundancy configuration of both RDMs through UNC and CSS. Verify that port 0_Port_Sw-to-Sw is set to Enabled on both RDMs in the Switch Configuration in CSS. If necessary, connect locally to verify RDM #2.</li> <li>5 Verify that the physical cabling is firmly connected and is in good condition. Check for any sharp bends or kinks in cabling. Test suspected ca-</li> </ol>

*Table continued...*

Problem	Troubleshooting
	<p>bling for noise, continuity, attenuation, and crosstalk. Replace the cabling if necessary.</p> <p><b>6</b> If the connection fails to operate normally, check the diagnostics, and if needed, contact Motorola Solutions Support Center (SSC).</p> <p><b>7</b> If the RDM still fails to operate properly, create a backup of the current configuration, then reinstall the software and reconfigure the RDM.</p> <p><b>8</b> Replace the RDM if necessary.</p>
Unit does not power up	<p><b>1</b> If you have access to the equipment, check the LEDs to verify that each piece of equipment is connected and is operational. See <a href="#">GPB 8000 Reference Distribution Module LEDs on page 227</a>.</p> <p><b>2</b> In the CSS, check the alarms for the RDM.</p> <p><b>3</b> Check the power cabling and verify that the power source for the RDM is supplying the appropriate voltage. Connect the RDM to another power source or replace the power cabling if necessary.</p> <p> <b>NOTICE:</b> Check all power sources if there is more than one.</p> <p><b>4</b> Check for any burn marks or physical damage to the RDM and check whether the RDM is properly grounded.</p> <p><b>5</b> Replace the RDM if necessary.</p>
Reference Service reported as not detected	<p><b>1</b> Verify that the Time Reference Configuration in CSS is properly configured.</p> <p><b>2</b> Verify that the time reference source is operational.</p>
Unable to perform a password reset	<p>If the device module has been replaced and serial port access is not available to configure the IP address, the device may have the account locked out or the backplane slot has passwords enabled. Perform the following steps:</p> <p><b>1</b> Move the board module to a different chassis or to a different slot in the backplane where local passwords are not configured.</p> <p><b>2</b> Configure the IP address and reset the device through the front panel RS-232 serial service port using CSS.</p> <p><b>3</b> Perform the local password reset operation (to clear account information stored in the FRU) through and Ethernet port link using CSS.</p> <p><b>4</b> Move the board module back to the original chassis or slot.</p> <p><b>5</b> Perform the local password reset operation again (to clear account information stored in the backplane).</p> <p>See <a href="#">Connecting Through an Ethernet Port Link on page 121</a> and <a href="#">Setting the Local Password Configuration in CSS on page 131</a>.</p>

## 12.7

## GPB 8000 Reference Distribution Module FRU and FRE Procedures

GPB 8000 Reference Distribution Modules (RDM) are composed of numerous Field Replaceable Units (FRUs) and Field Replaceable Entities (FREs). If you must replace a FRU, FRE, or part, obtain the

precise FRU/FRE Kit Number or part number. Review the replacement procedures provided, including all safety precautions and system impact information.

This section lists the FRUs and FREs, and provides the procedures for replacing the GPB 8000 Reference Distribution Module (RDM), including removal and installation of the RDM and backplane.

#### 12.7.1

## GPB 8000 Reference Distribution Module Field Replaceable Units and Parts

When ordering Field Replaceable Units (FRUs) for the GPB 8000 Reference Distribution Module (RDM), provide the FRU Kit Number. When ordering field replaceable parts, provide the part number. Contact Motorola Solutions Support Center (SSC) as needed. See [Motorola Solutions Support Center on page 162](#).

Table 59: GPB 8000 Reference Distribution Module Field Replaceable Units

Component Type	FRU Kit Number	Replacement Procedure
GPB 8000 Reference Distribution Module	DLN6966A	<a href="#">Replacing a GPB 8000 Reference Distribution Module on page 218</a>
Fan Module	DLN6898A	<a href="#">Replacing the Fan Assembly on page 177</a>
AC/48V DC Power Supply for DLN6966A	DLN6781A (0182516W14) or DLN6805 (0182516W20)	<a href="#">Replacing a Power Supply on page 178</a>
AC/48V DC Power Supply for DLN6569A	DLN6781A (0182516W14)	

Table 60: GPB 8000 Reference Distribution Module Field Replaceable Parts


Component Type	Part Number	Replacement Procedure
Power Supply Fan Module	5985167Y02	<a href="#">Replacing a Power Supply Fan on page 180</a>
Backplane	0180706H87	<a href="#">Replacing a GPB 8000 Reference Distribution Module Backplane on page 223</a>

#### 12.7.2

## Replacing a GPB 8000 Reference Distribution Module

Perform these procedures to replace a GPB 8000 Reference Distribution Module (RDM) when used with a GPW 8000 Receiver.

**Figure 82: GPB 8000 Reference Distribution Module**



**Prerequisites:** Before replacing the device, pull configuration and hardware information from the device into the Unified Network Configurator (UNC) by performing a “Pull All” procedure. See the “Scheduling the Pull of Device Configurations” in the *Unified Network Configurator* manual. This “Pull All” procedure may not be possible if communication is severed between the device and the UNC.

**Procedure:**

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground.
 

**CAUTION:** Wear the ESD strap throughout this procedure to prevent ESD damage to any components.
- 2 Locate the RDM being replaced.
- 3 If the RDM is not operational, go to [step 9](#).
- 4 Connect to the RDM Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 121](#).
- 5 Save the configuration to the service computer/laptop as follows:
  - a From the menu, select **File** → **Read Configuration From Device**.
  - b At the success message, click **OK**.
  - c From the menu, select **File** → **Save As**.
  - d On the **Properties Screen**, enter the <IP address> of the RDM. Click **OK**.
  - e Specify the directory location where you want to save the configuration file, and type a meaningful name for the file (use cpl as the extension or do not type an extension). Press **ENTER**.

The configuration is saved to the location indicated. The configuration file is reloaded later to the replacement RDM.

- 6 Disable the RDM as follows:
  - a From the menu, select **Service** → **Status Panel Screen**.  
The **Status Panel Screens** window appears.
  - b Select the **Reference Distribution Module** tab.

- c From the **User Requested State** list box, select **User Disabled**.

The RDM resets, after approximately two minutes, it is disabled.

- 7 If you choose to turn off the power, set the rocker switch on the front of the associated power supply to the Off (O) position.
- 8 Disconnect the Ethernet cable from the service port on the RDM module being replaced.
- 9 Remove the fan assembly to gain access to the RDM. See [Replacing the Fan Assembly on page 177](#).



**IMPORTANT:** Although the RDM can be swapped out without shutting the power off, minimize the amount of time that the fan assembly is removed, so the circuitry that remains powered on does not overheat and shut down.

- 10 Label and disconnect all cabling on the front of the RDM.
- 11 Using a T20 bit, loosen the two captive screws on the front of the RDM, so they disengage from the chassis.
- 12 Using the handle, gently pull the RDM straight out, along the guides on which it sits.
- 13 Slide in the replacement RDM along the guiding rails until it is engaged. A slight push may be needed to engage the module.

The LEDs on the RDM turn on when it is engaged.

- 14 Using a T20 bit, secure the RDM to the chassis with the two captive screws on the front of the module.
- 15 Reconnect all the cabling to the correct ports as previously labeled.
- 16 Reinstall the fan assembly. See [Replacing the Fan Assembly on page 177](#).
- 17 If you chose to turn off the power, set the rocker switch on the front of the associated power supply to the On (1) position.
- 18 Perform basic device configuration using the serial port in Configuration/Service Software (CSS). See [Connecting Through a Serial Port Link on page 116](#).
  - a Set the IP address of the device. See [Setting the Device IP Address and Pairing Number in CSS on page 118](#).
  - b Set the serial security services. See [Setting the Serial Security Services in CSS on page 119](#).
- 19 On systems with MAC Port Lockdown implemented, disable MAC Port Lockdown. The switch port needs to be Unlocked before connecting with CSS or performing a software download. See the MAC Port Lockdown manual for instructions on how to disable MAC Port Lockdown.
- 20 Perform a single device download to transfer and install the latest RDM software using Software Download Manager as follows:

- a Open the Software Download Manager application.



**CAUTION:** Load the correct version of the software. A mismatch in software versions may occur when replacing the RDM with an on-hand spare. If a mismatch in software versions occurs, it may cause all GPW 8000 Receivers at the site to go into a configuration mode of operation with a reason of 'Invalid Software Version'. To exit the receivers out of configuration mode, see [CSS Procedures → Changing from Configuration to Normal Mode](#) in the *CSS Online Help*.

If a mismatch in software versions occurs with an RDM, the mismatch may cause a 'critical malfunction', or if the RDM becomes active, may bring the entire site into a configuration mode of operation.

- b From the **Advanced Options** menu, select the transfer type.

- c From the menu, select **File** → **File Manager**.  
The **Software Depot File Manager** opens.
- d From the menu, select **Component Operations** → **Import Fileset**.  
The **Import a Fileset Into the Software Depot** dialog box appears.
- e Click **Browse** and search for the `swdlv3.cfg` file, or follow the path `E:\swdl\swdlv1.cfg` or `swdlv3.cfg`. Click **Open**.  
The file appears in the **Configuration File Path** field of the dialog box.
- f Click **Generate**. Click **OK**.  
The **Import a Fileset Into the Software Depot** dialog box closes and the software component appears in the **Components In the Software Depot** list of the **Software Depot File Manager** window
- g Exit the **Software Depot File Manager**.
- h From Software Download Manager, click **Open Single Device Mode**.
- i Enter the `<IP address>` of the device. Click **Connect**.  
A **Security Level** screen appears.
- j Choose the required security level. Click **OK**.
- k In the **Select an option** drop down list, select **Upgrade**.
- l In the **Operation Type**, select **Transfer and Install**.
- m In the **Application Type**, select **Reference Distribution Module**.
- n In the **Software Version** drop down list, select the appropriate software version.
- o In the **Bank Selection** drop down list, select the bank to receive the software. Select **Automatic** to store the software in the bank that is more suitable for the device.
- p Select **Start Operation**.
- q In the window that appears, click **Proceed**.  
If the transfer was successful, the progress bar in the **Operation Status** tab displays green.  
If the transfer failed, the progress bar displays red.

- 21** Perform basic device configuration using the Ethernet port in CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
  - a Set the current date and time. See [Setting the Date and Time in CSS on page 124](#).
  - b Set up the local Password Configuration (optional). See [Setting the Local Password Configuration in CSS on page 131](#).
- 22** Complete the configuration of the Information Assurance features in CSS, as follows:
  - a Change the SNMPv3 configuration and user credentials. See [Changing SNMPv3 Configuration and User Credentials in CSS on page 124](#).
  - b Create, update, or delete an SNMPv3 user. See [Adding or Modifying an SNMPv3 User in CSS on page 127](#).
  - c Verify the SNMPv3 credentials. See [Performing an SNMPv3 Connection Verification in CSS on page 127](#).
  - d Set the Software Download Manager (SWDL) transfer mode. See [Setting the SWDL Transfer Mode in CSS on page 129](#).

- e Configure DNS using the CSS. See Chapter 7, “Configuring DNS with CSS” in the *Authentication Services* manual.
- f Configure for Secure SHell (SSH). See Chapter 4, “Configuring SSH for Devices at an RF Site” in the *Securing Protocols with SSH* manual or see “Device Security Configuration – Remote Access/Login Banner (Ethernet)” in the *CSS Online Help*.
- g Restore the following Clear Protocols parameters in the Remote Access Configuration tab on the Device Security Configuration screen in CSS. See “Device Security Configuration – Remote Access/Login Banner (Ethernet)” in the *CSS Online Help*.
- h Enable RADIUS Authentication . See Chapter 7, “Configuring RADIUS Sources and Parameters with CSS” in the *Authentication Services* manual.
- i Enable Centralized Authentication. See Chapter 7, “Enabling/Disabling Centralized Authentication with CSS” in the *Authentication Services* manual.
- j Set the Local Cache Size for Centralized Authentication in CSS. See Chapter 7, “Setting the Local Cache Size for Central Authentication with CSS” in the *Authentication Services* manual.
- k Enable Centralized Event Logging (if required by your organization). See Chapter 6, “Enabling/Disabling Centralized Event Logging on Devices with CSS” and Chapter 1, “Event Logging Client Configuration” for proper hostnames in the *Centralized Event Logging* manual.
- l Set the NTP Server Settings. See [NTP Server Settings in CSS on page 130](#).

**23** From CSS, restore the Codeplug Archive from the backup. Reload the configuration file into the RDM, as follows:

- a From the menu, select **File** → **Open**. Locate and open the previously saved configuration file for the RDM.
-  **NOTICE:** If you were not able to back up the configuration from the previous RDM, you can use the configuration from your system build book, or use the default RDM configuration file. Specific settings for the RDM must still be configured. See **Site Controller Configuration & Service Help** → **GPB 8000 Reference Distribution** in the *CSS Online Help* for RDM detailed configuration instructions.
- b Locate and open the previously saved configuration file for the RDM.
- c On the **Properties** window, click **OK**.
- d When the **Progress Monitor** screen is complete, click **OK**.
- e From the menu, select **File** → **Write Configuration To Device**. Click **OK**.
- f On the Ethernet connection confirmation screen, click **OK**.
- g On the **Connection** screen, enter the <IP Address> and click **Connect**.
- h On the **SNMPv3 PassPhrase Prompt** dialog box, enter the **User Information** and **Passphrase Information**. Click **OK**. If Authentication Services are not enabled on a device, click **OK** when the dialog box appears.
- i On the confirmation screen, click **OK**.
- j When the **Progress Monitor** screen is complete, click **OK**.

The configuration from the file you selected is loaded into the RDM. Communication with the RDM is not available until the reset is complete.

**24** Read the RDM, as follows:

- a From the menu, select **File** → **Read Configuration From Device**.
- b On the confirmation screen, click **OK**.

c When the **Progress Monitor** screen is complete, click **OK**.

**25** Enable the RDM as follows:

a From the menu, select **Service** → **Status Panel Screen**.

The **Status Panel Screens** window appears.

b Select the **Reference Distribution** tab.

c From the **User Requested State** list box, select **Enabled**.

The RDM is enabled.

**26** If MAC Port Lockdown is enabled in the RDM, perform the following steps to disable then re-enable:



**NOTICE:** See the *MAC Port Lockdown* manual for instructions regarding MAC Port locking.

a On systems with MAC Port Lockdown, disable the lockdown.

b Re-enable the lockdown with the MAC address of the RDM.

c If the RDM being replaced is connected to an Ethernet port on a switch which implements MAC Port Lockdown (XHub), unlock the Ethernet switch port.

d Relock to the MAC address of the replacement RDM.

**27** Replace the RDM in the Unified Network Configurator (UNC). See “Replacing a Device” in the *Unified Network Configurator* manual.

**28** Discover the RDM in the Unified Event Manager (UEM). See the *Unified Event Manager* manual.

**29** Perform the following steps to verify that the RDM is operating properly:

a Verify the Status LED on the front of the RDM is green.


b Confirm proper operation using software tools, such as UEM, and CSS.

#### 12.7.3

### Replacing a GPB 8000 Reference Distribution Module Backplane

In a standalone GPB 8000 Reference Distribution Module (RDM), the backplane is the circuit board at the rear of the card cage, which connects the power supply and RDM modules.

**Figure 83: GPB 8000 Reference Distribution Module Connections to Backplane Through Backplane Cover**



**NOTICE:** The procedure assumes the following service access clearances:

- At least 2 ft access at the rear of the cabinet or rack, or
- At least 2 ft access on one side of the cabinet or rack, and at least 6 in. at the rear of the cabinet or rack


**Procedure:**

- 1 Wear an Electrostatic Discharge (ESD) strap and connect its cable to a verified good ground.
 

**CAUTION:** Wear this ESD strap throughout this procedure to prevent ESD damage to any components.
- 2 If the RDM modules are not operational, skip to [step 5](#).
- 3 Disable the RDM module as follows:
  - a Connect to the RDM module Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 121](#).
  - b From the menu, select **Service** → **Status Panel Screen**.  
The **Status Panel Screens** window appears.
  - c Select the **Reference Distribution Module** tab.
  - d From the **User Requested State** list box, select **User Disabled**.

The RDM module resets, and, after approximately two minutes, becomes disabled.
- 4 Repeat substeps a through d for the other RDM module.
- 5 Disconnect the Ethernet cable from the service port on the RDM module.
- 6 Push the power rocker switch to Off (O) on the power supply unit.
- 7 Label, then disconnect all cables from the RDM backplane.
- 8 Remove the power supply module from the chassis as follows:

- a Using a T20 bit, loosen the two captive screws on the front of the power supply, so that they disengage from the chassis.
  - b Pull on the metal handle to disengage the power supply module from the backplane, and remove it completely from the chassis.
- 8 Remove the fan assembly to gain access to the RDM modules. See [Replacing the Fan Assembly on page 177](#).
- 9 Disengage the RDM modules from the backplane as follows:
  - a Using a T20 bit, loosen the two captive screws on the front of each module, so that they disengage from the chassis.
  - b Using their handles, gently pull the modules until they disengage from the backplane.
- 10 Remove the fan cable from the backplane, accessing it from the front of the chassis, with the backplane still secured to the chassis, as follows:
  - a Follow the fan cable with your hand from its connector at the front of the chassis to its connection to the backplane, through the card-cage section from which you removed the power supply module.
  - b Remove the fan cable multi-pin connector from the backplane.
-  **NOTICE:** Squeeze the top and bottom of the connector and pull the connector straight out from the backplane.
- 11 Using a T20 bit, remove the seven screws that secure the metal backplane cover and the backplane circuit board to the rear of the RDM chassis.
- 12 Remove the metal backplane cover and the backplane circuit board.
- 13 Place the new backplane circuit board in the same location and orientation as the one that you removed.
- 14 Seat the seven screws, previously removed, into the backplane circuit board and backplane cover. Start all screws before fully securing them.
- 15 Secure the new backplane circuit board and the backplane cover to the rear of the RDM chassis with the seven screws. Torque to 18 +/- 2 in.-lb.
- 16 Connect the fan cable to the new backplane from the front of the chassis with the backplane secured to the chassis, as follows:
  - a Locate the port in the new backplane for the fan cable multi-pin connector.
  - b Follow the fan cable with your hand from its connector at the front of the chassis to the connector at the other end of the cable.
  - c Push the fan cable multi-pin connector, with the tab up, into the correct location in the backplane.

**Figure 84: Fan Cable Connector**

GTR\_GCP\_Fan\_Cable\_Connector

- 17 Slide the RDM modules into the new backplane. A slight push may be needed to engage the modules.
- 18 Secure the RDM modules to the chassis with the two captive screws on the front of each module.
- 19 Reinstall the fan assembly unit. See [Replacing the Fan Assembly on page 177](#).
- 20 Slide the power supply into the chassis, pushing gently until it seats in the new backplane.
- 21 Tighten the two captive screws on the front of the power supply.
- 22 Reconnect all cables at the rear of the RDM.
- 23 Set the power supply rocker switch to On (1).
- 24 Enable the RDMs modules as follows:
  - a Connect to the RDM module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
  - b From the menu, select **Service** → **Service Panel Screen**.  
The **Service Panel Screens** window appears.
  - c Select the **Reference Distribution Module** tab.
  - d In the **User Requested State** list box, select **Enabled**.  
The RDM module is enabled after approximately two minutes.
  - e Repeat substeps a through d for the other RDM module.
- 25 Verify that the LEDs indicate the modules you removed and reinstalled are operational.
  - The Status LEDs are green.

- The Alarm LEDs are off.
- The power supply Fan LED is off.

**26** Verify proper operation using software tools, such as Unified Event Manager, and Configuration/Service Software (CSS).

**27** Re-configure the Security Settings into the Backplane. See [Setting the Serial Security Services in CSS on page 119](#).

## 12.8

# GPB 8000 Reference Distribution Module LEDs


This information for GPB 8000 Reference Distribution Module (RDM) covers LED states.

### 12.8.1

## GPB 8000 Reference Distribution Module Software and Services- Controlled LEDs

The Software and Services-Controlled LEDs, visible on the front of a GPB 8000 Reference Distribution Module (RDM) with the service door open.

**Figure 85: RDM Software and Services-Controlled LEDs**



## 12.8.1.1

**GPB 8000 Reference Distribution Module Software-Controlled LEDs**

Table 61: RDM Software-Controlled LEDs

LED	Application Use	Green On	Green Blinking	Yellow On	Yellow Blinking	Red Blinking	Red On	Off
1	RDM state	RDM A: Active	RDM B: Active	Disabled (User Req)			Critical Malfunction (VV failure for SWDL )	
2	Unused							
3	Unused							
4	Unused							

## 12.8.1.2

**GPB 8000 Reference Distribution Module Services-Controlled LEDs**

**NOTICE:** The hardware controls LED 7, the Hardware Active LED. When active, it indicates that the GPB 8000 Reference Distribution Module (RDM) has ownership of the shared external interfaces.

Table 62: RDM Services-Controlled LEDs

LED	Services Use	Green On	Green Blinking	Yellow On	Yellow Blinking	Red Blinking	Red On	Off
5	SWDL/VLAN		Version validation or auto-VLAN detection	SWDL with common VLAN	SWDL with split VLAN		Not in SWDL with split VLAN	
6	Local hardware failure (all hardware including GNSS)			Warning (such as fan unplugged)	Minor hardware failure	Major hardware failure	Critical hardware failure (such as switch failure)	Good – no faults

Table continued...

LED	Services Use	Green On	Green Blinking	Yellow On	Yellow Blinking	Red Blinking	Red On	Off
7	Hardware Active	Active						

#### 12.8.2

## GPB 8000 Reference Distribution Module Status and Alarm LEDs

Definitions for each GPB 8000 Reference Distribution Module (RDM) status and alarm follow the assignment table.

Table 63: RDM Status and Alarm LED Assignment

LED	No Power	Lamp Test	Failure	Impaired	Booting Up	Online
Status LED (green)	Off	On	Off	On	Flash	On
Alarm LED (red)	Off	On	On	Flash	Off	Off

Table 64: RDM Status Definitions for the Status/Alarm LEDs

Status	Definitions
No Power	The RDM is currently without power, both primary power and auxiliary power. The No Power state is needed to tell the service technician that there is a fundamental problem.
Lamp Test	The Lamp Test state is used to verify that the indicators are operational.
Booting Up	The Booting Up state indicates that the device is booting or is undergoing diagnostics and is not yet ready to place into service. Even though no failure or impairment is identified, the RDM is not ready to place into service.
Online	The Online state is used to indicate that the RDM is fully operational. It may also be in an In Service mode. The Online state indicates that the device should not be removed as it is possibly involved in active calls.
Impaired	The RDM is not fully operational due to internal or external causes. Some corrective action must be taken to return to 100% functionality.
Failure	This status indicates a failure that is fixed only through replacement. If something other than a hardware fault is causing the state, the status is Impaired.

If both RDMs are Impaired, one RDM still provides the site reference to the GPW 8000 Receivers.

## 12.8.3

## GPB 8000 Reference Distribution Module Active/Inactive Status LEDs

The four active/inactive status LEDs are found on the top of the service port area of each GPB 8000 Reference Distribution Module (RDM). They are visible by opening the service door.

Table 65: RDM Active/Inactive Status LEDs

Active/Inactive LEDs	Description
SW	Status of connection between the RDMs.
CPU	Status of connection between the active CPU and the RDMs.
CP2	Status of connection between the RDM and the GPW 8000 Receivers.
SVC	Status of connection between the RDM and the service computer/laptop.

Table 66: RDM Active/Inactive LEDs

Information State	Link Status LED
Link Inactive	Off
Link Established (assumes no activity)	Green
Link Active	Yellow or Amber

## 12.8.4

## GPB 8000 Reference Distribution Module Link LEDs

The Link LEDs include the LEDs associated with the service port, GPB 8000 Reference Distribution Module (RDM) expansion ports, Net AUX port, and the Gateway port.

Table 67: RDM Link LEDs

LED	Link Inactive	Link Established (assumes no activity)	Link Active
Activity LED (yellow/amber)	Off	Off	Yellow/Amber constant
Link LED (green)	Off	Green constant	Green constant

## 12.9

## Recovering the GPB 8000 Reference Distribution Module

**When and where to use:** Perform this procedure to recover the GPB 8000 Reference Distribution Module (RDM) in the event of failure.

**Process:**

- 1 To rack mount, connect power, and ground see, [GPW 8000 Receiver Hardware Installation on page 79](#).

- 2 To cable the RDM, see [GPB 8000 Reference Distribution Module Installation on page 206](#).
- 3 To replace the RDM module within the chassis only, see [Replacing a GPB 8000 Reference Distribution Module on page 218](#) and follow steps 1 through 17.
- 4 To replace other hardware devices within the chassis, see [GPB 8000 Reference Distribution Module Field Replaceable Units and Parts on page 218](#).
- 5 To perform basic device configuration and SWDL download, see [Replacing a GPB 8000 Reference Distribution Module on page 218](#) and follow steps 18 through 29.

This page intentionally left blank.

## Chapter 13


# Standalone Expansion Hubs

The standalone Expansion Hubs (XHubs) are used only in receive-only trunked sites, and are installed in a standard rack including:

- GPB 8000 Reference Distribution Module (RDM)
- GPW 8000 Receivers

 **NOTICE:** The standalone XHub components are supported only for use with a trunked GPW 8000 Receiver.

**Figure 86: Expansion Hub**



The standalone XHub consists of one module and a fan module housed in a chassis.

Site architectures supported include:

- Trunked IP or circuit simulcast subsystem with receive-only subsite (receive-only remote site)
- Colocated trunked IP or circuit receive-only remote site at the prime site
- Trunked IP or circuit Single Transmit Receiver Voting (STRV) subsystem (receive-only remote site)

The XHub has three modes of operation:

- Normal Mode – the XHub extends the switching and interface capabilities of the GPW 8000 Receivers or RDMs. In normal mode, the RDM configures the Ethernet switch.
- Impaired Normal Mode – occurs when one of the links between the RDM and the XHub is lost. The other XHub remains active to pass the traffic.
- Standalone Mode – requires External 5 MHz and 1PPS, either as separate signals or as one combined 5 MHz/1PPS signal. 1PPS generates the 5 MHz frequency reference for the GPW 8000 Receivers even if it is not used by the GPW 8000 Receiver.

### 13.1

## XHub Port Default Speed/Duplex Settings

Table 68: XHub Port Default Speed/Duplex

Switch Port	Speed/Duplex
Base Radio 1	100BaseT/Full Duplex
Base Radio 2	100BaseT/Full Duplex
Base Radio 3	100BaseT/Full Duplex
Base Radio 4	100BaseT/Full Duplex
Base Radio 5	100BaseT/Full Duplex
Base Radio 6	100BaseT/Full Duplex
Alarm	Auto-Negotiate
Site Controller Expansion	100BaseT/Full Duplex
Net Aux	Auto-Negotiate

### 13.2

## Expansion Hub Field Replaceable Units and Parts

When ordering Field Replaceable Units (FRUs) for the Expansion Hub (XHub), provide the FRU Kit Number. When ordering field replaceable parts, provide the part number. Contact Motorola Solutions Support Center (SSC) as needed. See [Motorola Solutions Support Center on page 162](#).

Table 69: XHub Field Replaceable Units

Component Type	FRU Kit Number	Replacement Procedure
Expansion Hub Module	DLN6677A	<a href="#">Replacing the Expansion Hub on page 234</a>
Fan Module	DLN6898A	<a href="#">Replacing the Fan Assembly on page 177</a>

Table 70: XHub Field Replaceable Parts


Component Type	Part Number	Replacement Procedure
Power Supply Fan Module	5985167Y02	<a href="#">Replacing a Power Supply Fan on page 180</a>
Backplane	0180706H87	<a href="#">Replacing a GPB 8000 Reference Distribution Module Backplane on page 223</a>

### 13.3

## Replacing the Expansion Hub

Perform these procedures to replace an Expansion Hub (XHub) when used with a GPW 8000 Receiver.

**Figure 87: Expansion Hub**



**IMPORTANT:** The XHub can be hot swapped out without losing functionality.

For installation illustrations, see [Standalone Expansion Hub Connections on page 235](#).

**Procedure:**

- 1 Wear an Electrostatic Discharge (ESD) strap and connect its cable to a verified good ground. Wear this strap throughout this procedure to prevent ESD damage to any components.
- 2 Remove the fan assembly to gain access to the Expansion Hub module. See [Replacing the Fan Assembly on page 177](#).

**IMPORTANT:** The XHub module can be swapped out without shutting the power off.


- 3 Label and disconnect all cabling on the front of the Expansion XHub.
- 4 Using T20 bit, loosen the two captive screws holding the XHub to the chassis.
- 5 Using the handle, gently pull the used XHub straight out, along the guides on which it sits.
- 6 Slide in the replacement XHub module along the guiding rails until it is engaged. A slight push is needed to engage it.
- 7 Using a T20 bit, secure the XHub module with the two captive screws.
- 8 Reconnect all the cabling to the correct ports as previously labeled.
- 9 Reinstall the fan assembly. See [Replacing the Fan Assembly on page 177](#).
- 10 Perform the following steps to verify that the XHub is operating properly:
  - a Verify the Link Status LED for the RJ-45 EXP SN Input port on the front of the new XHub is green.
  - b Confirm the Status LED on the front of the XHub is green.
  - c Using software tools, such as Unified Event Manager (UEM), check the alarms of the equipment.

#### 13.3.1

### Standalone Expansion Hub Connections

The Expansion Hub (XHub) backplane connectors are shown in the following figure.

**Figure 88: XHub Backplane Connectors**



The table provides an example of XHub connections (rear, chassis) supporting standalone trunked GPW 8000 Receivers and GPB 8000 Reference Distribution Modules (RDMs).

**Table 71: XHub Backplane Connections**

Port	Description
RFDS	Not in use
Remote GPS 'A'	Not in use
Internal Alarm	Not in use
Remote GPS 'B'	Not in use
External Alarm	Not in use
SC A to Base Radio 1-6/ RJ-45	Connection between XHUB A and the GPW 8000 Receiver.
SC B to Base Radio 1-6/ RJ-45	Connection between XHUB B and the GPW 8000 Receiver.
EXT FREQ REF	Not in use
1PPS	Not in use
Battery Temp	Not in use
AUX PWR Output	Not in use
AUX PWR Input	28 VDC INPUT from GPW 8000 Receiver chassis AUX PWR Output.
+ Batt/DC	Not in use
AC	Not in use
GND	Two grounding lugs and cable.


Table 72: Standalone XHub and GPW 8000 Receiver Cabling Detail (Example)

Device	Port	Connects to Device /Port
XHub RDM A, Rear (Chassis)	SC A-2 to Base Radio 2	GPW 8000 Rear (Chassis) / XVCR2 / LAN A
XHub A, Rear (Chassis)	SC A-1 to Base Radio 1	GPW 8000 Rear (Chassis) / XVCR1 / LAN A
XHub A, Rear (Chassis)	SC A-4 to Base Radio 4	GPW 8000 Rear (Chassis) / XVCR4 / LAN A
XHub A, Rear (Chassis)	SC A-3 to Base Radio 3	GPW 8000 Rear (Chassis) / XVCR3 / LAN A
XHub A, Rear (Chassis)	SC A-6 to Base Radio 6	GPW 8000 Rear (Chassis) / XVCR6 / LAN A
XHub A, Rear (Chassis)	SC A-5 to Base Radio 5	GPW 8000 Rear (Chassis) / XVCR5 / LAN A
XHub B, Rear (Chassis)	SC B-2 to Base Radio 2	GPW 8000 Rear (Chassis) / XVCR2 / LAN B
XHub B, Rear (Chassis)	SC B-1 to Base Radio 1	GPW 8000 Rear (Chassis) / XVCR1 / LAN B
XHub B, Rear (Chassis)	SC B-4 to Base Radio 4	GPW 8000 Rear (Chassis) / XVCR4 / LAN B
XHub B, Rear (Chassis)	SC B-3 to Base Radio 3	GPW 8000 Rear (Chassis) / XVCR3 / LAN B
XHub B, Rear (Chassis)	SC B-6 to Base Radio 6	GPW 8000 Rear (Chassis) / XVCR6 / LAN B
XHub B, Rear (Chassis)	SC B-5 to Base Radio 5	GPW 8000 Rear (Chassis) / XVCR5 / LAN B



**NOTICE:** Route the cables from the XHub to GPB 8000 RDM out the slot in the side of the fan housing.

**Figure 89: XHub Front Connectors**



**Table 73: XHub Front Connections**

Port	Port Type	Description
NET AUX	RJ-45	Provides connection to auxiliary devices to the LAN.
EXPSN Input (CP3)	RJ-45	Provides connection between XHubs and RDMs.

#### 13.4

### Expansion Hub LEDs

The LEDs on the Expansion Hub are in the front of the Expansion Hub.

Figure 90: Expansion Hub LEDs




Table 74: Expansion Hub LEDs with Description

LED Label	LED Description
1	A hardware controlled green "MODE" LED. When illuminated, it indicates that the XHub is operating in the 'Normal' or 'Impaired Normal' mode.
7	A hardware controlled green "ACTIVE" LED. When illuminated, it indicates that the XHub has ownership of the redundant XHub shared external interfaces.
Reset	Not in use.
Status	LED is software-controlled when the XHub is operating in the Normal mode. When illuminated, Green = Online.
Alarm	LED is software-controlled when the XHub is operating in the Normal mode. When illuminated, Red = Failure.

The Status and Alarm LEDs work together to indicate status on the Expansion Hub. The Impaired State of the XHub indicates No Connection with the GPB 8000 Reference Distribution Module.

Table 75: Expansion Hub Status/Alarm LED Assignment

LED	No Power	Lamp Test	Failure	Impaired	Online
Status LED (green)	Off	On	Off	On	On
Alarm LED (red)	Off	On	On	Flash	Off

This page intentionally left blank.

## Appendix A

# Conventional GPW 8000 Receiver Option Kits

The required hardware and cables for the CA01958AA T2-2R Receiver Mute option kit are listed in this section.

This appendix covers the option kits that are available for the conventional GPW 8000 Receiver. Each section provides the necessary information to order, install, and configure each option kit.

### A.1

#### T2-2R, T3-3R, and T4-4R Receiver Mute Option Kits

The required hardware and cables for the CA01958AA T2-2R Receiver Mute option kit are listed in this section.

These option kits add the capability of simplex operation, while expanding the receive capability over two or more separate RF channels through a single antenna. The option kits allow a single GTR 8000 Base Radio to be interfaced with up to three GPW 8000 Receivers. The GTR 8000 Base Radio provides both transmit and receive functionality. The GPW 8000 Receivers are used as additional receive channels.

Four different Receiver Mute option kits are available:

- T2-2R Receiver Mute Option CA01958AA (ADD: 2 GPW 8000 Receiver Hardware Kit - 4-Wire Analog)
- T3-3R Receiver Mute Option CA01959AA (ADD: 3 GPW 8000 Receiver Hardware Kit - 4-Wire Analog)
- T4-4R Receiver Mute Option CA01960AA (ADD: 4 GPW 8000 Receiver Hardware Kit - 4-Wire Analog)
- Tn-nR Receiver Mute Option CA01961AA (ADD: GPW 8000 Receiver Hardware No Splitter Kit - 4-Wire Analog)



**NOTICE:** All Field Replaceable Unit (FRU), kit, and part numbers for all required components in each kit are listed in the parts list section for each receiver mute kit.

A single standalone T7039A GTR 8000 Base Radio is required for each option kit. The option kit name determines the number of GPW 8000 Receivers. For example, a T2-2R option kit requires one GTR 8000 Base Radio and one GPW 8000 Receiver. A T3-3R requires one base radio and two receivers, and so on. The number defines the total number of G-series devices.

##### A.1.1


#### T2-2R Receiver Mute Option Kit

The required hardware and cables for the CA01958AA T2-2R Receiver Mute option kit are listed in this section.

The CA01958AA T2-2R Receiver Mute option kit is used with a standalone GTR 8000 Base Radio and one GPW 8000 Receiver. All option kit hardware and cables required are included in [Table 76: T2-2R Receiver Mute Option Kit Parts List on page 242](#).



**NOTICE:** The illustrations show a GPW 8000 Receiver with one chassis and one transceiver. A dual-slot chassis with two transceivers is available.

**Figure 91: T2-2R Receiver Mute Option Kit Wiring Diagram**

**NOTICE:** See [System Connector Ports \(Conventional\) on page 96](#) for a detailed description of the system connector pinouts.



**NOTICE:** See [Figure 93: T4-4R Receiver Mute Configuration on page 246](#) for an example of a Receiver Mute configuration. However, the T2-2R Receiver Mute configuration only has one GPW 8000 Receiver.

#### A.1.1.1

### T2-2R Receiver Mute Option Kit Parts List

The required hardware and cables for the CA01958AA T2-2R Receiver Mute option kit are listed in this section.

**Table 76: T2-2R Receiver Mute Option Kit Parts List**

FRU	Kit	Part Number	Description	Quantity
DLN6795			<b>T2-2R RECEIVER MUTE</b>	1
A	CLN8788		<b>HARDWARE, T2-2R RECEIVER MUTE</b>	1
	A	0182017V14	SPLITTER, 2 WAY	1
		0285854Y01	NUT, M6-GROUND WIRE TO STUDS ON TRAY	2
		0310909E32	SCRMCH M3X0.5X8 SPLTR MTG	4

*Table continued...*

FRU	Kit	Part Number	Description	Quantity
		0310909A54	SCREW 3.5X30MM ANT RELAY MTG	2
		0310909E46	SCRMCH M3.5X0.6X8 ANT CONN & SIDE BRKTS	12
		0312016A49	SCREW FRONT PANEL TO CHASSIS (blk)	4
		0312016A54	SCRTPG M6 X 1 X 10 (blk) TRAY TO RACK	4
		07009370001	BRACKET CHASSIS SUPPORT	2
		27009304001	CHASSIS, PERIPHERAL	1
		40009272002	RELAY, COAXIAL 29V	1
		5682347B20	BAG FOR SCREWS	1
		64009317001	PANEL, FRONT	1
		0285504U05	CAGE NUT, M6 FOR CABINET MTG	4
		0310909C91	SCREW M6-GROUND CABLE TO BUS BAR AND TRAY TO CABINET CAGE NUTS	5
<b>CKN6941A</b>			<b>CABLES, T2-2R RECEIVER MUTE</b>	1
		30009380001	CABLE, SAC	1
		3013942M23	CBL N-N M-M 75 CM	1
		3013942P19	CBL N-N M-F PNL 55 CM	1
		3013943E20	CBL N-BNC M-M 60 CM	1
		3013943N29	CBL BNC-BNC M-M 110 CM	1
		3013943N30	CBL BNC-BNC M-M 120 CM	1
		3084848Y01	CABLE RELAY W/TEMP	1
		3071488H08	CABLE, GROUND TRAY TO BUS BAR	1
		58009291001	Adapter, N Plug to BNC Jack	2
		4210217A04	STRAP TIE .184X7.31 NYL BLK	10
		5682347B21	BAG, PLASTIC 584 X 431 MM	1
		SVCWARR12	12 MONTH STANDARD WARRANTY	1


#### A.1.2

#### T3-3R Receiver Mute Option Kit

The CA01959AA T3-3R Receiver Mute option kit is used with a standalone GTR 8000 Base Radio and two GPW 8000 Receivers. All option kit hardware and cables required are included in [Table 77: T3-3R Receiver Mute Option Kit Parts List on page 244](#).



**NOTICE:** The illustrations show a GPW 8000 Receiver with one chassis and one transceiver. A dual-slot chassis with two transceivers is available.

**Figure 92: T3-3R Receiver Mute Option Kit Wiring Diagram**

**NOTICE:** See [System Connector Ports \(Conventional\) on page 96](#) for a detailed description of the system connector pinouts.



**NOTICE:** See [Figure 93: T4-4R Receiver Mute Configuration on page 246](#) for an example of a Receiver Mute configuration. However, the T3-3R Receiver Mute configuration only has two GPW 8000 Receivers.

#### A.1.2.1

### T3-3R Receiver Mute Option Kit Parts List

The required hardware and cables for the CA01959AA T3-3R Receiver Mute option kit are listed in this section.

**Table 77: T3-3R Receiver Mute Option Kit Parts List**

FRU	Kit	Part Number	Description	Quantity
DLN6796			T3-3R RECEIVER MUTE	1
A	CLN8789		HARDWARE, T3-3R RECEIVER MUTE	1
A		0182017V15	SPLITTER, 3WAY	1

*Table continued...*

FRU	Kit	Part Number	Description	Quantity
		0285854Y01	NUT, M6-GROUND WIRE TO STUDS ON TRAY	2
		0310909E32	SCRMCH M3X0.5X8 SPLTR MTG	4
		0310909A54	SCREW 3.5X30MM ANT RELAY MTG	2
		0310909E46	SCRMCH M3.5X0.6X8 ANT CONN & SIDE BRKTS	12
		0312016A49	SCREW FRONT PANEL TO CHASSIS (blk)	4
		0312016A54	SCRTPG M6 X 1 X 10 (blk) TRAY TO RACK	4
		07009370001	BRACKET CHASSIS SUPPORT	2
		27009304001	CHASSIS, PERIPHERAL	1
		40009272002	RELAY, COAXIAL 29V	1
		5682347B20	BAG FOR SCREWS	1
		64009317001	PANEL, FRONT	1
		0285504U05	CAGE NUT, M6 FOR CABINET MTG	4
		0310909C91	SCREW M6-GROUND CABLE TO BUS BAR AND TRAY TO CABINET CAGE NUTS	5
<b>CKN694 2A</b>			<b>CABLES, T3-3R RECEIVER MUTE</b>	1
		30009380001	CABLE, SAC	1
		3013942M23	CBL N-N M-M 75 CM	1
		3013942P19	CBL N-N M-F PNL 55 CM	1
		3013943E20	CBL N-BNC M-M 60 CM	1
		3013943N29	CBL BNC-BNC M-M 110 CM	1
		3013943N30	CBL BNC-BNC M-M 120 CM	1
		3013943N31	CBL BNC-BNC M-M 130 CM	1
		3084848Y01	CABLE RELAY W/TEMP	1
		3071488H08	CABLE, GROUND TRAY TO BUS BAR	1
		58009291001	Adapter, N Plug to BNC Jack	3
		4210217A04	STRAP TIE .184X7.31 NYL BLK	10
		5682347B21	BAG, PLASTIC 584 X 431 MM	1
		SVCWARR12	12 MONTH STANDARD WARRANTY	1

### A.1.3


### T4-4R Receiver Mute Option Kit

The CA01960AA T4-4R Receiver Mute option kit is used with a standalone GTR 8000 Base Radio and three GPW 8000 Receivers. All option kit hardware and cables required are included in [Table 78: T4-4R Receiver Mute Option Kit Parts List on page 247](#).




**NOTICE:** The photos and illustrations show a GPW 8000 Receiver with one chassis and one transceiver. A dual-slot chassis with two transceivers is available.

**Figure 93: T4-4R Receiver Mute Configuration**



A712\_T44R\_Receiver\_Mute\_Config1


**Figure 94: T4-4R Splitter and Antenna Relay Tray**



A712\_T44R\_Splitter\_Relay\_Tray1

The wiring diagram for the T4-4R Receiver Mute option kit outlines the connections for all cables and provides part numbers for each type.

Figure 95: T4-4R Receiver Mute Option Kit Wiring Diagram



A712\_T44R\_Receiver\_Mute\_A



**NOTICE:** See [System Connector Ports \(Conventional\)](#) on page 96 for a detailed description of the system connector pinouts.

#### A.1.3.1

### T4-4R Receiver Mute Option Kit Parts List

The required hardware and cables for the CA01960AA T4-4R Receiver Mute option kit are listed in this section.

Table 78: T4-4R Receiver Mute Option Kit Parts List

FRU	Kit	Part Number	Description	Quantity
DLN6797	A		T4-4R RECEIVER MUTE	1

*Table continued...*

FRU	Kit	Part Number	Description	Quantity
CLN8790 A			<b>HARDWARE, T4-4R RECEIVER MUTE</b>	1
		0182017V16	SPLITTER, 4WAY	1
		0285854Y01	NUT, M6-GROUND WIRE TO STUDS ON TRAY	2
		0310909E32	SCRMCH M3X0.5X8 SPLTR MTG	4
		0310909A54	SCREW 3.5X30MM ANT RELAY MTG	2
		0310909E46	SCRMCH M3.5X0.6X8 ANT CONN & SIDE BRKTS	12
		0312016A49	SCREW FRONT PANEL TO CHASSIS (blk)	4
		0312016A54	SCRTPG M6 X 1 X 10 (blk) TRAY TO RACK	4
		07009370001	BRACKET CHASSIS SUPPORT	2
		27009304001	CHASSIS, PERIPHERAL	1
		40009272002	RELAY, COAXIAL 29V	1
		5682347B20	BAG FOR SCREWS	1
		64009317001	PANEL, FRONT	1
		0285504U05	CAGE NUT, M6 FOR CABINET MTG	4
CKN694 3A			<b>CABLES, T4-4R RECEIVER MUTE</b>	1
		30009380001	CABLE, SAC	1
		3013942M23	CBL N-N M-M 75 CM	1
		3013942P19	CBL N-N M-F PNL 55 CM	1
		3013943E20	CBL N-BNC M-M 60 CM	1
		3013943N29	CBL BNC-BNC M-M 110 CM	1
		3013943N30	CBL BNC-BNC M-M 120 CM	1
		3013943N31	CBL BNC-BNC M-M 130 CM	2
		3084848Y01	CABLE RELAY W/TEMP	1
		3071488H08	CABLE, GROUND TRAY TO BUS BAR	1
		58009291001	Adapter, N Plug to BNC Jack	4
		4210217A04	STRAP TIE .184X7.31 NYL BLK	10
		5682347B21	BAG, PLASTIC 584 X 431 MM	1
		SVCWARR12	12 MONTH STANDARD WARRANTY	1

## A.1.4

**Expected Site Performance for T2-2R, T3-3R, and T4-4R Receiver Mute**

The additional cables, splitter, and relay affect receiver sensitivity and transmitter output power. Use the attenuation values found in this section to determine the expected site performance. Other base radio and receiver specifications are not affected.

Table 79: Total Transmit and Receive Attenuation for T2-2R, T3-3R, and T4-4R Receiver Mute

Band Type Attenuation	CA01958AA: T2-2R	CA01959AA: T3-3R	CA019860AA: T4-4R
VHF Receive (Rx)	3.7 dB typical 4.0 dB maximum	5.6 dB typical 5.9 dB maximum	7.0 dB typical 7.3 dB maximum
VHF Rx Port to Port Isolation	32 dB typical	27 dB typical	30 dB typical
VHF Transmit (Tx)	0.3 dB typical 0.4 dB maximum	0.3 dB typical 0.4 dB maximum	0.3 dB typical 0.4 dB maximum
UHF Rx	4.2 dB typical 4.4 dB maximum	6.3 dB typical 6.5 dB maximum	7.5 dB typical 7.8 dB maximum
UHF Rx Port to Port Isolation	28 dB typical	21 dB typical	25 dB typical
UHF Tx	0.5 dB typical 0.6 dB maximum	0.5 dB typical 0.6 dB maximum	0.5 dB typical 0.6 dB maximum
800 MHz Rx	5.1 dB typical 5.4 dB maximum	7.2 dB typical 7.5 dB maximum	8.5 dB typical 8.8 dB maximum
800 MHz Rx Port to Port Isolation	28 dB typical	25 dB typical	25 dB typical
800 MHz Tx	0.8 dB typical 1.0 dB maximum	0.8 dB typical 1.0 dB maximum	0.8 dB typical 1.0 dB maximum

## A.1.5

**Tn-nR Receiver Mute Option Kit**

The CA01961AA Tn-nR Receiver Mute option kit is used with a standalone GTR 8000 Base Radio and up to three GPW 8000 Receivers.




**NOTICE:** The illustrations show a GPW 8000 Receiver with one chassis and one transceiver. A dual-slot chassis with two transceivers is available.

**Figure 96: Tn-nR Receiver Mute Option Kit Wiring Diagram**

Tn-nR Receiver Mute Kit

G-Series Option: CA01961AA



A712\_TnnR\_Receiver\_Mute\_A



**NOTICE:** See [System Connector Ports \(Conventional\) on page 96](#) for a detailed description of the system connector pinouts.



**NOTICE:** The antenna relay is mounted on the backplane of the GTR 8000 Base Radio. The only cable used with the Tn-nR Receiver Mute option kit is the control cable. All other required option kit hardware is included in [Table 80: Tn-nR Receiver Mute Option Kit Parts List on page 250](#).

**A.1.5.1****Tn-nR Receiver Mute Option Kit Parts List**

The required hardware and cable for the CA01961AA Tn-nR Receiver Mute option kit are listed in this section.

**Table 80: Tn-nR Receiver Mute Option Kit Parts List**

FRU	Kit	Part Number	Description	Quantity
DLN6798			RCVR SOFT NO SPLITTER	1
A	CKN6944		CABLES, RCVR SOFT NO SPLITTER	1
	A	30009380001	CABLE, SAC	1
		4210217A04	STRAP TIE .184X7.31 NYL BLK	10

*Table continued...*

FRU	Kit	Part Number	Description	Quantity
		5682347B21	BAG, PLASTIC 584 X 431 MM	1
		SVCWARR12	12 MONTH STANDARD WARRANTY	1

## A.1.6

**Installing the T2-2R, T3-3R, and T4-4R Receiver Mute Option Kits****Procedure:**

- 1 Install the standalone GTR 8000 Base Radio and GPW 8000 Receivers according to the processes and procedures in the Base Radio or Receiver Installation chapter.
 

 **WARNING:** To guard against personal injury and/or damage to equipment, place the base radio to Service Mode when performing service. Transmit inhibiting the base radio within the **Station Status** screen in the Configuration/Service Software (CSS) also prevents the transmitter from keying. Place the base radio back to Normal Mode when service is complete.

 **NOTICE:** See [Figure 93: T4-4R Receiver Mute Configuration on page 246](#) for an example of the GTR 8000 Base Radio and GPW 8000 Receivers installed in a rack. Leave no spaces between the devices in a rack or cabinet installation. Leave enough space above the splitter and antenna relay tray to allow room for connecting cables.
- 2 If the devices are in Normal Mode, ensure that each device is placed in Service Mode, as follows:
  - a Connect to the transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
  - b From the menu, select **File** → **Read Configuration From Device**.
  - c From the menu, select **Service** → **Test And Measurement Screen**.
  - d Click **Change to Service Mode**.
  - e At the confirmation screen, click **OK**.

The device halts activity in the current mode and switches operation to the requested mode.

 **NOTICE:** If you choose to turn off the power, set the rocker switch on the front of the associated power supply to the Off (O) position.

  - f Disconnect the Ethernet cable from the transceiver module Ethernet service port.
  - g Repeat for each device in the configuration.
- 3 Remove the fan module to gain access to the Transceiver Option Card (TOC) on the transceiver module. See [Replacing the Fan Assembly on page 177](#) for details.
- 4 Connect cables to each device according to its relevant wiring diagram.
  - For a T2-2R Receiver Mute configuration, see [Figure 91: T2-2R Receiver Mute Option Kit Wiring Diagram on page 242](#) for details.
  - For a T3-3R Receiver Mute configuration, see [Figure 92: T3-3R Receiver Mute Option Kit Wiring Diagram on page 244](#) for details.
  - For a T4-4R Receiver Mute configuration, see [Figure 95: T4-4R Receiver Mute Option Kit Wiring Diagram on page 247](#) for details.
  - For a Tn-nR Receiver Mute configuration, see [Figure 96: Tn-nR Receiver Mute Option Kit Wiring Diagram on page 250](#) for details.



**NOTICE:** When the GTR 8000 Base Radio or GPW 8000 Receiver is ordered with the preselector option, the type N to BNC adaptor (58009291001) must be used on the receiver end of RF cables. See [Figure 93: T4-4R Receiver Mute Configuration on page 246](#) for an example of how to route cables.

- 5 Replace the fan modules for the base radio and receivers. See [Replacing the Fan Assembly on page 177](#).



**NOTICE:** If you chose to turn off the power, set the rocker switch on the front of the associated power supply to the On (I) position.

- 6 Place each device to Normal Mode, as follows:

- a Connect to the transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
- b From the menu, select **File** → **Read Configuration From Device**.
- c From the menu, select **Service** → **Test And Measurement Screen**.
- d Click **Change to Normal Mode**.
- e At the confirmation screen, click **OK**.

The device halts activity in the current mode and switches operation to the requested mode.

- f Disconnect the Ethernet cable from the transceiver module Ethernet service port.
- g Repeat for each device in the configuration.

#### A.1.7

## Configuring the T2-2R, T3-3R, and T4-4R Receiver Mute Option Kits


**Prerequisites:** Ensure that all required installation procedures have been performed for the base radio and receiver and that the devices have been powered up.

**When and where to use:** This procedure is used to configure the WildCard Tables for a Receiver Mute configuration using the Configuration/Service Software (CSS).

#### Procedure:

- 1 If necessary, perform the initial configuration for the base radio and receiver. See [Device Configuration in CSS on page 115](#) for details.
- 2 Connect to the Ethernet port on the device. See [Connecting Through an Ethernet Port Link on page 121](#) for details.
- 3 From the menu, select **File** → **Read Configuration From the Device**.
- 4 From the navigation pane, select **Hardware Configuration**. Set **Station Type [R]** to **Analog Only**.
- NOTICE:** When configuring GPW 8000 Receivers, the **Hardware Platform [R]** parameter is set to **GPW 8000 Satellite Receiver**. The **Antenna Relay [R]** parameter is not configurable for GPW 8000 Receivers.
- 5 Set **Antenna Relay [R]** to **Enabled**.
- NOTICE:** Use the default value of 30 ms for the Antenna Relay Delay. This step is not required for GPW 8000 Receivers.
- 6 From the navigation pane, select **WildCard Tables**. Click **Set to Default** to add default WildCard tables.

Figure 97: CSS - WildCard Tables Example



7 Click **Yes** to reset the WildCard Tables to their default structure. The following default WildCard Tables are created:



**NOTICE:** WildCard Table numbers are arbitrary and shown for illustration purposes. Memory size and the number of States and Commands in each table limit the maximum number of WildCard tables.

Wild-Card Table	Descrip-tion	States and Condi-tion		Actions		Inactions	
		State	Value	Com-mand	Value	Com-mand	Value
1	In-cabi-net RPT	Input 6	n/a	In-cabi-net Re-peat ON	n/a	In-Cabi-net Re-peat OFF	n/a
2	Rx In-hibit	Input 7	n/a	RX IN-HIBIT	n/a	RX EN-ABLE	n/a
3	External PTT	Input 5	n/a	Key from Wi-deband	n/a	Dekey from Wi-deband	n/a
4	RD STAT-RX ACT	RX Qualifi-ers Met	n/a	Set Out-put (1..12)	7	Clear Output (1..12)	7
5	Tx In-hibit	Input 3	n/a	TX IN-HIBIT	n/a	TX EN-ABLE	n/a
6	TRC Function Tone (1..17)	1	1	Monitor	n/a	NULL	n/a
7	TRC Function (1..17)	2	2	Channel (1..16)	1	NULL	n/a

Table continued...

				Key from Wireline	n/a	n/a	n/a
8	LLGT Detect	n/a	NULL	n/a	Dekey from Wireline	n/a	n/a
9	T4 if CH2 Conf	TRC Function (1..17)	3	Channel (1..16) Key from Wireline	2 n/a	NULL n/a	n/a
10	T5 if CH3 Conf	TRC Function (1..17)	8	Channel (1..16) Key from Wireline	3 n/a	NULL n/a	n/a



**NOTICE:** Table configurations are selected from the TABLE parameter. See [Figure 97: CSS - WildCard Tables Example on page 253](#) for location of parameter fields.

- For all Receiver Mute Configurations, click **Add** and populate the new WildCard table to mute external receivers:

Wild-Card Table	Description	States and Condition		Actions		Inactions	
		State	Value	Com- mand	Value	Com- mand	Value
11	Mute Ext RXs	Analog Wireline PTT	n/a	Set Out- put (1..12)	3	Clear Output (1..12)	3
				Set Out- put (1..12)	4	Clear Output (1..12)	4
				Set Out- put (1..12)	5	Clear Output (1..12)	5

- For a T4-4R configuration, click **Add** and populate the new WildCard table to control channel 4, as follows



**NOTICE:** The description field is limited to 14 characters, including spaces.

WildCard Table	Description	States and Condition		Actions		Inactions	
		State	Value	Com- mand	Value	Com- mand	Value
12	TRC Function (1..17)	9	Channel (1..16)	4	NULL		
			Key from Wireline	n/a			



**NOTICE:** The function tones used in these tables must be correlated with the function tones set in the console.

**10** From the menu, select **File** → **Write Configuration To Device**.

**11** From the menu, select **Tools** → **Disconnect** to terminate the connection to the device.

**12** Repeat steps 1–7 for all GPW 8000 Receivers.



**NOTICE:** Only the default WildCard tables are required for the GPW 8000 Receivers.

**13** For GPW 8000 Receivers, edit TABLE 2 and change the **State and Conditions** from **Input 7** to **Input 4**.

**14** From the menu, select **File** → **Write Configuration To Device**.

**15** From the menu, select **Tools** → **Disconnect** to terminate the connection to the device.


## A.2

### T1-2R with Talk-Around Option Kit

The CA01957AA T1-2R with a Talk-Around option kit adds the capability of listening to the output transmit (Tx) frequency of the base radio when the base radio is not transmitting. This capability allows the console operator to listen to any talk-around (direct) operation. A GPW 8000 Receiver is used to monitor the output frequency.

A standalone T7039A GTR 8000 Base Radio is required. One GPW 8000 Receiver must be ordered without this option. This option kit includes one RF (transmit/receive) antenna relay, control cable, RF cables, and mounting hardware. The base radio must be ordered with the appropriate duplexer option.

All option kit hardware and cables required are included in [Table 81: T1-2R with Talk-Around Option Kit Parts List on page 256](#).

**Figure 98: T1-2R Talk-Around Option Kit Wiring Diagram**

A712\_T12R\_TalkAround\_A



**NOTICE:** See [System Connector Ports \(Conventional\) on page 96](#) for a detailed description of the system connector pinouts.



**NOTICE:** The antenna relay is mounted on the backplane of the GTR 8000 Base Radio.

#### A.2.1

### T1-2R with Talk-Around Option Kit Parts List

The required hardware and cables for the CA01957AA T1-2R with a Talk-Around option kit are listed in this section.

Table 81: T1-2R with Talk-Around Option Kit Parts List

FRU	Kit	Part Number	Description	Quantity
DLN6799			T1-2R W/TALKAROUND	1
A	CLN8792		HARDWARE, T1-2R W/TALKAROUND	1
	A	0310909A54	SCREW 3.5X30 MM ANT RELAY MTG	2
		40009272002	RELAY, COAXIAL 29 V	1

Table continued...

FRU	Kit	Part Number	Description	Quantity
CKN694 5A		5682347B20	BAG FOR SCREWS	1
			<b>CABLES, T1-2R W/TALKAROUND</b>	1
		3084921Y09	CBL, ASSY, COAX, 55CM, N-TO-QN	1
		4285026Y01	CLIP, CABLE RETAINER	1
		3013943E25	CBL N-BNC M-M 85CM	1
		3084848Y01	CABLE RELAY W/TEMP	1
		4210217A04	STRAP TIE .184X7.31 NYL BLK	10
		5682347B21	BAG, PLASTIC 584 X 431 MM	1
		SVCWARR12	12 MONTH STANDARD WARRANTY	1

## A.2.2

**Site Performance Expected for T1-2R with Talk-Around**

The additional cables, splitter, and relay affect receiver sensitivity and transmitter output power. Use the attenuation values found in this section to determine the expected site performance. Other base radio and receiver specifications are not affected.

Table 82: Total Transmit and Receive Attenuation for T1-2R with Talk-Around

Band Type Attenuation	CA01957AA: T1-2R
VHF Rx 1	0.6 dB typical 0.8 dB maximum
VHF Rx 2	0.9 dB typical 1.1 dB maximum
VHF Tx	0.8 dB typical 1.0 dB maximum
UHF Rx1	0.8 dB typical 1.0 dB maximum
UHF Rx2	1.3 dB typical 1.5 dB maximum
UHF Tx	1.2 dB typical 1.4 dB maximum
800 MHz Rx1	0.9 dB typical 1.1 dB maximum
800 MHz Rx2	1.7 dB typical 1.9 dB maximum

*Table continued...*

Band Type Attenuation	CA01957AA: T1-2R
800 MHz Tx	1.5 dB typical 1.7 dB maximum

## A.2.3

## Installing the T1-2R with Talk-Around Option Kit

### Procedure:

- 1 Install the standalone GTR 8000 Base Radio or GPW 8000 Receiver according to the processes and procedures provided in the Base Radio or Receiver Installation Chapter. Install a duplexer according to the appropriate “Replacing a Duplexer” procedure.



**WARNING:** To guard against personal injury and/or damage to equipment, place the base radio to Service Mode when performing service. Transmit inhibiting the base radio within the Station Status screen in the Configuration/Service Software (CSS) also prevents the transmitter from keying. Remember to place the base radio back to Normal Mode when service is complete.

- 2 If the base radio and receiver are in Normal Mode, ensure that each device is placed in Service Mode, as follows:
  - a Connect to the transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
  - b From the menu, select **File** → **Read Configuration From Device**.
  - c From the menu, select **Service** → **Test And Measurement Screen**.
  - d Click **Change to Service Mode**.
  - e At the confirmation screen, click **OK**.

The device halts activity in the current mode and switches operation to the requested mode.

  - f Disconnect the Ethernet cable from the transceiver module Ethernet service port.
  - g Repeat for each device in the configuration.
- 3 If you choose to turn off the power, set the rocker switch on the front of the associated power supply to the Off (O) position.
- 4 Attach the antenna relay to the backplane of the GTR 8000 Base Radio. See the “Replacing an Antenna Relay” procedure for details.
- 5 Remove the fan module to gain access to the Transceiver Option Card (TOC) on the transceiver module. See [Replacing the Fan Assembly on page 177](#) for details.
- 6 Connect cables to each device according to [Figure 98: T1-2R Talk-Around Option Kit Wiring Diagram on page 256](#).
- 7 Replace the fan modules for the base radio and receivers.
- 8 If you chose to turn off the power, set the rocker switch on the front of the associated power supply to the On (I) position.
- 9 Place each base radio and receiver to Normal Mode, as follows:
  - a Connect to the transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
  - b From the menu, select **File** → **Read Configuration From Device**.
  - c From the menu, select **Service** → **Test And Measurement Screen**.

d At the confirmation screen, click **OK**.

e Click **Change to Normal Mode**.

The device halts activity in the current mode and switches operation to the requested mode.

f Disconnect the Ethernet cable from the transceiver module Ethernet service port.

g Repeat for each device in the configuration.

#### A.2.4

### Configuring the T1-2R with Talk-Around Option Kit

**Prerequisites:** Ensure that all required installation procedures have been performed for the base radio and receiver and that the devices have been powered up.

**When and where to use:** This procedure is used to configure the WildCard Tables for a T1-2R with Talk-Around configuration using the Configuration/Service Software (CSS).

#### Procedure:

- 1 If necessary, perform the initial configuration for the base radio. See [Device Configuration in CSS on page 115](#) for details.
- 2 Connect to the Ethernet port on the base radio. See [Connecting Through an Ethernet Port Link on page 121](#) for details.
- 3 From the menu, select **File** → **Read Configuration From the Device**.
- 4 From the navigation pane, select **Hardware Configuration**. Set *Station Type [R]* to **Analog Only**.



**NOTICE:** When configuring GPW 8000 Receivers, the **Hardware Platform [R]** parameter is set to **GPW 8000 Satellite Receiver**.

- 5 Set **Antenna Relay [R]** to **Enabled**.



**NOTICE:** Use the default value of 30 msec for the Antenna Relay Delay.

- 6 From the navigation pane, select **WildCard Tables**. Click **Set to Default** to add default WildCard tables.
- 7 Click **Yes** to reset the WildCard Tables to their default structure. The following default WildCard Tables are created:



**NOTICE:** WildCard Table numbers are arbitrary and shown for illustration purposes. Memory size and the number of States and Commands in each table limit the maximum number of WildCard tables.

Wild-Card Table	Descrip-tion	States and Condi-tion		Actions		Inactions	
		State	Value	Com-mand	Value	Com-mand	Value
1	In-cabi-net RPT	Input 6	n/a	In-cabi-net Re-peat ON	n/a	In-Cabi-net Re-peat OFF	n/a
2	Rx In-hibit	Input 7	n/a	RX IN-HIBIT	n/a	RX EN-ABLE	n/a

*Table continued...*

3	External PTT	Input 5	n/a	Key from Wi-deband	n/a	Dekey from Wi-deband	n/a
4	RD STAT-RX ACT	RX Qualifiers Met	n/a	Set Output (1..12)	7	Clear Output (1..12)	7
5	Tx Inhibit	Input 3	n/a	TX INHIBIT	n/a	TX ENABLE	n/a
6		TRC Function Tone (1..17)	1	Monitor	n/a	NULL	n/a
7		TRC Function (1..17)	2	Channel (1..16)	1	NULL	n/a
				Key from Wireline	n/a	n/a	n/a
8		LLGT Detect	n/a	NULL	n/a	Dekey from Wireline	n/a
9	T4 if CH2 Conf	TRC Function (1..17)	3	Channel (1..16)	2	NULL	n/a
				Key from Wireline	n/a	n/a	n/a
10	T5 if CH3 Conf	TRC Function (1..17)	8	Channel (1..16)	3	NULL	n/a
				Key from Wireline	n/a	n/a	n/a



**NOTICE:** Table configurations are selected from the TABLE parameter. See [Figure 97: CSS - WildCard Tables Example](#) on page 253 for location of parameter fields.

- 8 From the menu, select **File** → **Write Configuration To Device**.
- 9 From the menu, select **Tools** → **Disconnect** to terminate the connection to the device.
- 10 Repeat steps 1–7 for all GPW 8000 Receivers.



**NOTICE:** Only the default WildCard tables are required for the GPW 8000 Receivers.

- 11 For GPW 8000 Receivers, edit TABLE 2 and change the *State and Conditions* from **Input 7** to **Input 4**.
- 12 From the menu, select **File** → **Write Configuration To Device**.
- 13 From the menu, select **Tools** → **Disconnect** to terminate the connection to the device.

A.3

## T2-2R with Duplexer and Triple Relay Option Kit

The CA01962AA T2-2R with a Duplexer and Triple Relay option kit adds the capability to dynamically tune the TX frequency based on the active channel. The GTR 8000 Base Radio is a normal duplexed repeater while the GPW 8000 Receiver monitors the TX frequency. The other channel is for talk-around (transmit and receive). This option is sometimes called the triple relay option. A GPW 8000 Receiver is used to monitor the second frequency.


A standalone T7039A GTR 8000 Base Radio is required for this option kit. One GPW 8000 Receiver must be ordered without this option. This option kit includes 3 RF (transmit/receive) antenna relays, control cables, RF cables, and mounting hardware. The base radio must be ordered with the appropriate duplexer option.

All option kit hardware and cables required are included in [Table 83: T2-2R with Duplexer and Triple Relay Option Kit Parts List on page 264](#).



**NOTICE:** The photos and illustrations in this section show the GPW 8000 Receiver with one chassis with one transceiver. A dual-slot chassis with two transceivers is available.

**Figure 99: T2-2R with Duplexer and Triple Relay Configuration**




A712\_T22R\_Duplexer\_Config1



**NOTICE:** Base radio and receiver are shown without fan modules for clarity.


The triple antenna relay tray is illustrated to show the placement of the antenna relays:

**Figure 100: Triple Antenna Relay Tray**

A712\_T22R\_Duplexer\_Relay\_Tray

The wiring diagram for the T2-2R with a Duplexer and Triple Relay option kit outlines the connections for all cables and provides part numbers for each type.

Figure 101: T2-2R with Duplexer and Triple Relay Option Kit Wiring Diagram



**NOTICE:** See [System Connector Ports \(Conventional\)](#) on page 96 for a detailed description of the system connector pinouts.

## A.3.1

**T2-2R with Duplexer and Triple Relay Option Kit Parts List**

The required hardware and cables for the CA01962AA T2-2R with a Duplexer and Triple Relay option kit are listed in this section.

Table 83: T2-2R with Duplexer and Triple Relay Option Kit Parts List

FRU	Kit	Part Number	Description	Quantity
DLN6800			<b>T2-2R DUPLXR AND TRPL RELAY</b>	1
A	CLN8793		<b>HARDWARE, T2-2R DUPLXR AND TRPL RELAY</b>	1
	A	0285854Y01	NUT, M6-GROUND WIRE TO STUDS ON TRAY	2
		0310909A54	SCREW 3.5X30MM ANT RELAY MTG	6
		0310909E46	SCRMCH M3.5X0.6X8 ANT CONN & SIDE BRKTS	20
		0312016A49	SCREW FRONT PANEL TO CHASSIS (blk)	4
		0312016A54	SCRTPG M6 X 1 X 10 (blk) TRAY TO RACK	4
		07009370001	BRACKET CHASSIS SUPPORT	2
		27009304001	CHASSIS, PERIPHERAL	1
		40009272002	RELAY, COAXIAL 29V	3
		5682347B20	BAG FOR SCREWS	1
		64009317001	PANEL, FRONT	1
		0285504U05	CAGE NUT, M6 FOR CABINET MTG	4
		0310909C91	SCREW M6-GROUND CABLE TO BUS BAR AND TRAY TO CABINET CAGE NUTS	5
CKN694			<b>CABLES, T2-2R DUPLXR AND TRPL RELAY</b>	1
6A			CABLE, TRIPLE RELAY	1
		30009379001	CBL N-N M-M 32.5 CM	2
		3013942M11	CBL N-N M-M 75 CM	1
		3013942M23	CBL N-N M-M 110 CM	2
		3013942P19	CBL N-N M-F PNL 55 CM	1
		3013943E25	CBL N-BNC M-M 85 CM	1
		3013943E27	CBL N-BNC M-M 95 CM	1
		3084848Y01	CABLE RELAY W/TEMP	1
		3071488H08	CABLE, GROUND TRAY TO BUS BAR	1
		58009291001	Adapter, N Plug to BNC Jack	2

Table continued...

FRU	Kit	Part Number	Description	Quantity
		4210217A04	STRAP TIE .184X7.31 NYL BLK	10
		5682347B21	BAG, PLASTIC 584 X 431 MM	1
		SVCWARR12	12 MONTH STANDARD WARRANTY	1

## A.3.2

**Site Performance Expected for T2-2R with Duplexer and Triple Relay**

The additional cables, and relays affect receiver sensitivity and transmitter output power. Use the attenuation values found in this section to determine the expected site performance. Other base radio and receiver specifications are not affected.

Table 84: Total Transmit and Receive Attenuation for T2-2R with Duplexer and Triple Relay

Band Type	Attenuation	CA01962AA: T2-2R
VHF Rx 1		1.0 dB typical 1.2 dB maximum
VHF Rx 2		1.2 dB typical 1.5 dB maximum
VHF Tx		1.4 dB typical 1.7 dB maximum
UHF Rx1		1.6 dB typical 1.8 dB maximum
UHF Rx2		1.9 dB typical 2.1 dB maximum
UHF Tx		2.0 dB typical 2.4 dB maximum
800 MHz Rx1		2.2 dB typical 2.5 dB maximum
800 MHz Rx2		2.6 dB typical 2.9 dB maximum
800 MHz Tx		2.9 dB typical 3.3 dB maximum

## A.3.3

## Installing the T2-2R with Duplexer and Triple Relay Option Kit

**Procedure:**

- 1 Install the standalone GTR 8000 Base Radio or GPW 8000 Receiver according to the processes and procedures provided in the Base Radio or Receiver Installation Chapter. Install a duplexer according to the appropriate “Replacing a Duplexer” procedure.



**WARNING:** To guard against personal injury and/or damage to equipment, switch the base radio to Service Mode when performing service. Transmit inhibiting the base radio within the Station Status screen in the Configuration/Service Software (CSS) also prevents the transmitter from keying. Remember to switch the base radio back to Normal Mode when service is complete.

- 2 If the base radio and receiver are in Normal Mode, ensure that each device is placed to Service Mode, as follows:

- a Connect to the transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
- b From the menu, select **File → Read Configuration From Device**.
- c From the menu, select **Service → Test And Measurement Screen**.
- d Click **Change to Service Mode**.
- e At the confirmation screen, click **OK**.

The device halts activity in the current mode and switches operation to the requested mode.

- f Disconnect the Ethernet cable from the transceiver module Ethernet service port.
- g Repeat for each device in the configuration.

- 3 If you choose to turn off the power, set the rocker switch on the front of the associated power supply to the Off (O) position.
- 4 Remove the fan module to gain access to the Transceiver Option Card (TOC) on the transceiver module. [Replacing the Fan Assembly on page 177](#) for details.
- 5 Connect cables to each device according to [Figure 101: T2-2R with Duplexer and Triple Relay Option Kit Wiring Diagram on page 263](#).



**NOTICE:** When the GTR 8000 Base Radio or GPW 8000 Receiver is ordered with the preselector option, the type N to BNC adaptor (58009291001) must be used on the receiver end of RF cables.

- 6 Replace the fan modules for the base radio and receivers.
- 7 If you chose to turn off the power, set the rocker switch on the front of the associated power supply to the On (I) position.
- 8 Place the base radio and receivers to Normal Mode, as follows:

- a Connect to the transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 121](#).
- b From the menu, select **File → Read Configuration From Device**.
- c From the menu, select **Service → Test And Measurement Screen**.
- d Click **Change to Normal Mode**.
- e At the confirmation screen, click **OK**.

The device halts activity in the current mode and switches operation to the requested mode.

- f Disconnect the Ethernet cable from the transceiver module Ethernet service port.
- g Repeat for each device in the configuration.

#### A.3.4

### Configuring the T2-2R with Duplexer and Triple Relay Option Kit

**Prerequisites:** Ensure that all required installation procedures have been performed for the base radio and receiver and that the devices have been powered up.

**When and where to use:** This procedure is used to configure a T2-2R with Duplexer and Triple Relay configuration using the Configuration/Service Software (CSS).

#### Procedure:

- 1 If necessary, perform the initial configuration for the base radio and receivers. See [Device Configuration in CSS on page 115](#) for details.
- 2 Connect to the Ethernet port on the device. See [Connecting Through an Ethernet Port Link on page 121](#) for details.
- 3 From the menu, select **File → Read Configuration From the Device**.
- 4 From the navigation pane, select **Hardware Configuration**. Set **Station Type [R]** to **Analog Only**.
 

 **NOTICE:** When configuring GPW 8000 Receivers, the **Hardware Platform [R]** parameter is set to **GPW 8000 Satellite Receiver**. The Antenna Relay [R] parameter is not configurable for GPW 8000 Receivers.
- 5 Set **Antenna Relay [R]** to **Enabled**.
- 6 Set **Antenna Relay Delay** to **80 msec**.
 

 **NOTICE:** The 80 msec antenna relay delay is required to allow sufficient time for all antenna relays to propagate the transmission signal from the GTR 8000 Base Radio. This step is not required for GPW 8000 Receivers.
- 7 From the navigation pane, select **WildCard Tables**. Click **Set to Default** to add default WildCard tables.
- 8 Click **Yes** to reset the WildCard Tables to their default structure. The following default WildCard Tables are created:
 

 **NOTICE:** WildCard Table numbers are arbitrary and shown for illustration purposes. Memory size and the number of States and Commands in each table limit the maximum number of WildCard tables.

Wild-Card Table	Descrip-tion	States and Condi-tion		Actions		Inactions	
		State	Value	Com-mand	Value	Com-mand	Value
1	In-cabi-net RPT	Input 6	n/a	In-cabi-net Re-peat ON	n/a	In-Cabi-net Re-peat OFF	n/a
2	Rx In-hibit	Input 7	n/a	RX IN-HIBIT	n/a	RX EN-ABLE	n/a

*Table continued...*

3	External PTT	Input 5	n/a	Key from Wi-deband	n/a	Dekey from Wi-deband	n/a
4	RD STAT-RX ACT	RX Qualifiers Met	n/a	Set Output (1..12)	7	Clear Output (1..12)	7
5	Tx Inhibit	Input 3	n/a	TX INHIBIT	n/a	TX ENABLE	n/a
6		TRC Function Tone (1..17)	1	Monitor	n/a	NULL	n/a
7		TRC Function (1..17)	2	Channel (1..16)	1	NULL	n/a
				Key from Wireline	n/a	n/a	n/a
8		LLGT Detect	n/a	NULL	n/a	Dekey from Wireline	n/a
9	T4 if CH2 Conf	TRC Function (1..17)	3	Channel (1..16)	2	NULL	n/a
				Key from Wireline	n/a	n/a	n/a
10	T5 if CH3 Conf	TRC Function (1..17)	8	Channel (1..16)	3	NULL	n/a
				Key from Wireline	n/a	n/a	n/a



**NOTICE:** Table configurations are selected from the TABLE parameter. See [Figure 97: CSS - WildCard Tables Example](#) on page 253 for location of parameter fields.

9 Click **Add** and populate the new WildCard table, as follows:

Wild-Card Table	De-scrip-tion	States and Condition				Actions		Inactions	
		State	Value	Con-dition	State	Com-mand	Value	Com-mand	Value
11	Keyed on Channel (1..16)	Cur-rent Chan-nel (1..16)	2	AND	Sta-tion Keyed	WAIT (10..1000 msec)	80	Chan-nel (1..16)	1

*Table continued...*

Clear 7  
Out-  
put  
(1..12  
)

**10** Click **Add** and populate the new WildCard table, as follows:

Wild-Card Table	De-scrip-tion	States and Condition				Actions		Inac-tions
		State	Value	Condi-tion	State	Com-mand	Value	
12	De-keyed on Ch	Cur-rent Chan-nel (1..16)	2	AND NOT	Station Keyed	Set Output (1..12)	7	NULL

**11** Click **Add** and populate the new WildCard table, as follows:

Wild-Card Table	De-scrip-tion	States and Condition				Actions		Inac-tions
		State	Value	Condi-tion	State	Com-mand	Value	
13	De-keyed on Ch	Cur-rent Chan-nel (1..16)	1	AND NOT	Station Keyed	Clear Output (1..12)	7	NULL

**12** From the menu, select **File** → **Write Configuration To Device**.

**13** From the menu, select **Tools** → **Disconnect** to terminate the connection to the device.

**14** Repeat steps 1–8 for all GPW 8000 Receivers.



**NOTICE:** Only the default WildCard tables are required for the GPW 8000 Receivers.

**15** For GPW 8000 Receivers, edit TABLE 2 and change the *State and Conditions* from **Input 7** to **Input 4**.

**16** From the menu, select **File** → **Write Configuration To Device**.

**17** From the menu, select **Tools** → **Disconnect** to terminate the connection to the device.

This page intentionally left blank.