

System Release 7.17.2
ASTRO® 25
INTEGRATED VOICE AND DATA



ATIA Log Viewer

User Guide

NOVEMBER 2017

MN004288A01-A

Copyrights

The Motorola Solutions products described in this document may include copyrighted Motorola Solutions computer programs. Laws in the United States and other countries preserve for Motorola Solutions certain exclusive rights for copyrighted computer programs. Accordingly, any copyrighted Motorola Solutions computer programs contained in the Motorola Solutions products described in this document may not be copied or reproduced in any manner without the express written permission of Motorola Solutions.

© 2017 Motorola Solutions, Inc. All Rights Reserved

No part of this document may be reproduced, transmitted, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without the prior written permission of Motorola Solutions, Inc.

Furthermore, the purchase of Motorola Solutions products shall not be deemed to grant either directly or by implication, estoppel or otherwise, any license under the copyrights, patents or patent applications of Motorola Solutions, except for the normal non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Disclaimer

Please note that certain features, facilities, and capabilities described in this document may not be applicable to or licensed for use on a specific system, or may be dependent upon the characteristics of a specific mobile subscriber unit or configuration of certain parameters. Please refer to your Motorola Solutions contact for further information.

Trademarks

MOTOROLA, MOTO, MOTOROLA SOLUTIONS, and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.

European Union (EU) Waste of Electrical and Electronic Equipment (WEEE) directive



The European Union's WEEE directive requires that products sold into EU countries must have the crossed out trash bin label on the product (or the package in some cases).

As defined by the WEEE directive, this cross-out trash bin label means that customers and end-users in EU countries should not dispose of electronic and electrical equipment or accessories in household waste.

Customers or end-users in EU countries should contact their local equipment supplier representative or service centre for information about the waste collection system in their country.

This page intentionally left blank.

Contact Us

Motorola Solutions Support Center

The Solutions Support Center (SSC) is the primary Motorola Solutions support contact. Call:

- Before any software reload.
- To confirm troubleshooting results and analysis before removing and replacing a Field Replaceable Unit (FRU) and Field Replaceable Entity (FRE) to repair the system.

For...	Phone
United States Calls	800-221-7144
International Calls	302-444-9800

North America Parts Organization

For assistance in ordering replacement parts or identifying a part number, contact the Motorola Solutions Parts organization. Your first response when troubleshooting your system is to call the Motorola Solutions SSC.

For...	Phone
Phone Orders	800-422-4210 (US and Canada Orders) For help identifying an item or part number, select choice 3 from the menu.
	302-444-9842 (International Orders) Includes help for identifying an item or part number and for translation as needed.
Fax Orders	800-622-6210 (US and Canada Orders)

Comments

Send questions and comments regarding user documentation to documentation@motorolasolutions.com.

Provide the following information when reporting a documentation error:

- The document title and part number
- The page number with the error
- A description of the error

We welcome your feedback on this and other Motorola Solutions manuals. To take a short, confidential survey on Motorola Solutions Customer Documentation, go to docsurvey.motorolasolutions.com or scan the following QR code with your mobile device to access the survey.



This page intentionally left blank.

Document History

Version	Description	Date
MN004288A01-A	Original release of the <i>ATIA Log Viewer User Guide</i> .	November 2017

This page intentionally left blank.

Contents

Copyrights.....	3
Contact Us.....	5
Document History.....	7
List of Figures.....	11
List of Tables.....	13
List of Procedures.....	15
About ATIA Log Viewer User Guide.....	17
What is Covered in This Manual.....	17
Helpful Background Information.....	17
Related Information.....	17
Chapter 1: Description.....	19
1.1 ATIA Log Viewer Overview.....	19
1.1.1 ATIA Log Viewer Features.....	19
1.2 ATIA Log Viewer Window.....	20
Chapter 2: Operation.....	21
2.1 Viewing ATIA Logs.....	21
2.2 Downloading ATIA Logs Interactively.....	22
2.3 Downloading ATIA Logs Non-Interactively.....	23
2.4 Accessing Archived ATIA Logs.....	23
2.5 Closing ATIA Log Files.....	25
2.6 Closing ATIA Log Viewer.....	26
Chapter 3: Reference.....	27
3.1 ATIA Log Viewer Dialog Box.....	27
3.1.1 ATIA Log Viewer Window.....	27
3.1.2 Menu Options in the ATIA Log Viewer Window.....	28

This page intentionally left blank.

List of Figures

Figure 1: ATIA Log Viewer Window.....	21
Figure 2: ATIA Server Host Key Warning Window.....	22
Figure 3: Archived Logs Tab.....	24
Figure 4: Unpacked Log Tab.....	25

This page intentionally left blank.

List of Tables

Table 1: ATIA Log Viewer Tabs Description.....	27
Table 2: ATIA Log Viewer Menu Options	28

This page intentionally left blank.

List of Procedures

Viewing ATIA Logs	21
Downloading ATIA Logs Interactively	22
Downloading ATIA Logs Non-Interactively	23
Accessing Archived ATIA Logs	23
Closing ATIA Log Files	25
Closing ATIA Log Viewer	26

This page intentionally left blank.

About ATIA Log Viewer User Guide

The Air Traffic Information Access (ATIA) Log Viewer is a Motorola System Traffic Monitor (STM) Suite application that displays log files generated by the Air Traffic Router server application (ATR) and ZoneWatch. These log files contain records of all recent zone activity, such as site registrations and calls processed.

What is Covered in This Manual

This document describes the ATIA Log Viewer application of the Motorola Private Radio Network Management system.

This document contains the following chapters:

- [Description on page 19](#)
- [Operation on page 21](#)
- [Reference on page 27](#)

Helpful Background Information

Motorola Solutions offers various courses designed to assist in learning about the system. For information, go to <http://www.motorolasolutions.com/training> to view the current course offerings and technology paths.

Related Information

Refer to the following documents for associated information about the radio system.

Related Information	Description
<i>Standards and Guidelines for Communication Sites</i>	Provides standards and guidelines that should be followed when setting up a Motorola Solutions communications site. Also known as the R56 manual. This document may be purchased by calling the North America Parts Organization at 800-422-4210 (or the international number: 302-444-9842).
<i>System Overview and Documentation Reference Guide</i>	Provides an overview of the ASTRO® 25 new system features, documentation set, technical illustrations, and system-level disaster recovery that support the ASTRO® 25 radio communication system.
<i>Securing Protocols with SSH Feature Guide</i>	Provides information on the implementation and management of the Secure Shell (SSH) protocol for secure transmission of data between devices in ASTRO® 25 systems, including configuration sequences that minimize downtime when adding this feature to a system that is already in operation.

This page intentionally left blank.

Chapter 1

Description

The Air Traffic Information Access (ATIA) Log Viewer is a Private Radio Network Management (PRNM) Suite application that displays the Air Traffic Router (ATR) log files. These log files contain records of all recent zone activity, such as site registrations and processed calls.

1.1

ATIA Log Viewer Overview

The ATIA Log Viewer application permits you to view the “raw” ATIA data straight from the ATIA log files. For an overview, see the following figure.

The ATIA Log Viewer allows you to examine air traffic historical data within channels and sites in the zone, within a particular time interval.



IMPORTANT: ATIA data logging must be enabled through the Air Traffic Router (ATR) server Administration Menu. Otherwise, no ATIA log data is collected for viewing.

1.1.1

ATIA Log Viewer Features

The ATIA Log Viewer application displays ATIA log files that have been archived in the zone. ATIA messages are recorded and archived daily for all call processing activities and other site events in the zone. The ATIA Log Viewer allows you to select one of the daily log files and view activities that took place in the system.

The ATIA Log Viewer allows you to examine air traffic historical data in a specified zone for one or more specified time intervals. ATIA Log Viewer displays the following data:

- Radio events that have occurred within a zone, active sites, channel numbers, and radio affiliations
- Events occurring at specified intervals in the zone.

This feature is normally used to examine data logs when debugging the system. The ATIA Log Viewer records the last 25 hours of ATIA data packets on the ATR server application. The data displays on an hourly basis, and you can select the interval packets that you want to view. Additionally ATIA Log Viewer provides daily archives for up to 30 days, if there is enough allocated disk space.

The data is displayed in an easy-to-read, text-based format which can be printed, saved, or copied into a third-party application for future evaluation.

ATIA messages include the date, time, and description of the event that occurred (such as a radio registration, call request, or site handover).

ATIA Log Viewer allows to download binary log files and archives from ATR server application using either ATIA Log Viewer menu option “Save as” or the non-interactive options.

The ATR log files are transferred to the ATIA Log Viewer using the File Transfer Protocol (FTP), and decoded into a text format. The maximum size of a log file generated within an hour cannot exceed a specified value (20 MB). When the limit is reached, a new log file is generated. If the size of a log file does not exceed the limit, the data is displayed on an hourly basis. Otherwise, the data is displayed whenever a new log file is generated.

There is a possibility to watch archived logs stored on a local drive. They are displayed in a separate tab. For more information on how to access them go to [Accessing Archived ATIA Logs on page 23](#) section.

The ATIA Log Viewer allows to save binary log files and archives from ATR server application with **Save as** menu option. For more information, see: [Downloading ATIA Logs Interactively on page 22](#) section.

The ATIA Log Viewer supports Controlled Channel Access Data calls. You can view logs of call processing events and resource assignments for both classic and CCA Data calls.

The ATIA Log Viewer supports Random Access Data calls. You can view logs of call processing events and resource assignments for both classic and RA Data calls.

The ATIA stream contains information necessary to distinguish between FDMA and TDMA call types for talkgroup, emergency, multigroup, supergroup (patch and msel), interconnect, and unit-to-unit calls.

1.2

ATIA Log Viewer Window

This section describes the ATIA Log Viewer Window.

The ATIA Log Viewer Window consists of three menus and the list of available report dates from the most recent log files. The report date includes: time, day, date, year, and size. For files stored on the ATR server, the time denotes the time of the arrival of the first packet logged to a file. Time and date portions denote the time when a log was created. In case of files opened from a local drive, what is shown is only a file name.

The contents pane consists of three tabs:

- Current logs tab – shows current logs.
- Local logs tab – shows logs added by the user.
- Archived logs tab – shows archived logs in zip format. When one is chosen, it is displayed in the fourth tab.

The ATIA Log Viewer application launches a document processor associated with doc files. In this example, the document processor is Wordpad.

Chapter 2

Operation

The ATIA Log Viewer application performs several user-oriented functions.

2.1

Viewing ATIA Logs

The ATIA Log Viewer allows you to examine air traffic historical data in a specified zone for a particular time interval or intervals. shows you how to use the ATIA Log Viewer to select, open, and examine data log files.

Prerequisites: ATIA data logging must be enabled through the Air Traffic Router (ATR) Administration Menu. Otherwise, no ATIA log data is collected for viewing. Historical reports data is collected regardless of the ATIA log setting.

Procedure:


- 1 From the Application Launcher, select a zone.

All available applications for the zone appear in the content pane.

- 2 Double-click the **ATIA Log Viewer** folder entry.


The ATIA Log Viewer Window appears with the list of stored logs, as shown in [Figure 1: ATIA Log Viewer Window on page 21](#).

Figure 1: ATIA Log Viewer Window



 **WARNING:** In case the server host key is different than the one cached in the ATIA Log Viewer's registry, a warning window displays informing you that a potential security incident occurs. It is important to verify that no security breach is taking place. If you have any questions or doubts, contact Motorola Solutions or perform the key rotation procedure — see the *Securing Protocols with SSH Feature Guide*.

Figure 2: ATIA Server Host Key Warning Window



 **NOTICE:** ATIA log files which are present on the local hard drive can be opened using a pop-up Windows context menu option **Send To**. To view the ATIA logs, select the desired log file from the local hard drive and right-click the mouse button. Select the **Send To** option and then **ATIA Log Viewer**.

- 3 Select the desired log file from the list (you may select multiple intervals using standard Windows selection techniques), and then click the **View** button.
The log is displayed in the default document processor window.
- 4 You may perform any operation on the log your document processor allows, including printing the log, saving it to another file, or editing it.

2.2

Downloading ATIA Logs Interactively

Use this procedure to save a log file copy for later viewing from the ATIA Log application.

Procedure:

- 1 From the PRNM Suite Application window, select a zone.
All available applications for the zone appear in the content pane.
- 2 Double-click the **ATIA Log Viewer** icon.
The ATIA Log Viewer window appears with a list of stored log files that you can view.
- 3 Select a single log or archive you want to save.
- 4 From the File menu, choose **File → Save As...**
- 5 Choose the directory and filename for the file.
The log file will be downloaded to the selected directory.

- 6 To save logs archive, navigate to **Archived logs**, select the desired archive and tab and repeat [step 4](#) and [step 5](#).

The logs archive will be downloaded to the selected directory.

- 7 To save an unpacked log, navigate to the fourth tab, select the desired log and repeat [step 4](#) and [step 5](#).

The log will be copied to the selected directory.

2.3

Downloading ATIA Logs Non-Interactively

Use this procedure to save a log file copy from the ATR server.

Procedure:

- 1 Press the **WINDOWS** key + **R** to access the Run command prompt.
- 2 For the list of ATIA log files from the ATR server, execute following command:`"<atialv_dir>.\atialv.exe" -DSERVER="<atr_ip>" -DLISTLOGS` where **<atialv_dir>** is the install directory of STM applications and **<atr_ip>** is the IP address of ATR server application.

List of log files available on ATR server names will be printed to console.

- 3 To download a selected log file from the ATR server, type:`"<atialv_dir>.\atialv.exe" -DSERVER="<atr_ip>" -DGETLOG="<log_name>"`



NOTICE: The user needs to have write permission for that directory.

The log file **<log_name>** will be downloaded to the local directory.

- 4 To get the list of ATIA log archives from the ATR server, type:`"<atialv_dir>.\atialv.exe" -DSERVER="<atr_ip>" -DLISTARCHIVES`
- 5 To download a selected archive from the ATR server, type:`"<atialv_dir>.\atialv.exe" -DSERVER="<atr_ip>" -DGETARCHIVE="<archive>"`



NOTICE: The user needs to have write permission for that directory.

The archive is downloaded from ATR to the local directory.

2.4


Accessing Archived ATIA Logs

ATIA Log Viewer allows you to examine archived logs. Previously created ATIA log files are obtainable from the Air Traffic Router. The period of log retention is 30 days. Follow the steps in to view the archived ATIA logs.

Procedure:

- 1 In the contents pane, go to Archived logs tab.


Figure 3: Archived Logs Tab



- 2** Select the archive you want to access.
- 3** Double-click a file.

The file is extracted into the fourth tab.

Figure 4: Unpacked Log Tab



The screenshot shows a Windows application window titled "ATIA log viewer - ZONE008 Zone8". The window has a menu bar with "File", "View", and "Help". Below the menu is a tab bar with "Current logs", "Local logs", "Archived logs", and "Unpacked logs". The "Unpacked logs" tab is selected, indicated by a blue border. Below the tab bar is a table with two columns: "Interval" and "Size". The table lists 24 log files, each with a small icon to its left. The log files are timestamped from 01:00:49 on Friday, January 04, 2013, to 00:00:16 on Saturday, January 05, 2013. The sizes of the files are listed in the "Size" column, with most being 2 kB and one being 4 kB.

Interval	Size
01:00:49 Fri, January 04, 2013	2 kB
02:00:49 Fri, January 04, 2013	2 kB
03:00:49 Fri, January 04, 2013	2 kB
04:00:49 Fri, January 04, 2013	2 kB
05:00:49 Fri, January 04, 2013	2 kB
06:00:49 Fri, January 04, 2013	2 kB
07:00:49 Fri, January 04, 2013	2 kB
08:00:49 Fri, January 04, 2013	2 kB
09:00:49 Fri, January 04, 2013	2 kB
10:00:49 Fri, January 04, 2013	4 kB
11:00:56 Fri, January 04, 2013	32 kB
12:00:39 Fri, January 04, 2013	81 kB
13:00:56 Fri, January 04, 2013	78 kB
14:00:01 Fri, January 04, 2013	15 kB
15:00:19 Fri, January 04, 2013	2 kB
16:00:19 Fri, January 04, 2013	2 kB
17:00:16 Fri, January 04, 2013	2 kB
18:00:16 Fri, January 04, 2013	2 kB
19:00:16 Fri, January 04, 2013	2 kB
20:00:16 Fri, January 04, 2013	2 kB
21:00:16 Fri, January 04, 2013	2 kB
22:00:16 Fri, January 04, 2013	2 kB
23:00:16 Fri, January 04, 2013	2 kB
00:00:16 Sat, January 05, 2013	2 kB

4 Double-click the log file you want to view.

The log is displayed in the default document processor window.

2.5

Closing ATIA Log Files

Procedure:

1 In the text editor, select **File** → **Exit**.

The log file closes.



NOTICE: If changes have been made to the file, you can choose to save it to disk.

2.6

Closing ATIA Log Viewer

Procedure:

- 1 In the **ATIA Log Viewer** dialog box, select **File** → **Exit**.

The **ATIA Log Viewer** dialog box closes.



NOTICE: Close each ATIA log file individually.

Chapter 3

Reference

The ATIA Log Viewer window consists of elements assigned different functions.

3.1

ATIA Log Viewer Dialog Box

The ATIA Log Viewer dialog box contains a list of time intervals that are available for you to select. These intervals encompass the last 24 hours collected in the ATIA log.

3.1.1

ATIA Log Viewer Window

By default, the ATIA Log Viewer has access to the last 24 hours of log files and the older, archived files. The ATR server application keeps the logs for up to 30 days , if the total amount of ATIA data stored does not exceed 40GB. See the following table for description.

The title of the main ATIA Log Viewer window displays additional data;

- <Zone Alias> — reflects the current zone alias that the User is logged on
- <Zone ID> — reflects the current zone ID that the User is logged on
- <Zone Core> — is either "Primary Core" or "Backup Core" depending on whether ATIA Log Viewer is connected to Primary Zone Core or Backup Zone Core

Table 1: ATIA Log Viewer Tabs Description

Tab number	Tab	Description	Default
1	Current logs	Read-only list contains the stored log files that you can choose to view.  NOTICE: Multiple selection of items is possible.	Visible
2	Local logs	Read-only list contains the local log files added by user that you can choose to view.	Visible
3	Archived logs	Read-only list contains the stored archive files that you can choose to open.	Visible
4	Unpacked logs	Read-only list contains the stored log files that you can choose to view.  NOTICE: Only visible when an archived log from the Archived logs tab is open. Multiple selection of items is possible.	Hidden

3.1.2

Menu Options in the ATIA Log Viewer Window

The ATIA Log Viewer Window contains menu options, as shown in the following table.

Table 2: ATIA Log Viewer Menu Options

Menu Option	Sub-Menu Option	Description
File	Open	Opens the ATIA Log Viewer Report Window to show the selected log file. Also, you can execute this option through the shortcut CTRL + O .
	Open Local	Opens single file from the disc. Also, you can execute this option through the shortcut CTRL + L .
	Open Local Directory	Opens the selected folder. Also, you can execute this option through the shortcut CTRL + D .
	Save As...	Saves a single log file or archive to the disc.
View	Exit	Exits the application and closes ATIA Log Viewer Window.
	Refresh	Dynamically refreshes the list of ATIA logs. Also, this option can be executed by pressing the F5 key.
Help	Remove Item from List	Removes the selected file from the list. Also, you can execute this option through the DELETE button.
	Help Topics	Launches the online help for the application. Also, this option can be executed using the shortcut CTRL + T .
	About ATIA	Displays a version and copyright information for the application.